


# Operation Manual

**INKJET PRINTER**  
***Tiger600-1800TS***

**Operation Manual**



You can also download the latest manual from official website.

**MIMAKI ENGINEERING CO., LTD.**

<https://mimaki.com/>

D203673-17  
Original instructions

# TABLE OF CONTENTS

Introduction .....	5
To Ensure Safe Use .....	6
Symbols .....	6
Usage Precautions .....	7
Prohibited Dangerous Actions .....	11
Usage Restrictions.....	13
Usage Restrictions.....	13
Operator Restrictions.....	13
Area Restrictions .....	13
Connecting the Power .....	15
Tiger600 Wiring Configuration .....	15
Ink and Other Liquid Handling Precautions .....	20
Ink Specifications.....	21
Installation Precautions.....	22
Installation Space .....	24
Adjuster Feet .....	25
When Relocating This Machine .....	25
Emergency Stop Switches and Light Curtain .....	26
Warning Labels.....	27

## Chapter 1 Before Use

1.1 Items to be Prepared by the Customer.....	32
1.2 Part Names and Functions .....	33
Front/Rear.....	33
Ink Supply Unit.....	36
Winding unit .....	36
Carriage .....	36
Station.....	37
Platen.....	37
Light Curtain .....	37
Signal tower light .....	38
Drying unit.....	38
Maintenance Switch.....	39
1.3 System Configuration .....	40
Connecting to a Local Network.....	41
1.4 Preparing the RIP PC .....	43
RIP PC System Requirements .....	43
Setting up an Ethernet connection.....	43
Preparations for using TxLink .....	48
Preparations for using RasterLink .....	54
1.5 Ink Tank Replacement Method.....	56
When Ink Near End is Displayed .....	56
When Ink End is Displayed .....	56
Replacing the ink tank .....	56
1.6 Purified Water Replenishment Procedure .....	62
When Purified Water Near End is Displayed .....	62
When Purified Water End is Displayed .....	62
Replenish Purified Water .....	62



---

## Chapter 2 Printing

2.1 Print Process .....	66
2.2 Load the media .....	68
Media .....	68
Preparation .....	70
Loading the Media on the Feeding Air Shaft .....	76
Loading the Paper Core on the Take-up Air Shaft.....	79
Loading Media on to the Printer Main Unit .....	81
Initializing the Tension Bar.....	86
2.3 Setting the Head Gap .....	89
Checking the Head Gap Value .....	89
2.4 Test Printing.....	90
Checking Print Head Discharge.....	90
Ejection Failures .....	92
2.5 Head Cleaning .....	93
Cleaning.....	93
Powerful Cleaning.....	93
2.6 Correcting the Drop Position.....	95
2.7 Preparing a Job (RIP Data) .....	96
When using TxLink .....	96
When using RasterLink.....	106
2.8 Printing.....	113
Starting Printing .....	113
Stopping Printing .....	115
Skipping the wait until heater temperature is reached.....	116
Printing Using Nozzle Recovery .....	117

## Chapter 3 Settings (MPC)

3.1 Mimaki Printer Controller .....	122
Screen structure .....	122
3.2 Print menu .....	126
3.3 Maintenance Menu .....	127
Registering abnormal nozzle with the nozzle check tool .....	129
Nozzle recovery registration .....	138
3.4 Setting 1 Menu.....	142
3.5 Setting 2 Menu.....	144
Brake function.....	145
3.6 History Menu.....	148
3.7 System menu.....	149
Power Supply.....	150

## Chapter 4 Maintenance

4.1 Maintenance Precautions .....	154
4.2 Maintenance Timing .....	155
Items Required for Maintenance.....	155

4.3 Performing Maintenance .....	157
Wiper Cleaning .....	157
Carriage Underside Cleaning .....	159
Wiper Unit Cleaning .....	161
Flushing Box Cleaning .....	161
Waste Ink Tank Waste Ink Level Checking .....	162
Platen Cleaning .....	163
X Drive Roller Cleaning .....	163
Ink Maintenance .....	164
Drying Fan Filter Cleaning .....	165
Jam Sensor Detecting Plate Cleaning .....	166
Exterior Cleaning (e.g., cover, Y-bar, ) .....	167
Moisture Tray Cleaning.....	167
Performing supply test .....	169
Drying Unit Cleaning.....	171
Cleaning the Print Head Nozzle Surface .....	172
4.4 Consumable Item Replacement .....	174
Wiper Replacement .....	174
Carriage Filter Replacement.....	175
Blower Filter Replacement.....	176
Ink filter replacement .....	177

## Chapter 5 Troubleshooting

5.1 Troubleshooting .....	184
The power does not turn on.....	184
Printing is not possible.....	184
The media jams or the media is dirty.....	184
The media is skewed (winding shift).....	184
Image defects occur. ....	185
Ink has leaked out.....	186
Touch panel operation is not possible. ....	186
5.2 Problems Indicated by Messages.....	187
5.3 Collecting Logs .....	202

## Chapter 6 Appendix

6.1 Specifications.....	206
6.2 LICENSE Library .....	208

# Introduction

Thank you for purchasing the Inkjet printer Tiger600 Series.

Read this operating manual ("this document" hereinafter) thoroughly and make sure you understand its contents to ensure safe and correct use of the product.

Please note that the illustrations contained in this manual are intended to show functions, procedures, or operations and may sometimes differ slightly from the actual machine.

Adobe, the Adobe logo, Acrobat, Illustrator, Photoshop, and PostScript are the trademarks or registered trademarks of Adobe Incorporated in the United States and other countries.

RasterLink and TxLink are trademarks or registered trademarks of Mimaki Engineering Co. Ltd. in Japan and other countries.

Other company and product names mentioned herein are the trademarks or registered trademarks of the respective companies in Japan and in other countries.

Unauthorized reproduction of any portion of this document is strictly prohibited.

© 2023 MIMAKI ENGINEERING Co., Ltd.

## ● DISCLAIMERS

- MIMAKI ENGINEERING REJECTS ALL LIABILITY FOR DAMAGE ARISING DIRECTLY OR INDIRECTLY FROM THE USE OF THE Tiger600 Series ("THIS MACHINE" HEREINAFTER), WHETHER OR NOT THE PRODUCT IS FAULTY.
- MIMAKI ENGINEERING REJECTS ALL LIABILITY FOR DAMAGE, DIRECT OR INDIRECT, TO MATERIALS CREATED WHILE USING THIS MACHINE.
- USING THIS MACHINE IN CONJUNCTION WITH DEVICES OTHER THAN THOSE RECOMMENDED BY MIMAKI ENGINEERING MAY RESULT IN FIRE OR ACCIDENTS. SUCH INCIDENTS ARE NOT COVERED BY THE PRODUCT WARRANTY. MIMAKI ENGINEERING REJECTS ALL LIABILITY FOR DAMAGE, DIRECT OR INDIRECT, ARISING FROM SUCH INCIDENTS.
- USE ONLY GENUINE MIMAKI ENGINEERING INK AND MAINTENANCE LIQUID. USE OF OTHER PRODUCTS MAY RESULT IN FAILURES OR REDUCE PRINT QUALITY. SUCH INCIDENTS ARE NOT COVERED BY THE PRODUCT WARRANTY. MIMAKI ENGINEERING REJECTS ALL LIABILITY FOR DAMAGE, DIRECT OR INDIRECT, ARISING FROM SUCH INCIDENTS.
- DO NOT ATTEMPT TO REFILL THE INK TANKS WITH UNAUTHORIZED INK. SUCH INCIDENTS ARE NOT COVERED BY THE PRODUCT WARRANTY. MIMAKI ENGINEERING REJECTS ALL LIABILITY FOR DAMAGE, DIRECT OR INDIRECT, ARISING FROM SUCH INCIDENTS.

## ● TV and radio interference



- The machine emits high-frequency electromagnetic radiation while operating. Under certain circumstances, this may result in TV or radio interference. We make no guarantee that this machine will not affect special radio or TV equipment.

If radio or TV interference occurs, check the radio or TV reception after turning off the machine. If the interference disappears when the power is turned off, the machine is likely to be the cause of the interference.










Try any of the following solutions or combinations of these solutions:

- Change the orientation of the TV or radio antenna to find a position where interference does not occur.
- Move the TV or radio away from this machine.

# To Ensure Safe Use

## Symbols

In this manual, the symbols indicate and explain precautions. Make sure you fully understand the meaning of each symbol and use the machine safely and correctly.

Explanation		
	Warning	Indicates a potential hazard that may result in death or serious injury if handled improperly or if instructions are disregarded.
	Caution	Indicates a potential hazard that may result in minor or moderate injury if handled improperly or if instructions are disregarded.
	Notice	Indicates a potential hazard that may result in property damage if handled improperly or if instructions are disregarded.
	Warning sign	Indicates something that requires attention. Warning specifics are drawn inside the symbol.
	Mandatory action sign	Indicates an action that must be carried out. The specifics of the mandatory action are drawn inside the symbol.
	Prohibition sign	Indicates a prohibited action. The specifics of the prohibited action are drawn inside the symbol.
	Important	Indicates important information related to use of this machine.
	Tip	Indicates useful reference information.
	Reference information	Indicates the corresponding page for related information.

## Usage Precautions

### ● In the event of abnormal conditions

#### WARNING



- In the event of abnormal conditions such as smoke or unusual odor, turn off the main power immediately and turn off the breaker. Continuing to use the machine under these conditions may result in failure, electric shock, or fire. Once you have confirmed that smoke is no longer being emitted, contact your local dealer or our service office. Never attempt to repair the machine yourself, which is hazardous.

#### CAUTION



- Immediately wipe off any ink, maintenance liquid, waste ink, or other liquid used with the product that comes into contact with your skin. Then wash using soap, and rinse with plenty of water. Failure to wash off ink may result in skin inflammation. If your skin becomes irritated or painful, seek medical attention immediately.
- If ink, maintenance liquid, waste ink, or any other liquid used in the product comes into contact with your eyes, rinse immediately with plenty of clean water. Rinse for at least 15 minutes. If you wear contact lenses and they can be easily removed, remove after rinsing for at least 15 minutes with clean water. Be sure to also rinse the undersides of your eyelids. Failure to rinse off ink may result in blindness or impaired vision. If your eyes become irritated or painful, seek medical attention immediately.
- If ink, maintenance liquid, waste ink, or any other liquid used in the product enters your mouth or is swallowed, gargle with water immediately. Do not induce vomiting. Seek medical attention promptly. Inducing vomiting may cause liquid to enter the airway.
- If a large amount of vapor is inhaled, move to a well-ventilated area, keep warm, and rest in a posture that allows easy breathing. If the condition does not improve, seek medical attention promptly.

#### NOTICE



- If an ink leak occurs, turn off the main power immediately and turn off the breaker. Then, contact your local dealer or our service office.

## ● Power supply precautions

### ⚠ WARNING



- Do not damage or modify the power cable. Do not place heavy objects on, heat or stretch it. Doing so may damage the cable, leading to electric shock or fire.
- Do not use the power cable if it is damaged or broken or if the core wire is exposed. Otherwise there is a risk of failure, electric shock, or fire.




- Always connect the machine to a switchboard with grounded polarity. Otherwise there is a risk of failure, electric shock, or fire. All electrical work (Class C grounding work; formerly Type 3 grounding work) must be handled by a licensed electrician.

### NOTICE



- Do not turn off the main power supply for the machine and the power supply for the control PC. Turning off the power supply will disable the automatic maintenance function (including nozzle clogging prevention function and ink discharge channel cleaning function). This increases the risk of ejection failures (such as nozzle clogging or deflection).



- Use the machine with a power supply that meets specifications.
- When connecting the power cable, check the input voltage of the power outlet and the capacity of the breaker. Also, connect each cable to a separate power source with an independent breaker. Connecting to power outlets linked with the same breaker will cause the breaker to trip.

## ● Vacuum unit

### NOTICE



- Do not attempt to disassemble or repair the vacuum unit. Doing so may reduce the vacuum strength or cause abnormal heat generation or failure of this machine.



- Avoid touching the relief valve (pressure regulating valve) and blocking the exhaust port of the vacuum unit. Doing so may reduce the vacuum strength or cause abnormal heat generation or failure of this machine.





- Use at low temperature may cause the vacuum unit to generate a high-pitched noise. This does not indicate a failure.

## ● Do not stand or sit on the machine.

### NOTICE



- Never stand or sit on the platen. Disregarding this precaution may impair the precision of the platen surface and affect print quality.
- Never stand or sit on the drying unit, take-up/feeding motors, or external supply unit. Disregarding this precaution is extremely dangerous and may damage the machine and result in injury.

## ● Caution regarding moving parts

### ⚠ CAUTION



- Keep parts of the body such as the face and hands away from moving parts. Also keep clothing (e.g., loose clothing and accessories) that may impede work away from the machine. Failure to do so may result in injury.



- Long hair should be tied back. Failure to do so may result in injury.

## ● Do not disassemble or repair

### ⚠ WARNING



- Do not attempt to disassemble or repair this machine. Otherwise there is a risk of failure, electric shock, or fire.

## ● About the monitor arm

### ⚠ CAUTION



- The maximum load capacity of the monitor arm is 8 kg. Do not install a monitor that is heavier than the maximum load capacity. Doing so may damage the arm.
- The monitor arm on which the touch panel is mounted is attached to the front of the machine. Take care to avoid bumping into the monitor arm or touch panel and injuring yourself while working.

### NOTICE




- The monitor arm angle can be adjusted to vary the touch panel mounting angle and orientation. Adjust the arm angle so as not to impede the carriage movement range or printing operations.

## ● About the touch panel

### NOTICE



- Do not press, rub, or push the touch panel with excessive force.
- Do not tap the touch panel with a ball-point pen or other hard metal object.
- Do not touch the black outer frame of the screen.
- Do not affix adhesive tape or labels to the touch panel screen or black outer frame. Doing so may reduce sensitivity and prevent operation.



- Immediately wipe off any liquid on the touch panel.
- Take care not to allow any liquids to get inside the touch panel gaps.

## ● Other usage precautions

### ⚠ WARNING



- Keep children away from the machine.

### ⚠ CAUTION



- Do not use the product after consuming medication or alcohol that may impair movement or thinking. Otherwise there is a risk of injury due to incorrect operation.

### NOTICE

## ● Disposing of the product

### ⚠ CAUTION



- Please contact your local retailer or service agent.
- When disposing of the product yourself, contact an industrial waste disposal operator or dispose of the product in accordance with local laws and regulations.



## Prohibited Dangerous Actions

Never perform any of the following dangerous actions while the power is turned on. Disregarding these precautions may result in serious injury (crushing or severing) if the carriage moves, for example during periodic maintenance.

### ● Keep face, hands, and body away from carriage



- Keep your face, hands, and body away from the gap between the carriage and Y-bar.




- Keep your face, hands, and body away from the gaps between the carriage and platen or station.



### ● Keep face, hands, and body away from moving parts



- Keep your face, hands, and body away from the Y-bar belt.




---

● **Keep face, hands, body, and other objects away from cableveyor**

---



- Keep your face, hands, and body away from the Y cableveyor, and do not place objects on top of it.



---

● **Keep face, hands, and body away from underneath platen during operation**

---



- Do not crawl under or insert your face, hands, or body underneath the platen while the machine is operating.

---

● **Keep face, hands, and body away from take-up unit, and do not peer inside during operation**

---



- Keep your face, hands, and body away from the take-up unit, and do not peer inside while the machine is operating.


---

● **Keep hands and objects away from platen**

---



- Keep your face, hands, and body away from the platen, and do not place objects other than media on top of it.



---

● **Do not impede carriage operation**

---



- Do not forcibly move the carriage while it is operating (e.g. during printing and cleaning).

# Usage Restrictions

## Usage Restrictions

### ⚠ WARNING



- The machine includes fast-moving and high temperature parts, which present extreme hazards. The machine must be used only by persons that are fully aware of these potential dangers.

## Operator Restrictions

### ⚠ WARNING




- The machine must be operated only by persons that have received our safety training or who have been trained by such trained personnel.

## Area Restrictions

### ⚠ WARNING



- Persons other than users who have received the appropriate training are prohibited from approaching the machine. Restrictions must be applied to the area indicated in the diagram below. The area restrictions must make it clear that the area is hazardous, for example by installing the machine within a dedicated room or by enclosing it within a fence.
- Implement measures to prevent those other than persons that have received our safety training or who have been trained by such trained personnel from entering the danger area. There is a danger of injury from moving parts such as the carriage or tension bar while printing is in progress if untrained personnel are allowed within the restricted area while the machine is operating.





- If a safety fence is used to restrict the area, this should comply with the EN ISO 13857 standard.
  - If the machine is installed in a dedicated room, locks and safety Interlocks should be provided on the doors to the room, and ultimately a risk assessment should be conducted for the installation before use.
-

# Connecting the Power

The printer requires a large power supply and must be powered directly from the switchboard. Customers must complete any electrical work before the printer is carried in.



- Always connect the machine to a switchboard with grounded polarity. Otherwise there is a risk of failure, electric shock, or fire. All electrical work (Class C grounding work; formerly Type 3 grounding work) must be handled by a licensed electrician.



- Make sure the connections are correct. Incorrect connections may result in damage to the equipment.
- Be careful to avoid problems in wiring configuration.

## Tiger600 Wiring Configuration




- Terminal blocks are attached inside the machine's electrical box. A power cable is not included. The user is responsible for providing power cables. Electrical work between the terminal blocks connecting the switchboard to the main unit must be performed by a licensed electrician.
- Be sure to only use the following types of cables and circuit breakers.
  - (1) Cable: VCT-5.5 mm<sup>2</sup> × 5-core (600 V) or UL-AWG10 × 5C (600 V) or equivalent. Outer sheath external diameter 16 to 25 mm.
  - (2) Circuit breaker: Three-phase four-wire 380 to 415 V AC, 30 A

### ● Wiring connections




- Check the specifications of the switchboard three-phase power supply. A delta-star conversion transformer must be provided if three-phase four-wire star connection wiring is not used.

If the power supply is three-phase Y (star) connected (three wires + neutral)



If the power supply is three-phase Δ (delta) connected (three wires)




## ● List of nominal industrial voltage for major countries

Check the voltage at the installation site beforehand and refer to the following table to ascertain whether a transformer is required.

No.	Nominal industrial voltage [V]	Country	Transformer
1	200 V 3-phase 3-wire	Japan	Required
2	208 V 4-phase 3-wire	USA	
3	220 V 4-phase 3-wire	Brazil	
4	346 V 4-phase 3-wire	Hong Kong	
5	380 V 4-phase 3-wire	China	Not required
6		Taiwan	
7		Thailand	
8		Italy	
9		Spain	
10		Russia	
11		Other 380 V regions	
12	400 V 4-phase 3-wire	India	
13		Belgium	
14		Denmark	
15		France	
16		Germany	
17		Netherlands	
18		Sweden	
19		Switzerland	
20		UK	
21		Portugal	
22		New Zealand	
23		Other 400 V regions	
24	415 V 4-phase 3-wire	Singapore	
25		Malaysia	
26		India	
27		Australia	
28		New Zealand	
29		UK	
30		Other 415 V regions	
31	460 V 4-phase 3-wire	USA	Required
32	480 V 4-phase 3-wire	Mexico	
33	480 V 3-phase 3-wire	Philippines	

## ● Wire preparation

### 1 Strip the power cable sheath as shown in the diagram below.



\*1: Please prepare the wire according to the particular crimp terminal specifications.

### 2 Attach the allowable types of crimp terminals to the L1, L2, L3, N, and FG wires.

- The sheath must be stripped off the wires to a length that is appropriate for the crimp terminal type you are using.
- For more information regarding allowable crimp terminals, see below.

- Terminal block connection details

(1) Model No.: TXUM3004


(2) Manufacturer: Patlite

(3) Terminal screws: M5 × 10

- L1, L2, L3, and N wire end preparation

(1) Preparation method: Ring terminal with insulating layer

(2) Shape:



(3) Examples of allowable crimp terminals:

- N5.5-5 (J.S.T. Mfg)
- FN5.5-5 (J.S.T. Mfg)
- TMEX5.5-5 (Nichifu)

- FG wire end preparation

(1) Preparation method: Ring terminal with insulating layer

(2) Mounting screws: M5 × 10 (3-part SEMS screw)

(3) Examples of allowable crimp terminals:

- N5.5-5 (J.S.T. Mfg)
- FN5.5-5 (J.S.T. Mfg)
- TMEX5.5-5 (Nichifu)


- Screw tightening torque: 2.2 to 2.8 Nm



- Be sure to observe the following three points. Failure to observe the following three points may result in fire, smoke generation, or electric shock.
  - (1) Only use power cables and crimp terminals that satisfy the specifications.
  - (2) Be sure to attach a ring crimp terminal to the end of the power cable.
  - (3) Secure the ring terminal to the terminal block using the specified tightening torque.


### ● Power connection work

- 1** Make sure that the machine main power supply and the switchboard circuit breaker have been turned off.
- 2** Remove the lower cover on the power supply box.
- 3** Loosen the nut on the cable gland, and insert the cable.
  - If the power cable has an outer diameter of 20 mm or less, use the FGA33-22B provided instead.





- 4** Secure the L1, L2, L3, and N wires to the terminal block, and secure the FG wire to the screw hole next to the protective ground name plate.
- Tighten the terminal block screws to a torque of 2.2 to 2.8 Nm.



- 5** Once the cable has been wired in place, secure using the clamps and cable strap.
- 6** Tighten the nut on the cable gland, and replace the lower cover on the power supply box.

# Ink and Other Liquid Handling Precautions

Precautions regarding ink, maintenance liquid, or other liquids used with this machine are included with the containers. Thoroughly read them and make sure you understand the contents.



- Be sure to read the safety data sheet (SDS) before use. <https://mimaki.com/supply/sds/>

## CAUTION



- Pay close attention to ventilation and be sure to wear safety glasses, gloves, and a mask when handling ink, maintenance liquid, waste ink, or other solutions used with the machine. Leaking ink may adhere to the skin or get into the eyes or mouth.



- Do not subject cases containing ink to strong shock or violent shaking. Do not attempt to refill the ink. Leaking ink may adhere to the skin or get into your eyes or mouth.



- Do not disassemble cases containing ink. Leaking ink may adhere to the skin or get into your eyes or mouth.



- Do not store ink, maintenance liquid, or other liquids used with the machine in locations where children may enter.



- When disposing of ink, maintenance liquid or other liquid used with the product, or containers or non-woven fabric contaminated with ink or other liquid, contact an industrial waste disposal operator or dispose of the product in accordance with the local laws and regulations.

## NOTICE



- Do not store ink, maintenance liquid, or other liquids used with the machine in locations exposed to direct sunlight.
- Do not store ink, maintenance liquid, or other liquids used with the machine in environments where cutting fluid or other volatile substances (such as amines or modified amine alcohol) are present in significant quantities. Storage in such places increases the risk of failure or ejection failures (e.g., nozzle clogging or deflection).
- Do not use ink, maintenance liquid, or other liquids used with this machine with other printers. Doing so may cause failure.



- Be sure to store them in a low place no higher than 1 m above the floor. Otherwise there is a risk of scattering if the containers fall.
- Store in tightly sealed containers.
- Store in a cool, dark place.
  - (1) Store ink in a place where ink does not freeze. Using defrosted ink may deteriorate ink constituents and reduce print quality.
  - (2) When ink is moved from a cold place to a warm place, leave it in the environment where the machine is installed for at least three hours, and check that the ink temperature is close to that of the use environment before using it.
  - (3) Open the container just before installing it, and use it up as quickly as possible. If it is opened and left for an extended period of time, print quality may be reduced.



- Do not use ink, maintenance liquid, or other liquids used with this machine with other printers. Doing so may cause failure.

## Ink Specifications

Item		Details
Type		MLSb510
Color		Yellow (Y) Magenta (M) Blue (B) Black (K)
Form		Ink tank or pack-in-box
Ink capacity		10 L
Expiration date		As indicated on the Ink tank. However, ink should be consumed within three months after opening, even if before the expiration date.
Storage temperature	When stored	5 °C to 30 °C (daily mean temperature) However, not more than 1 month at 30 °C <ul style="list-style-type: none"> <li>Ink quality may deteriorate if stored outside these conditions.</li> </ul>
	During transportation	1 °C to 60 °C However, not more than 120 hours at 60 °C, and not more than 1 month at 40 °C <ul style="list-style-type: none"> <li>Where possible, avoid storing in cold locations below 0 °C and hot locations above 40 °C.</li> <li>Ink quality may deteriorate if stored outside these conditions.</li> </ul>



- The ink expiration date is indicated on the ink containers. Expired ink may cause ejection failures or alter the color tone. Printing is possible even if the ink has passed its expiration date. Nevertheless, we recommend replacing with new ink or using up as quickly as possible.

# Installation Precautions

## ⚠ WARNING



- Do not install the machine in a place close to fire.
- Do not place flower vases, pots, cups, containers containing cosmetics, chemicals or water, or small metal items on or close to the machine. If they enter the machine, there is a risk of failure, electric shock, or fire.



- Do not install this machine in humid locations or locations where it may be exposed to splashing water. Otherwise there is a risk of failure, electric shock, or fire.



- Do not install the machine in a place where children may enter.

## ⚠ CAUTION



- A ventilation system must be provided if this machine is installed in a poorly ventilated area or sealed room.
- Be sure to observe the following points when installing an extractor outlet:
  - (1) The extractor outlet must be installed in accordance with applicable local EHS (environmental, health, and safety) guidelines.
  - (2) If the extractor outlet is fitted with a shutoff valve, the valve must be open when this machine is in use.



- Check to confirm that the floor is sufficiently strong to bear the weight of the machine before installing.

## NOTICE



- Do not install this machine in locations where dust or powder is present. Failure or printing defects may result (e.g., nozzle clogging, deflection) if dust gets inside this machine.
- Do not install this machine in locations exposed to drafts (e.g., from air conditioning). Disregarding this precaution may result in dust or powder getting inside this machine.
- Do not install this machine in unstable locations or locations subject to vibration. This will increase the risk of failure or printing defects (e.g., nozzle clogging, deflection).
- Do not install this machine in locations exposed to direct sunlight.
- Do not install this machine in locations subject to sudden temperature changes. This will increase the risk of failure or printing defects (e.g., nozzle clogging, deflection).
- Do not install this machine in locations exposed to excessive noise from large machinery.
- Do not install this machine in locations where photographic fixing agents generate vapor or acid gas (e.g., acetic acid, hydrochloric acid) or locations filled with metal working fluids or highly volatile substances (e.g., amines, amine-modified alcohols). Malfunctions or printing defects may result (e.g., nozzle clogging, deflection) as print head ink is more likely to harden under such environments.




- Operating environment: 20 to 30 °C (68 to 86 °F), 35 to 65%RH (no condensation)
- Temperature range in which accuracy is guaranteed: 20 to 25 °C (68 to 77 °F)



- Install the machine in a location where the entire working area is clearly visible. (Guideline: 300 lux)  
There is a risk of incorrect operation and injury if operated in a dark location.



- Pay particular attention to the following diagram, and avoid installing in such conditions where possible. Conditions in which the side of the station is subject to drafts will increase the risk of nozzle clogging occurring during standby. If using the machine in the conditions described in the diagram below is unavoidable and nozzle clogging occurs during standby, take measures to avoid the station being exposed to direct drafts, such as by installing a partition between the machine and the air conditioner.




## Installation Space

Provide the following space around the machine to allow safe and proper replacement of ink and media:

Item	Tiger600-1800TS
Width <sup>*1</sup>	At least 8,300 mm (5,300 mm)
Depth <sup>*1</sup>	At least 5,800 mm (2,800 mm)
Height <sup>*1</sup>	(1,900 mm)
Weight	1,620 kg

\*1. The figures in parentheses indicate machine dimensions.




- If a safety fence is used to restrict the area, this should comply with the EN ISO 13857 standard.
- If the machine is installed in a dedicated room, locks and safety Interlocks should be provided on the doors to the room, and ultimately a risk assessment should be conducted for the installation before use.



## Adjuster Feet

Do not attempt to adjust the adjuster feet yourself. Doing so may prevent the machine from operating correctly.

If you have any queries, contact your local distributor, our sales office, or service center.




## When Relocating This Machine

Contact your local dealer or our service office. Attempting to handle relocation yourself may result in failure or damage.



- Pay particular attention to the following diagram, and avoid installing in such conditions where possible. Conditions in which the side of the station is subject to drafts will increase the risk of nozzle clogging occurring during standby. If using the machine in the conditions described in the diagram below is unavoidable and nozzle clogging occurs during standby, take measures to avoid the station being exposed to direct drafts, such as by installing a partition between the machine and the air conditioner.



# Emergency Stop Switches and Light Curtain

The machine is equipped with emergency stop switches and a light curtain to ensure safety during use. The light curtain stops the machine when a person or object is detected.



- Check to confirm that the emergency stop switches and light curtain operate correctly before starting operation.




- If an obstruction or danger to the operator occurs, press one of the emergency stop switches to stop the machine and prevent more serious problems from arising.



- To release an emergency stop switch, check to confirm that there are no objects trapped in the feed unit and that the operator is safe before resetting the switch. To reset the emergency stop switch, turn it counterclockwise. Once the emergency stop switch has been reset and the alarm has been cleared on the MPC screen, the feed unit initializes, after which the machine is ready for operation.

## ● Emergency stop switch locations and light curtain detection area

[Front]




- : Light curtain detection area
- : Area not detected by light curtain (area 61.5 mm above the platen and also the sides)
- : Emergency stop switch



















# Warning Labels

Make sure you fully understand the details indicated on the various warning labels.

If any labels are dirty, illegible, or peeling, contact your local dealer or our service office to obtain new ones.



N o.	Order code	Label	Details						
1	M903239		Indicates hot parts.						
2	M903281	<div>See SET UP GUIDE before connecting to the supply. 電源を接続する前に、必ず セットアップガイドを読むこと。 在接通电源之前请一定阅读安装说明书。</div>	Note when connecting the power supply cable.						
3	M903330		Wear safety glasses and gloves while working.						
4	M905624	<table><tr><td><b>⚠ 警告</b> 漏えい電流大 電源へ接続する前に 接地接続が必要</td><td><b>⚠ WARNING</b> HIGH LEAKAGE CURRENT EARTH CONNECTION ESSENTIAL BEFORE CONNECTING SUPPLY</td></tr><tr><td><b>⚠ AVERTISSEMENT</b> COURANT DE FUITE ELEVE CONNECTER LA MISE A LA TERRE AVANT DE CONNECTER L'ALIMENTATION</td><td><b>⚠ WARNING</b> HOHER KRIECHSTROM BITTE ERDKABEL ANSCHLIESSEN BEVOR SIE STROMZUFUHR ANSCHLIESSEN</td></tr></table>	<b>⚠ 警告</b> 漏えい電流大 電源へ接続する前に 接地接続が必要	<b>⚠ WARNING</b> HIGH LEAKAGE CURRENT EARTH CONNECTION ESSENTIAL BEFORE CONNECTING SUPPLY	<b>⚠ AVERTISSEMENT</b> COURANT DE FUITE ELEVE CONNECTER LA MISE A LA TERRE AVANT DE CONNECTER L'ALIMENTATION	<b>⚠ WARNING</b> HOHER KRIECHSTROM BITTE ERDKABEL ANSCHLIESSEN BEVOR SIE STROMZUFUHR ANSCHLIESSEN	Caution regarding current leakage.		
<b>⚠ 警告</b> 漏えい電流大 電源へ接続する前に 接地接続が必要	<b>⚠ WARNING</b> HIGH LEAKAGE CURRENT EARTH CONNECTION ESSENTIAL BEFORE CONNECTING SUPPLY								
<b>⚠ AVERTISSEMENT</b> COURANT DE FUITE ELEVE CONNECTER LA MISE A LA TERRE AVANT DE CONNECTER L'ALIMENTATION	<b>⚠ WARNING</b> HOHER KRIECHSTROM BITTE ERDKABEL ANSCHLIESSEN BEVOR SIE STROMZUFUHR ANSCHLIESSEN								
5	M906115	<table><tr><td></td><td><b>⚠ 警告</b> 手指和身体请勿靠近运动 部位。以免造成危险</td><td><b>⚠ 警告</b> 危険な可動部 指や体を近づけないように</td><td><b>⚠ WARNING</b> HAZARDOUS MOVING PARTS Keep fingers and other body parts away.</td><td><b>⚠ WAARSCHUWING</b> GEFÄHRLICHE BEWEGLICHE TEILE Finger und andere Körperteile fernhalten.</td><td><b>⚠ AVERTISSEMENT</b> PIECES MOBILES DANGEREUSES Doigts et autres parties du corps sont hors de portée.</td></tr></table>		<b>⚠ 警告</b> 手指和身体请勿靠近运动 部位。以免造成危险	<b>⚠ 警告</b> 危険な可動部 指や体を近づけないように	<b>⚠ WARNING</b> HAZARDOUS MOVING PARTS Keep fingers and other body parts away.	<b>⚠ WAARSCHUWING</b> GEFÄHRLICHE BEWEGLICHE TEILE Finger und andere Körperteile fernhalten.	<b>⚠ AVERTISSEMENT</b> PIECES MOBILES DANGEREUSES Doigts et autres parties du corps sont hors de portée.	Caution regarding moving parts.
	<b>⚠ 警告</b> 手指和身体请勿靠近运动 部位。以免造成危险	<b>⚠ 警告</b> 危険な可動部 指や体を近づけないように	<b>⚠ WARNING</b> HAZARDOUS MOVING PARTS Keep fingers and other body parts away.	<b>⚠ WAARSCHUWING</b> GEFÄHRLICHE BEWEGLICHE TEILE Finger und andere Körperteile fernhalten.	<b>⚠ AVERTISSEMENT</b> PIECES MOBILES DANGEREUSES Doigts et autres parties du corps sont hors de portée.				
6	M906222		Caution overhead.						
7	M907764	<div><div><b>注意</b> <b>⚠ CAUTION</b> <b>ATTENTION</b></div><div></div><div>上部に乗るな DO NOT STEP ON TOP NE GRIMPEZ PAS DESSUS</div></div>	Do not climb on top						
8	M907935		Caution regarding high voltage.						
9	M909381	<table><tr><td></td><td><b>⚠ 警告</b> 危険な可動部／指や体を 近づけないように。</td><td><b>⚠ WARNING</b> -HAZARDOUS MOVING PARTS- Keep fingers and other body parts away.</td></tr><tr><td></td><td><b>⚠ WARNING</b> -GEFÄHRLICHE BEWEGLICHE TEILE- Finger und andere Körperteile fernhalten.</td><td><b>⚠ AVERTISSEMENT</b> -PIECES MOBILES DANGEREUSES- Doigts et autres parties du corps sont hors de portée.</td></tr></table>		<b>⚠ 警告</b> 危険な可動部／指や体を 近づけないように。	<b>⚠ WARNING</b> -HAZARDOUS MOVING PARTS- Keep fingers and other body parts away.		<b>⚠ WARNING</b> -GEFÄHRLICHE BEWEGLICHE TEILE- Finger und andere Körperteile fernhalten.	<b>⚠ AVERTISSEMENT</b> -PIECES MOBILES DANGEREUSES- Doigts et autres parties du corps sont hors de portée.	Caution regarding moving parts.
	<b>⚠ 警告</b> 危険な可動部／指や体を 近づけないように。	<b>⚠ WARNING</b> -HAZARDOUS MOVING PARTS- Keep fingers and other body parts away.							
	<b>⚠ WARNING</b> -GEFÄHRLICHE BEWEGLICHE TEILE- Finger und andere Körperteile fernhalten.	<b>⚠ AVERTISSEMENT</b> -PIECES MOBILES DANGEREUSES- Doigts et autres parties du corps sont hors de portée.							

N o.	Order code	Label	Details
1 0	M912054		Caution regarding entrapment.
1 1	M918531		Caution when lifting heavy objects.



# Chapter 1 Before Use



## This chapter


This chapter describes information essential before use, such as part names.

Items to be Prepared by the Customer .....	32	Preparing the RIP PC .....	43
Part Names and Functions .....	33	RIP PC System Requirements.....	43
Front/Rear .....	33	Setting up an Ethernet connection .....	43
Ink Supply Unit .....	36	Preparations for using TxLink .....	48
Winding unit .....	36	Preparations for using RasterLink.....	54
Carriage .....	36	Ink Tank Replacement Method .....	56
Station .....	37	When Ink Near End is Displayed .....	56
Platen .....	37	When Ink End is Displayed .....	56
Light Curtain .....	37	Replacing the ink tank.....	56
Signal tower light.....	38	Purified Water Replenishment Procedure .....	62
Drying unit .....	38	When Purified Water Near End is Displayed .....	62
Maintenance Switch .....	39	.....	62
System Configuration .....	40	When Purified Water End is Displayed .....	62
Connecting to a Local Network .....	41	Replenish Purified Water .....	62

# 1.1 Items to be Prepared by the Customer

The following items should be prepared by the customer before installing the machine.

## ● Equipment and consumable items



No.	Item	Remarks
1	RIP PC	Reference:  "Recommended RIP PC requirements"(P. 43)
2	10 Gb compatible hub	When using multiple machines with the same PC
3	LAN cable	As required
4	Ink	10 L ink tanks for water-based sublimation ink
5	Purified water	-
6	Purified water tank	Max. 220 mm (W) × 350 mm (D) × 400 mm (H) • We recommend using a 20L tank (empty weight: approx. 1100 g) as a purified water tank. If a larger tank is used, the error message "068A: Purified Water Tank Sensor" may appear.
7	Waste ink tank	

## ● Installation environment and equipment


Item	Requirements	Remarks
Main unit power supply	3ø-4L-380 to 415 V AC, 25 A	
Power supply circuit breaker	"Connecting the Power"(P. 15)	
Power cable		Use the cable gland provided (FGA33-22B) for cables with an outer diameter of 20 mm or less.
Transformer		
Air facilities	Compressor capacity: 6 to 8 bar@Dry air	For air chuck shaft
Lifter	"Lifter specifications"(P. 69)	For loading the media

















For more information on other installation environment requirements, refer to "Specifications"(P. 206).



# 1.2 Part Names and Functions

## Front/Rear




No.	Name	Overview
1	Y-bar	The Y-bar is equipped with a carriage. This part moves over the table to print.
2	Platen	Print area.  <a href="#">"Platen"(P. 37)</a>
3	Cable carrier (Y-bar)	Ink tubes and other parts are routed through the cable carrier. Do not insert your hands or other objects into the cable carrier.
4	Carriage	Consists of components such as the print head and jam sensor.  <a href="#">"Carriage"(P. 36)</a>
5	Signal tower light	To confirm machine status, check the color of the illuminated lights. A buzzer sounds to signal that the carriage will begin moving soon.  <a href="#">"Signal tower light"(P. 38)</a>
6	Emergency stop switch	Press to stop the machine in emergencies. Located on the left and right sides on both the front and rear.  <a href="#">"Emergency Stop Switches and Light Curtain"(P. 26)</a>
7	Light Curtain	Detection of a person or object will halt the machine.  <a href="#">"Light Curtain"(P. 37)</a>
8	Station	Includes wipers and a moisture tray to prevent the print head nozzle surface from drying out.  <a href="#">"Station"(P. 37)</a>
9	Waste ink tank	<ul style="list-style-type: none"> <li>• Container for waste ink.  <a href="#">"Waste Ink Tank Waste Ink Level Checking"(P. 162)</a></li> <li>• This should be provided by the customer.  <a href="#">"Items to be Prepared by the Customer"(P. 32)</a></li> </ul>
10	Ink Supply Unit	Supplies ink to the print head from the Ink tank.  <a href="#">"Ink Supply Unit"(P. 36)</a>
11	Touch panel	<p>The touch panel is used to control the machine.  <a href="#">"Mimaki Printer Controller"(P. 122)</a></p> <ul style="list-style-type: none"> <li>• How to operate the touch panel <ul style="list-style-type: none"> <li>– Tap: Select a function.</li> <li>– Long tap: Select multiple jobs.</li> <li>– Swipe: Move the screen up or down.</li> </ul> </li> </ul>
12	Main power switch	The main power supply for the machine. To prevent print head ejection failures (such as nozzle clogging or deflection), do not turn off the main power supply.  <a href="#">"Power Supply"(P. 150)</a>
13	Control PC	Controls the machine. Do not turn off the control PC.  <a href="#">"System Configuration"(P. 40)</a>
14	Winding unit	Consists of the take-up unit and feeding unit.  <a href="#">"Winding unit"(P. 36)</a>
15	Drying unit	Dries the ink on the printed media from underneath the machine.  <a href="#">"Drying unit"(P. 38)</a>
16	Maintenance Switch	Selects maintenance mode (MAINT) or print mode (PRINT).  <a href="#">"Maintenance Switch"(P. 39)</a>
17	Tension bar initializing switch	Initializes the tension bar.
18	Feed switch	Rotates the X drive roller to feed the media. The take-up unit and feeding unit also operate in unison after the tension bar has been initialized.
19	Purified water tank	<ul style="list-style-type: none"> <li>• Used to feed water to the moisturizing tray and to clean the wiper.</li> <li>• This should be provided by the customer.  <a href="#">"Items to be Prepared by the Customer"(P. 32)</a></li> </ul>
20	JOG button	Feeds the take-up unit and feeding unit respectively.




No.	Name	Overview
21	Rotation direction switch CCW/CW	Used to change the rotation direction of the take-up unit and feeding unit respectively.

Ink Supply Unit



No.	Name	Overview
1	Ink tank	Mount the Ink tank. <a href="#">"Replacing the ink tank"(P. 56)</a>
2	Cap cover	Lift up the lever to remove the Ink tank.


Winding unit



No.	Name	Overview
1	Take-up Unit	Rolls up the printed roll media. <a href="#">"Load the media"(P. 68)</a>
2	Feeding unit	Loads the roll media prior to printing. Compatible with 3-inch paper cores.


Carriage

The carriage includes a print head for ejecting ink, and a jam sensor for stopping the carriage when media clogs. Printing occurs as ink is ejected while traversing left and right.




## Station

The station includes a moisture tray for preventing the print head nozzle surface from drying out, and a wiper required for print head maintenance.




## Platen

Print area. The platen secures the media under vacuum pressure.



## Light Curtain

The light curtain is used to stop the machine when a person or object is detected.




- Detection is not possible in the area up to 61.5 mm above the platen and in the areas at the sides. Parts of the body or other objects in this area cannot be detected. This can pose serious hazards because the carriage does not stop moving.

## Signal tower light

The signal tower light allows the machine status to be confirmed from the color of the illuminated lights.



Color	Status	Overview
Red	Illuminated	Error level 2 or 3 <sup>*1</sup> occurrence Printing is not possible due to system failure.
	Off	The printer is operating normally.
Yellow	Illuminated	Error level 0 or 1 <sup>*1</sup> occurrence A recoverable error has occurred. Check the displayed message and take appropriate action.  <a href="#">"Problems Indicated by Messages"(P. 187)</a>
	Off	The printer is operating normally.
Green	Illuminated	Standby state with the power turned on.
	Flashing	Indicates printing is underway.
	Off	Power turned off.

\*1. Error level


- 0: Information: Ink near end, etc.
- 1: Warning: Light curtain detection, etc.
- 2: Error: Ink leak, etc.
- 3: Emergency: Y limit sensor activated, etc.



- Printing cannot be started in level 1 or higher.

## Drying unit

The drying unit consists of the drying heater and drying heater fan. It is located underneath the machine and dries the ink on the printed media.




## Maintenance Switch

Switch for selecting maintenance mode (MAINT) or print mode (PRINT).


Be sure to switch to maintenance mode before carrying out maintenance work.

The light curtain is disabled when in maintenance mode. 🖱️ ["Light Curtain"\(P. 37\)](#)

[Maintenance mode selected]




[Print mode selected]



## 1.3 System Configuration

Use RIP software to prepare jobs (RIP data) from print data created in applications such as Illustrator or Photoshop.

Jobs prepared this way are printed using the MPC (Mimaki Printer Controller) application installed on the machine (control PC).  ["Settings \(MPC\)"](#)(P. 121)



### ● Control PC



- Do not use a web browser if the control PC is connected to the Internet. Using a web browser may create security risks.
- Do not install any software other than that specified by Mimaki on to the control PC. Do not use other than for the MPC. Installing other software may cause serious problems, such as preventing the product from starting up and preventing printing.
- The control PC is connected to the machine with a LAN cable. Never disconnect the LAN cables connected to the machine, as shown in the red frames below.



- Install the control PC no more than 2 m (ideally less than 1.5 m) away from the machine. (Because the LAN cable is 2 m long)


## Connecting to a Local Network

Connect the machine (control PC) and RIP PC via a local network or direct LAN cable to enable jobs (RIP data) to be easily imported. Insert the LAN cable until it clicks into place.


### ● Machine (control PC) and RIP PC configuration

The machine can be connected using one of the following two methods:

- Connection using a LAN cable



- Connection via a local network



### ● LAN connection precautions

- Set up the control PC and the RIP PC to transfer print data on the same network. Connections via a router or using Wi-Fi are not possible.
- The following connection devices should be used for a local network connection.

Device	Required	Recommended
RIP PC LAN port	1 Gbps or higher	10Gbps
LAN cable	CAT 6 or higher	CAT 6A or higher
Switching hub	1 Gbps or higher	10Gbps


### LAN connection checking method

#### ● Check the machine (control PC) status


Check the LAN connector indicators near the bottom on the back of the control PC.

- The LAN connector indicators are illuminated when the system is connected.

- If the indicators are not illuminated, insert the LAN cable until it clicks into place.




LED	Status	Overview
SPEED	Green	Linked via 10GBASE-T
	Yellow	Linked over a connection other than 10GBASE-T
LINK/ACT	Flashing green	Data is being sent and received.
	Green	No network traffic.


- 
- Do not unplug the cable while data is being transferred.

● Check the touch panel

Check [Network setting] on the touch panel.

- 
- Be sure to confirm whether the LAN connector indicator is lit before configuring the following settings.

- From MENU on the touch panel, tap [SETTING 2] > [System setting] > [Network setting]. Check the dialog box. If the LAN connection has been successfully established, the address will be displayed.





# 1.4 Preparing the RIP PC

## RIP PC System Requirements

The customer should provide a RIP PC and network devices that meet the recommended requirements.



- RIP software cannot be installed on the Tiger600-1800TS control PC. The user must provide a separate PC for use with the RIP software. An Internet connection is also required in order to obtain the RIP software license.

### ● Recommended RIP PC requirements

Item	Requirement
OS	Windows 11 <sup>®</sup> Pro 64bit
Processor	Performance equivalent to intel <sup>®</sup> Core i7-7700K (4.2 GHz) or higher
Chipset	Genuine intel <sup>®</sup> chipset
Memory	8 GB or more
Storage	500 GB SSD ×2 or more
Network interface	10 Gigabit Ethernet * PCI Express X1 or higher is required when adding a 10 Gigabit Ethernet board to the PCI.
USB interface	USB 2.0 port (for connecting dongle)
Display	1,920 × 1,200 pixels or more
Optical drive	Optical drive capable of reading CD-ROM


### ● Recommended network environment

Item	Requirement
Network hub * Not required if the machine is directly to the RIP PC.	SW-HUB 10 Gigabit Ethernet compatible
LAN cable	CAT 6A or higher


## Setting up an Ethernet connection

### Sharing a Network


- 1 On the RIP PC, open the Windows start menu and click [Settings].



## 2 Select [Network & Internet].




## 3 Under the "Change your network settings" section, select [Network and Sharing Center].




## 4 Select [Private], [Guest or Public], or [Domain].

- The selection items may vary depending on the network configuration. Contact your network administrator.




## 5 Select [Turn on network discovery] and click [Save changes].




## 6 Restart the RIP PC.

### Setting up an Ethernet connection


#### 1 On the RIP PC, open the Windows start menu and click [Settings].



#### 2 Select [Network & Internet].




### 3 Select [Change adapter options].




### 4 Right-click [Ethernet], and then select [Properties].

- If there are multiple [Ethernet] icons, select the properties for the port you wish to use.
- The names may vary depending on the PC.




### 5 On the Networking tab, select the [Internet Protocol Version 4 (TCP/IPv4)] item, then click [Properties].



## 6 Configure the network settings.

- Configure the network according to the network settings of the control PC.
- For more information regarding the network settings of the control PC and RIP PC, contact your network administrator.



## 7 Restart the RIP PC.

## 8 Confirm that the connection has been established.


- Connect the RIP PC and control PC via a LAN cable. ["Connecting to a Local Network"\(P. 41\)](#)

## 9 Open Explorer on the RIP PC and enter [\\machine serial number] in the address bar.

- The machine serial number can be checked on the touch panel (MENU > [SYSTEM] > [System information]).

## 10 Check the Explorer display.

- Check whether two folders, [HotFolder] and [SharedJob], are displayed. If they are displayed, configuration is complete.



## Preparations for using TxLink

### Installing RIP Software

The explanation here applies to the MIMAKI RIP software (TxLink).



- If using TxLink, refer to the TxLink operating manual.

#### 1 Install TxLink.

- The following icon appears on the PC desktop once the software has been installed.



### Obtaining Color Profiles

Print quality (e.g., tone, bleeding) will vary depending on the media and ink set. By selecting a color profile that matches the media and ink set, you can maintain consistent print quality.

- provides a function to download color profiles directly from the Internet and install them. For more information, refer to "Profile Installation" in the installation guide.  
<https://mimaki.com/download/software.html>  
 [ used ] > [ Manuals ]
- Our website provides color profiles for our RIP software (TxLink).  
<https://mimaki.com/download/inkjet.html>  
 [ Tiger600 Series ] > [ Profile ]

### Setting Up RIP Software

The explanation here applies to the MIMAKI RIP software (TxLink).

This section describes the procedure for registering the Tiger600 Series printer configuration.

#### 1 Launch TxLink.

- If no printer configuration has yet been registered, a guide to creating the printer configuration will be displayed when first launched. Click [Add], then proceed to step 3.

#### 2 The add printer configuration window appears.


- (1) Click the printer configuration button at the top of the window.




- (2) Click [Add].

### 3 Create a print client.

- (1) Click the [+] button.
- (2) Select the desired printer driver, then click [OK].
  - Open the Mimaki Tiger600-1800 folder.



- (3) Select a port.




- If the port is not listed in the combo box, follow these steps to create it.

(1) Click [Add Port].


(2) Select the type of port for the connection and click [OK].

- File Interface: Sends jobs to the RIP computer.
- MIMAKISTATUSPORT: Sends jobs to the machine (control PC) over the local network.




● **When File Interface is selected**


(1) Select a folder for job output and click [OK].






## ● When MIMAKISTATUSPORT is selected

- (1) Join the local network.  "Connecting to a Local Network"(P. 41)
- (2) In [Destination Folder], enter the path of the shared folder for job output.



- The output shared folder can be selected from the following:
  - SharedJob: To print from [Job List] on the touch panel  
(Ex.: [\\\*\*\*\*\*\SharedJob])
  - HotFolder: To print automatically (Ex.: [\\\*\*\*\*\*\HotFolder])
- (3) Click [Search for the printer].
- The printer list at the bottom of the UI is updated.



- (4) In the printer list, select the printer to connect, then click [OK].



- Please change "\*\*\*\*\*" to the serial number of the printer.
- From MENU on the touch panel, tap [SYSTEM] > [System information] to display the serial number on the browser screen at right.

## 4 Select the type of status monitor.

- Mimaki Textile: Monitors the printer on a regular schedule and displays the status in the print client window. See Step 5 of ["Creating RIP Data"\(P. 97\)](#).
- None: Printer status is not monitored.

**Edit Printer Port Settings**

Port  
Specify a Port for Data Output

File Interface: C:\Users\...\Desktop

Port Settings... Add Port... Remove Port...

Status Monitor Type: **Mimaki Textile**

Folder for Spool Files  
C:\Users\Public\Documents\EsRip\15\Files\Spool\Mimaki Tiger600-1800  
Browse...

Name:

Description:

Cost Factor: 1 per h

Print data type: Mimaki Tiger600

Assigned to Computer:


OK Cancel

## 5 Click [OK].

## 6 Set an appropriate name for the print client, then click [OK].

- The printer configuration is then created.

**7** Click [Print Settings] > [Printing Ink Assignment], set the ink for each slot, then click [OK].



## Preparations for using RasterLink

### Installing the Mimaki Driver



- This procedure is not required when using TxLink.
- Use MimakiDriver version 5.9.8 or later.

#### 1 Download the Mimaki driver from our website.

- <https://mimaki.com/download/inkjet.html>  
[Tiger600 Series] > [Driver/Utility]

#### 2 Install the MIMAKI driver.

### Installing RIP Software

The explanation here applies to the MIMAKI RIP software (RasterLink).



- Use RasterLink7 version 3.3.1 or later.

#### 1 Install RasterLink.

- The following icon appears on the PC desktop once the software has been installed.



- For more information, refer to the RasterLink installation guide. <https://mimaki.com/download/software.html>

### Obtaining Color Profiles

Print quality (e.g., tone, bleeding) will vary depending on the media and ink set. By selecting a color profile that matches the media and ink set, you can maintain consistent print quality.

- The RasterLink series provides a function to download color profiles directly from the Internet and install them. For more information, refer to "Profile Installation" in the RasterLink series installation guide. <https://mimaki.com/download/software.html>  
[RasterLink Series used] > [Manuals]
- Our website provides color profiles for our RIP software (RasterLink). <https://mimaki.com/download/inkjet.html>  
[Tiger600 Series] > [Profile]

### Setting Up RIP Software


The explanation here applies to the MIMAKI RIP software (RasterLink).

#### 1 Launch RasterLink.


- The [Printer Management] screen appears.
- To add a new model, launch RasterLink, then select [Environment] > [Printer Management].

## 2 Register Tiger600 Series.

(1) Click [Add].



(2) Set the information for Tiger600 Series.



- Model name: Select the model.
  - Color: Select the ink set that is filled.
  - Output Port: [Ethernet] is recommended. With output port set to [Ethernet]
  - Available Printers: Select the connected Tiger600 Series.
  - Printer: Enter any name.
- (3) Click [OK].
- A confirmation screen appears.
- (4) Click [Yes].
- Printer registration starts.




- For more information, refer to the RasterLink installation guide. <https://mimaki.com/download/software.html>

# 1.5 Ink Tank Replacement Method

## When Ink Near End is Displayed

Ink levels are low. We recommend replacing with new Ink tank as soon as possible. Note that ink may run out during printing.

You can check which Ink tank must be replaced in INK STATUS on touch panel.  ["INK STATUS"\(P. 124\)](#)



## When Ink End is Displayed

The ink has run out. Replace with new Ink tank.

Thoroughly read the following and make sure you understand its contents.

 ["Ink and Other Liquid Handling Precautions"\(P. 20\)](#)



- Pay close attention to ventilation and be sure to wear safety glasses, gloves, and a mask when handling ink, maintenance liquid, waste ink, or other solutions used with the machine. Leaking ink may adhere to the skin or get into the eyes or mouth.


## Replacing the ink tank

### Replacing the ink tank

#### ● Remove Ink tank


##### 1 Lift up the cap cover.

- The machine detects that the cap cover is detached, allowing the tank to be removed.




## 2 Remove the fitting from the Ink tank cap.

- Press down on the fitting latch, then pull out the fitting.




- Be sure to press down the latch fully to remove the fitting. If you try to force off the fitting without pressing down the latch fully, there is a risk of damaging the O-ring on the fitting, which may cause ink leakage.

## 3 Remove the other fitting in the same way.




## 4 Press the tip of the fitting lightly against the ink wiping sponge to prevent ink dripping from the tip of the fitting.








- Do not press the valve at the tip of the fitting in firmly. If the valve is pushed in, ink may leak out, and air may enter the ink paths, causing malfunctioning.




Valve not pushed in  
(valve sealed)



Valve pushed in  
(valve open)

## 5 Remove the Ink tank from the ink supply unit.



- When disposing of ink, maintenance liquid or other liquid used with the product, or containers or non-woven fabric contaminated with ink or other liquid, contact an industrial waste disposal operator or dispose of the product in accordance with the local laws and regulations.

## ● Prepare Ink tank


### 1 Shake the new Ink tank gently from left to right to ensure it is fully mixed.

- Tighten the Ink tank lid securely, then move from left to right to ensure that the ink moves inside, holding the lid with a paper towel.



## ● SetInk tank


- 1** Remove the Ink tank cap, then attach the new Ink tank.




- When disposing of ink, maintenance liquid or other liquid used with the product, or containers or non-woven fabric contaminated with ink or other liquid, contact an industrial waste disposal operator or dispose of the product in accordance with the local laws and regulations.

- 2** Mount the new Ink tank in the supply unit, then attach the fitting.


- Insert the fitting with the fitting latch pressed down.



- Be sure to press down the latch fully when inserting the fitting. If you try to forcibly insert the fitting without pressing down the latch fully, there is a risk of damaging the O-ring on the fitting, which may cause ink leakage.
- Take care not to push in the valve at the tip of the fitting when connecting the fitting. If the valve is pushed in, ink may leak out, and air may enter the ink paths, causing malfunctioning.




Valve not pushed in  
(valve sealed)




Valve pushed in  
(valve open)

### 3 Attach the other fitting in the same way.




### 4 Check to confirm that the fittings are securely connected.

(1) There are no gaps in the fittings.




OK (correctly connected)




Unsatisfactory (not connected)

(2) The fittings do not detach when pulled gently.




## 5 Lower the cap cover.

- When closing the cap cover, make sure the sensor shade is inserted inside the slot in the cap sensor.



## 6 Check the touch panel display, then tap OK.



## 7 Tap the [CLEAR ALARM] button on the touch panel.


# 1.6 Purified Water Replenishment Procedure

## When Purified Water Near End is Displayed

Once the remaining purified water level is low, "0689 Purified Water NEAR END" will appear in SYSTEM ALARM on the touch panel.


We recommend replenishing purified water as soon as possible.


You can check the remaining purified water level in INK STATUS on the touch panel.





## When Purified Water End is Displayed


Once purified water runs out, "0688 Purified Water END" will appear in SYSTEM ALARM on the touch panel. Perform the following steps to replenish purified water.



- 
- Water feeding to the moisture tray and dripping to the wiper stop when purified water runs out.
  - While printing and cleaning are possible, using the machine in this state may lead to ejection failures (such as nozzle clogging or deflection). Replenish purified water immediately when purified water runs out.


## Replenish Purified Water

- 
- Always wear safety glasses and gloves when doing this work.
- 

- 
- Watch your head when performing work under the station.


## ● Procedure

- 1** Lower the purified water tank from the purified water tank slot.



- 2** Replenish purified water in the purified water tank.

- 3** Place the purified water tank on the purified water tank slot, then insert the purified water tube from the top panel into the purified water tank.



- Insert the tube into the purified water tank immediately after the purified water tank is placed on the purified water tank slot.

- 4** Check to confirm that the tube end sinks in the purified water tank.



- If the tube is not in the purified water tank when water feeding starts, air may enter the tube, causing it to rise up and preventing normal water feeding.
- If air enters the tube and the tube rises up, contact your local dealer or our service office.

- 5** Tap the [CLEAR ALARM] button on the touch panel.





# Chapter 2 Printing



## This chapter

This chapter describes printing procedures and settings.

Print Process .....	66	Head Cleaning.....	93
Load the media.....	68	Cleaning .....	93
Media .....	68	Powerful Cleaning .....	93
Preparation.....	70	Correcting the Drop Position .....	95
Loading the Media on the Feeding Air Shaft .....	76	Preparing a Job (RIP Data) .....	96
Loading the Paper Core on the Take-up Air Shaft.....	79	When using TxLink .....	96
Loading Media on to the Printer Main Unit.....	81	When using RasterLink.....	106
Initializing the Tension Bar .....	86	Printing .....	113
Setting the Head Gap .....	89	Starting Printing .....	113
Checking the Head Gap Value.....	89	Stopping Printing.....	115
Test Printing .....	90	Skipping the wait until heater temperature is reached .....	116
Checking Print Head Discharge .....	90	Printing Using Nozzle Recovery .....	117
Ejection Failures.....	92		

## 2.1 Print Process

### 1. Setting Up RIP Software

- ☞ "Installing RIP Software"(P. 48) (required first time only)
- ☞ "Setting up an Ethernet connection"(P. 43) (required first time only)

### 2. Set up the control PC and RIP PC on the same local network.

- ☞ "Connecting to a Local Network"(P. 41) (required first time only)
  - If the system is not connected to a local network, you can use a removable disk to store jobs (RIP data) in MPC.☞ "With Output Port Set to [File Interface]"(P. 102)

### 3. Load the media.


- ☞ "Load the media"(P. 68)

### 4. Setting the Head Gap

- ☞ "Setting the Head Gap"(P. 89)

### 5. Check the state of the print head nozzles.

- ☞ "Test Printing"(P. 90)



### 6. Clean the head to clear malfunctioning nozzles.

- ☞ "Head Cleaning"(P. 93)

### 7. Adjust the drop position for bi-directional printing.

- ☞ "Correcting the Drop Position"(P. 95)

### 8. Import the job (RIP data) into MPC.

☞ "Preparing a Job (RIP Data)"(P. 96)

## 9. Print the job (RIP data).

☞ "Printing"(P. 113)

## 2.2 Load the media



- Adjust the head height before loading media. Moving the carriage after the media has been loaded may result in the print head coming into contact with the media and being damaged.

### Media

#### ● Media handling precautions



- Use Mimaki-approved media to ensure consistent high-quality printing.

#### ⚠ WARNING



- Assign at least two people to load roll media. Otherwise there is a risk of back injury due to the weight of the media.

#### NOTICE



- When using a lifter to load the media, check the lifter specifications before commencing.



- An air compressor is required for loading the media (recommended pressure 0.5 MPa).




- Do not use media soon after it has been removed from its packaging. The media may expand or contract depending on the temperature and humidity of the location in which it was stored. Allow the media to stand for at least 24 hours in the same indoor environment as the machine before loading it.
- Adjust the indoor conditions to suit the media used.
- Do not use media with wrinkles or misaligned roll edges. Doing so may impair print quality.



- Store unopened media in a cool, dry location away from direct sunlight.
- After opening, be careful not to touch the surface (especially the printing surface).
- If the media is left out for extended periods, such as overnight, wrap plastic sheeting or similar at least once around the exterior of the media. This will help prevent any effects from ambient condition variations.




- Do not stand on or place heavy objects on the winding unit beams (parts shown in orange in the diagram below).





● Lifter specifications


Item	Requirements
Load capacity	Min. 350 kg
Fork length	800 mm or more
Fork width	500 to 700 mm (fork external dimension)
Minimum height	Max. 150 mm
Maximum height	500 mm or more
Recommended lifter	HC-10B-70 (load capacity 1,000 kg)



## Preparation

-  "When no media is loaded (at the time of new installation)"(P. 70)
-  "When media is loaded (at the time of media replacement)"(P. 72)



### When no media is loaded (at the time of new installation)

- 1 Tap [SET 2] > [Media] > [Set media] on the touch panel.
- 2 Switch the maintenance switch to maintenance mode.  "Maintenance Switch"(P. 39)
- 3 Lower the two tension bars on the feeding side and take-up side.





- If the tension bar is at the retract position, [Rotate roll to removable position]] in Steps 4 to 5 will not function.


- 4 Tap [Feeding] > [Rotate roll to removable position] on the touch panel to rotate the air shaft until the air shaft inlet is facing upward.



- 5** Tap [Winding] > [Rotate roll to removable position] on the touch panel to rotate the air shaft until the air shaft inlet is facing upward.




- 6** Retract the two tension bars on the feeding side and winding side.



- Hold the tension bars level (two people should be used for this task). The tension bars may not operate correctly if they are not kept level.
- When raising or retracting the tension bars, move them slowly and support with your hands.

## When media is loaded (at the time of media replacement)

- 1 Slacken the feeding media (release the automatic tension bar control) using either procedure A or procedure B described below.



- **Procedure A**


- (1) From MENU on the touch panel, tap [SET 2] > [Media] > [Set media].
- (2) Tap [Feeding] > [Rotate roll to removable position].



- Check to confirm that the tension bar is not at the retract position.

- **Procedure B**


- (1) Check to confirm that the feeding rotation direction switch is set to CCW.
- (2) Press the feeding JOG switch to feed the media.
  - Release the switch once the removable position faces upward.



- Press the feeding JOG switch until the feeding tension bar is fully lowered, then check to confirm that the removable position is facing upward.
- If the feeding tension bar is not fully lowered, it will drop when the media is cut.



- 2** Slacken the take-up media (release the automatic tension bar control) using either procedure A or procedure B described below.



• **Procedure A**



- (1) From MENU on the touch panel, tap [SET 2] > [Media] > [Set media].
- (2) Tap [Winding] > [Rotate roll to removable position].



- Check to confirm that the take-up tension bar is not at the retract position.


• **Procedure B**

- (1) Turn the take-up rotation direction switch to CW.
- (2) Press the take-up JOG switch to feed the media.
  - Release the switch once the removable position faces upward.




- Press the take-up JOG switch until the take-up tension bar is fully lowered, then check to confirm that the attach/detach position is facing upward.
- If the take-up tension bar is not fully lowered, it will drop when the media is cut.

### 3 Cut the media.



- Fix the cut media to the return bar with adhesive tape.



### 4 Retract the tension bars.




- Hold the tension bars level (two people should be used for this task). The tension bars may not operate correctly if they are not kept level.
- When raising or retracting the tension bars, move them slowly and support with your hands.

### 5 Remove the take-up media.

- If the removable position does not face upward, press the take-up JOG switch to turn the removable position upward.




## 6 Pull out the take-up air shaft.




## 7 Remove the feeding media (paper core).

- If the removable position does not face upward, press the feeding JOG switch to turn the removable position upward.



## 8 Pull out the feeding air shaft.




## Loading the Media on the Feeding Air Shaft



- Skip to Step 3 when media is loaded (at the time of media replacement).

### 1 Tilt the shaft clamp.




- Before tilting the shaft clamp, be sure to check that the air shaft inlet is facing upward.




- The shaft will not rotate unless the power is turned on.
- Be careful to avoid catching your hands or fingers when using force to move the shaft clamp.
- The shaft clamp movement is made stiff to ensure safety. A plastic hammer or similar can be used if it is difficult to move.

### 2 Remove the air shaft.

### 3 Insert the feeding air shaft into the media roll.




- 4** Adjust the air shaft position, then use the air nozzle provided to feed air into the air shaft and secure the media.



- Load so that the readings are identical on the scales at both ends of the air shaft.
- Be sure to mount with the air shaft inlet on the motor side.

Air shaft inlet



Media loading position





- Reference: For a media width of 1,620 mm, the readings should be approximately 14.5 mm on both left and right.




- If the air is insufficient, the media may slip, causing feeding problems.
- Applying pressure until the paper core deforms may cause feeding problems. Recommended pressure: 0.5 MPa




- When using a lifter, supply the air with the media placed on the lifter.
- Place the media on the lifter forks and adjust the angle so that the air shaft can be inserted into the grooves.




## 5 Move the media to the feeding shaft clamping position.



- When using lifter  
When using a lifter, remove the front take-up air shaft.



## 6 Lower the media and clamp the feeding shaft.



- Be sure to clamp the shaft securely. There is a risk of the air shaft falling off if the media is rotated without clamping it, posing hazards.




- Be careful to avoid catching your hands or fingers when using force to move the shaft clamp.
- The shaft clamp movement is made stiff to ensure safety. A plastic hammer or similar can be used if it is difficult to move.

## Loading the Paper Core on the Take-up Air Shaft



- Skip to Step 3 when media is loaded (at the time of media replacement).

### 1 Tilt the shaft clamp.




- Before tilting the shaft clamp, be sure to check that the air shaft inlet is facing upward.



- The shaft will not rotate unless the power is turned on.
- Be careful to avoid catching your hands or fingers when using force to move the shaft clamp.
- The shaft clamp movement is made stiff to ensure safety. A plastic hammer or similar can be used if it is difficult to move.


### 2 Remove the air shaft.

### 3 Insert the take-up air shaft into a new paper core.






- 4** Adjust the air shaft position, then use the air nozzle provided to feed air into the air shaft and secure the paper core.



- Load so that the readings are identical on the scales at both ends of the air shaft.
- Be sure to mount with the air shaft inlet on the motor side.




Paper core loading position



- If the air is insufficient, the paper core may slip, causing feeding problems.
  - Applying pressure until the paper core deforms may cause feeding problems.
- Recommended pressure: 0.5 MPa

- 5** Clamp the take-up shaft.



- Be sure to clamp the shaft securely. There is a risk of the air shaft falling off if rotated without clamping it, posing hazards.



- Be careful to avoid catching your hands or fingers when using force to move the shaft clamp.
- The shaft clamp movement is made stiff to ensure safety. A plastic hammer or similar can be used if it is difficult to move.




## Loading Media on to the Printer Main Unit

- "When no media is loaded (at the time of new installation)"(P. 81)
- "When media is loaded (at the time of media replacement)"(P. 84)


### When no media is loaded (at the time of new installation)

#### 1 Feed the media through to the printer main unit.




##### (1) Feed the media through with the tension bar raised.

- Use the feeding JOG switch to feed the media.
- Turn the feeding rotation direction switch to CCW.




##### (2) Feed the media as far as the printing surface.

- Pull the media out from the platen side at the front, and use the rear feed switch and feeding JOG switch to feed the media.




- The media can be loaded more easily if the task is performed by two persons, one at the front and one at the rear.

## 2 Feed the media underneath the printer.




- Loading the media on to the take-up paper core requires feeding out approximately 6 m of the media.

(1) Tap [Drying unit] > [Drying unit Taking out] on the touch panel, then pull out the drying unit.




(2) Use the feeding JOG switch to feed out the media.






- Pulling out the drying unit then securing the fed media to the drying unit (with adhesive tape or magnets, etc.) makes it easier to feed the end.
- When feeding under the brush rollers on the take-up and feeding unit, folding over the end of the media to increase its strength makes this easier.




### 3 Press the feeding JOG switch to feed the media.

- Feed the media to the position where it can be wound on to the paper core.




- Load media straight using the following procedure.
  - (1) Tension the media on the platen to ensure it is straight.
  - (2) Align the media to be attached to the take-up paper core with the fed media, and confirm that the media is straight.



## 4 Secure the media to the take-up paper core.

- Secure the media with adhesive tape.




- Pull the roll media evenly on both the left and right sides, aligning both edges, check to confirm that it is free of sagging and creasing, then affix the tape.
- If the end of the media is damaged, pull it out to where there are no wrinkles or folds, then cut it and tape it down.

## When media is loaded (at the time of media replacement)

### 1 Connect the feeding media to the end of the media cut in [Step 3](#) in [Preparation] > [When media is loaded (at the time of media replacement)].

**"When media is loaded (at the time of media replacement)"**(P. 72)




- Tape them securely. Otherwise, the feeding media may be removed from the cut media when loading media.




- Taping them with the loaded media (OLD) facing down makes it easier to feed the end.

## 2 Press the feeding JOG switch to feed the media.

- Turn the feeding rotation direction switch to CCW.
- Feed the media until the media loaded in the machine (approximately 6 m) goes through the take-up air shaft.
- Cut the taped portion.




- Load media straight using the following procedure.
  - (1) Tension the media on the platen to ensure it is straight.
  - (2) Align the media to be attached to the take-up paper core with the fed media, and confirm that the media is straight.



## 3 Secure the media to the take-up paper core.

- Secure the media with adhesive tape.




- Pull the roll media evenly on both the left and right sides, aligning both edges, check to confirm that it is free of sagging and creasing, then affix the tape.
- If the end of the media is damaged, pull it out to where there are no wrinkles or folds, then cut it and tape it down.

## Initializing the Tension Bar


### 1 Press the feeding JOG switch to feed the media.

- Feed the media to the position where the take-up tension bar can be lowered.



### 2 Lower the tension bar.


- Use the feeding JOG switch to feed out the media until the tension bar lowers to its lowest position.



- When lowering the tension bar (when passing through the rail), support it with your hand and lower it slowly. The tension bar may not operate correctly if it is subjected to excessive force. The tension bar may drop if the stopper is released without supporting it, posing hazards.

### 3 Lower the feeding tension bar.

- Use the feeding JOG switch to feed out the media until the tension bar lowers to its lowest position.








- When lowering the tension bar (when passing through the rail), support it with your hand and lower it slowly. The tension bar may not operate correctly if it is subjected to excessive force.  
The tension bar may drop if the stopper is released without supporting it, posing hazards.

#### 4 Press the feeding JOG switch to feed the media.

#### 5 Press the take-up JOG switch and feed switch to wind the media at least five times around the paper core.



- Check to confirm that the media edges are not misaligned.
- Wind so that the take-up tension bar cannot rise fully.



- If there is insufficient media, press the feeding JOG switch and feed switch to feed out the media.

#### 6 Tap [Set media] > [Winding] on the touch panel, then press the Tension Bar switch.

- The take-up tension bar is initialized.



If an error occurs

- Use the feeding JOG switch to lower the tension bar to its lowest position, and try again.  
Be careful to ensure that the media does not sag down here.

#### 7 Tap [Set media] > [Feeding] on the touch panel, then press the Tension Bar switch.

- The feeding tension bar is initialized.




If an error occurs

- Use the feeding JOG switch to lower the tension bar to its lowest position, and try again.  
When repeating the procedure, be careful so that the media does not sag down.




- Pressing the feed switch after initializing the tension bar also feeds the feeding and take-up units in unison with the X drive roller.
- Pressing the Tension Bar switch at the rear of the printer initializes both the feeding tension bar and the take-up tension bar.




## 8 Tap [Forward feed] on the touch panel.

- The tension bar operates.




## 9 Switch the maintenance switch to print mode. "Maintenance Switch"(P. 39)

## 10 Position the media holders.



## 11 Turn on the platen vacuum.



- Be sure to check the ink levels and waste ink level before starting printing. Printing will stop midway if there is insufficient ink.




- Be careful to avoid objects being dragged into the take-up unit during printing (during take-up). Otherwise, there is a risk of clothing etc. being dragged in. Where this is unavoidable, for example when checking print quality, either pause printing or check inside while holding the emergency box.



## 2.3 Setting the Head Gap

Set the height from the media to the print head nozzle surface.



- Be sure to correct the dot position after altering the print head height.  ["Correcting the Drop Position"\(P. 95\)](#)
- Adjust the print head height to suit the media. With inkjet printers, if the gap between the print and media increases, the ink droplets may vaporize before they reach the media. Vaporized ink may adhere to the print head nozzle surface and media, affecting print quality and causing failure of the print head.

- 1** From MENU on the touch panel, tap [SETTING 2].
- 2** Tap [Media] > [Head gap].
- 3** Enter the head gap value.
  - Setting value: 2.0 to 4.0 mm
- 4** Tap [SET].

### Checking the Head Gap Value

- 1** From MENU on the touch panel, tap [SETTING 2].
- 2** Tap [Media].
  - The head gap value is displayed.

## 2.4 Test Printing

Print a test pattern to confirm that the ink prints correctly. Perform head cleaning if you observe any ejection failures (e.g., nozzle clogging or deflection). ["Head Cleaning"\(P. 93\)](#)

### Check beforehand

- Is media loaded? ["Load the media"\(P. 68\)](#)
- Is the maintenance switch set to print mode? ["Maintenance Switch"\(P. 39\)](#)
- Did you set the head gap? ["Setting the Head Gap"\(P. 89\)](#)


## Checking Print Head Discharge

### 1 From the MPC menu, tap [PRINT] > [TEST PATTERN] > [User] > [TestPattern] > [TestDraw].

- A dialog box appears.
- Set the print origin as necessary. ["Setting Print Conditions"\(P. 114\)](#)
- The layout can be changed automatically when using repeated printing. ["Printing Layout and Direction"\(P. 92\)](#)




- Tap [QUICK MENU] > [Test print] for a shortcut to the dialog.




### 2 Tap [Print].

- Test printing starts.

### 3 Check the print results.





- Nozzle layout for TestDraw



Printing Layout and Direction

You can change the printing layout and direction.


- 1 From MPC, tap [SETTING 1].
- 2 Tap [Internal pattern] > [Auto print origin shift].
  - A dialog box appears.

Internal pattern		Set the print position for printed patterns used in test printing or for correcting the drop position.
	Origin shift	<div><ul style="list-style-type: none"><li>• Origin shift: Prints in the direction specified when set to ON.</li><li>• Origin shift direction: Set the print direction.</li></ul><div><div> : Scan (horizontal) dir</div></div></div>
	Origin shift margin	<ul style="list-style-type: none"><li>• Y margin: Sets the scan (horizontal) direction margin.</li></ul>

- 3 Tap [SET].

Ejection Failures

Typical examples of ejection failures (e.g., nozzle clogging, deflection) are as shown below. In order to prevent printing in such a state, check whether the ink has been properly ejected regularly before printing.



## 2.5 Head Cleaning

### Cleaning

The following cleaning methods are available. Choose the method based on test results.

Item	Details
Soft	If the print shows a bent line (nozzle deflection)
Normal	If the print shows a missing line (nozzle clogging)
Hard	If soft cleaning and normal cleaning fail to resolve ejection failures (e.g., nozzle clogging or deflection).



- Cleaning is not possible when [Ink End] is displayed. Replace with new ink. ["Ink Tank Replacement Method"\(P. 56\)](#)

#### 1 From the MPC menu, tap [MAINTENANCE].

- The Maintenance menu is displayed.

#### 2 Tap [Cleaning] > [Cleaning].

- The Cleaning menu is displayed.



- The Cleaning menu can also be accessed by tapping [Cleaning] in the quick menu.

#### 3 Select the type of cleaning and the head to be cleaned.

#### 4 Tap [EXEC].

#### 5 Run another test print and check the print results.

- Repeat the cleaning and test printing process until the print results appear normal.



- Do the following if head cleaning fails to resolve ejection failures such as nozzle clogging or deflection:  
["Wiper Cleaning"\(P. 157\)](#)  
["Powerful Cleaning"\(P. 93\)](#)  
["Cleaning the Print Head Nozzle Surface"\(P. 172\)](#)

### Powerful Cleaning

Powerful cleaning is a function for helping to resolve ejection failures. It involves applying high pressure inside the sub-tank to eliminate all ink from inside the sub-tank, purging any air from inside the head, and then replacing the old ink inside the sub-tank with new ink.



- Powerful cleaning consumes approximately 130 ml of ink.

#### 1 From the MPC menu, tap [MAINTENANCE].

- The Maintenance menu is displayed.

**2** Tap [Cleaning] > [Powerful cleaning].

**3** Select the head to be cleaned.



- Only one head unit can be selected for powerful cleaning. If you wish to perform powerful cleaning on multiple heads, repeat the procedure, changing the head selected.
- 

**4** Tap [EXEC].

## 2.6 Correcting the Drop Position

Changing the media and print head height will alter the drop positions during bi-directional printing. Correct the drop position to suit the type of media used. Image defects (e.g., overlaid lines or blurred images) will result if the drop position is not properly corrected.

## Check beforehand

- Is media loaded? 🖱️ "Load the media"(P. 68)
- Is the maintenance switch set to print mode? 🖱️ "Maintenance Switch"(P. 39)
- Did you set the head gap? 🖱️ "Setting the Head Gap"(P. 89)



- Load media at least 500 mm wide. You cannot print the entire pattern if media less than 500 mm wide is used.

**1** From MENU on the touch panel, tap [SETTING 2].

**2** Tap [Bi-directional adjustment] > [\*\*\*\* \*\*pattern].

- Select the resolution to adjust.




- The indicated resolutions are those in the scan direction.

**3** Tap [EXEC].

#### 4 Check the print results.

- A correction value input screen appears.
- Enter the position where the two upper and lower lines coincide.



- For System Pack version 1.03.0 and later, grid patterns are added to the top and bottom of the correction pattern, but they are not used for adjustment.  
Grid pattern printing is indented for consistent discharge and more precise adjustment.

**5** Tap [Bi-directional adjustment] > [Adjust Bi-directional print].

**6** Enter the correction value.

- Correction value: -40 to 40

**7** Tap [EXEC].



- If the lines do not coincide when the correction value is within the range -40 to 40, the head gap may be inappropriate. Adjust the gap. 🖐️ **"Setting the Head Gap"**(P. 89)

## 2.7 Preparing a Job (RIP Data)

The explanation here applies to MIMAKI RIP software (TxLink and RasterLink). The method for importing jobs (RIP data) to the machine (control PC) differs depending on the output port setting (☞ ["Setting Up RIP Software"](#)(P. 48)) in the TxLink and RasterLink printer settings.




- Prepare suitable image data for printing.
- Load a job to the control PC for printing using the following procedure. Other methods (such as using the control PC to access a server and printing a job from the server) are not recommended, as they may cause unexpected problems.

### When using TxLink

#### With Output Port Set to [MIMAKISTATUSPORT]

Import jobs (RIP data) to the machine (control PC) using a local network. ☞ ["Connecting to a Local Network"](#)(P. 41)



The shared folder for the machine (control PC) includes the following two types: These should be used as necessary, as the operation differs depending on the data saving destination.

Item	Overview
SharedJob	<ul style="list-style-type: none"> <li>• Saving data in [SharedJob] adds the jobs to the MPC job list. ☞ <a href="#">"When saved to [SharedJob]"</a>(P. 100) <ul style="list-style-type: none"> <li>– Jobs can be printed by selecting from the job list.</li> </ul> </li> </ul>
HotFolder	<ul style="list-style-type: none"> <li>• Saving data in [HotFolder] starts printing immediately. ☞ <a href="#">"When saved to [HotFolder]"</a>(P. 100) <ul style="list-style-type: none"> <li>– Printing is not always started immediately, even if you save to [HotFolder].</li> </ul> </li> </ul>



## Creating RIP Data

### 1 Launch TxLink.


### 2 Set the port type to [MIMAKISTATUSPORT].

- (1) Click the printer configuration button at the top of the window.



- (2) Click [SET].

- (3) Click [Print settings] > [Output Device], then click the edit button.



- (4) Select [MIMAKISTATUSPORT] for the port type, then click [OK].

The output shared folder can be selected from the following:

- SharedJob: To print from [JOB LIST] on the touch panel (Example: [\\\*\*\*\*\*\SharedJob])
- HotFolder: To print automatically (Example: [\\\*\*\*\*\*\HotFolder])



- Please change "\*\*\*\*\*" to the serial number of the printer.
- From MENU on the touch panel, tap [SYSTEM] > [System information] to display the serial number on the browser screen at right.

### 3 Select the image data to print.

- (1) Select [File] > [Open].

- (2) Select the desired image data, then click [Open].

## 4 Check the settings and alter as necessary.

- Configure the following print settings as required:
  - Properties on right of window

The screenshot shows a 'Properties' dialog box. On the left, a tree view lists several categories: Customer Info, Job Info, Media Size, Job Margin, Job Processing Policy, Job Ink Control, Job Fotoba, Job Production, Job Gradation Curves, and Media Background Simulation. 'Customer Info' is currently selected. The main area on the right is titled 'Preset' and contains a dropdown menu, a green '+' button, and five text input fields labeled 'Name', 'Responsible', 'Order Number', 'Order Name', and 'Project'. At the bottom of the dialog are 'Apply' and 'Discard' buttons.

- [Print environment] > [Settings] at top of window


The screenshot shows a 'Print Settings' dialog box for the Mimaki Tiger600-1800\_4C (Sublimation) - 600x600. The left pane has a tree view with categories: General, Quality, Output Device, Extras, Printing Ink Assignment, Ink Control, Media Size, Ink Cost, and Device Options. 'Device Options' is selected. The right pane contains several settings: Media Name (Default), Compression (None), Passes (1), Wave Shape (WF1), Ink Layers (1), Direction (Unidirectional), and Speed (Standard). There is a checked checkbox for 'BMP Preview'. At the bottom, there is a checkbox labeled 'Archive print environment before changing' and 'OK' and 'Cancel' buttons.

## 5 Prepare a job (RIP data) from image data.


- Clicking the [Print] button at the top of the window displays the print dialog.



- Set the name, then click [OK].



- Clicking the [Start print client] button at the top of the window displays the print client dialog. Click [Controller] > [Offline] at the top of the window to unselect the offline check box. The job output then starts automatically.



- When the output destination folder is [SharedJob]: The RIP job is added to the touch panel job list. "When saved to [SharedJob]"(P. 100)
- When the output destination folder is [HotFolder]: "Job receiving" is displayed in the lower-left corner of the touch panel screen, and printing starts. "When saved to [HotFolder]"(P. 100)



- When saving on the RIP PC, only the following ASCII characters can be used. Printing will not be possible if other characters are included.

File name and folder name supported characters list

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0																
1																
2	Space	!		#	\$	%	&	'	(	)		+	,	-	.	
3	0	1	2	3	4	5	6	7	8	9		;		=		
4	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
5	P	Q	R	S	T	U	V	W	X	Y	Z	[		]	^	_
6	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
7	p	q	r	s	t	u	v	w	x	y	z	{		}	~	


## When saved to [SharedJob]

Saving data in [SharedJob] adds the jobs to the MPC job list.

### ● Job checking procedure

Jobs that have been successfully loaded are saved in [SharedJob].

- From MENU on the touch panel, tap [PRINT] > [JOB LIST] > [SharedJob].



- If a job is not displayed, tap the refresh button.

## When saved to [HotFolder]


Saving data in [HotFolder] starts printing immediately.

- If another job is currently being printed
  - The job is added to the queue. Printing starts automatically when the other job print is complete.

### ● Job checking procedure

Jobs that have been successfully loaded are saved to [HotFolder].


- From MENU on the touch panel, tap [PRINT] > [JOB LIST] > [HotFolder].



## Copying jobs to a shared folder at any time

Jobs can be created in advance on the RIP PC, and then copied to the shared folder at any time for importing to MPC.

- 1 Create a job on the RIP PC in advance.
- 2 Copy the job created on the RIP PC to the shared folder (SharedJob or HotFolder) to be used.
  - Enter [\\\*\*\*\*\*] in the Explorer address bar to open the shared folder of the machine.



- Please change "\*\*\*\*\*" to the serial number of the printer.
- From MENU on the touch panel, tap [SYSTEM] > [System information] to display the serial number on the browser screen at right.

## With Output Port Set to [File Interface]

Import jobs (RIP data) to the machine (control PC) using an external hard drive (e.g., USB flash memory).

### Creating RIP Data

#### 1 Launch TxLink.


#### 2 Set the port type to [File Interface].

- (1) Click the printer configuration button at the top of the window.



- (2) Click [SET].

- (3) Click [Print settings] > [Output Device], then click the edit button.



- (4) Select [File Interface] for the port type, then click [OK]

#### 3 Select the image data to print.

- (1) Select [File] > [Open].  
 (2) Select the desired image data, then click [Open].

## 4 Check the settings and alter as necessary.

- Configure the following print settings as required:
  - Properties on right of window

The screenshot shows a 'Properties' dialog box. On the left, a tree view lists several categories: Customer Info, Job Info, Media Size, Job Margin, Job Processing Policy, Job Ink Control, Job Fotoba, Job Production, Job Gradation Curves, and Media Background Simulation. The 'Customer Info' category is selected. The main area on the right is titled 'Preset' and contains a dropdown menu, a green '+' button, and five text input fields labeled 'Name', 'Responsible', 'Order Number', 'Order Name', and 'Project'. At the bottom of the dialog are 'Apply' and 'Discard' buttons.

- [Print environment] > [Settings] at top of window


The screenshot shows a 'Print Settings' dialog box for a Mimaki Tiger600-1800\_4C (Sublimation) printer. The left pane has a tree view with categories: General, Quality, Output Device, Extras, Printing Ink Assignment, Ink Control, Media Size, Ink Cost, and Device Options. 'Device Options' is selected. The right pane contains the following settings: Media Name (Default), Compression (None), Passes (1), Wave Shape (WF1), Ink Layers (1), Direction (Unidirectional), and Speed (Standard). There is a checked checkbox for 'BMP Preview'. At the bottom are 'OK' and 'Cancel' buttons.

## 5 Prepare a job (RIP data) from image data.


- Clicking the [Print] button at the top of the window displays the print dialog.



- Set the name, then click [OK].



- Clicking the [Start print client] button at the top of the window displays the print client dialog. Click [Controller] > [Offline] at the top of the window to unselect the offline check box. The job output then starts automatically.





## Saving to an External Hard Drive (e.g. USB Flash Drive)

### 1 Save the job (RIP data) stored on the RIP computer to an external hard drive.

-  "Creating RIP Data"(P. 102)

### 2 Connect the external hard drive into the machine (control PC).

### 3 From MENU on the touch panel, tap [JOB IMPORT].



- A dialog box appears.

(1) Select the removable disk on which you will save the job.


(2) Specify where to save the job.

- To add a folder, tap [ADD NEW FOLDER]. When the dialog box appears, enter a folder name to add the folder.



(3) Select the job.


(4) Tap [→] to import the job.



## When using RasterLink

### With Output Port Set to [Ethernet]

Import jobs (RIP data) to the machine (control PC) using a local network. Connecting to a Local Network



The shared folder for the machine (control PC) includes the following two types: These should be used as necessary, as the operation differs depending on the data saving destination.

Item	Overview
SharedJob	<ul style="list-style-type: none"> <li>Saving data in [SharedJob] adds the jobs to the MPC job list.  "When saved to [SharedJob]"(P. 108) <ul style="list-style-type: none"> <li>Jobs can be printed by selecting from the job list.</li> </ul> </li> </ul>
HotFolder	<ul style="list-style-type: none"> <li>Saving data in [HotFolder] starts printing immediately.  "When saved to [HotFolder]"(P. 109) <ul style="list-style-type: none"> <li>Printing is not always started immediately, even if you save to [HotFolder].</li> </ul> </li> </ul>

### Creating RIP Data


#### 1 Launch RasterLink.

- Click the icon on the desktop of the RIP PC.



#### 2 Select the shared folder from [Select output folder].

- SharedJob: To print from [JOB LIST] on the touch panel (Example: [\\\*\*\*\*\*\SharedJob]).
- HotFolder: To print automatically (Example: [\\\*\*\*\*\*\HotFolder]).






- Please change "\*\*\*\*\*" to the serial number of the printer.
- From MENU on the touch panel, tap [SYSTEM] > [System information] to display the serial number on the browser screen at right.


### 3 Select the image data to print.

- (1) Select [File] > [Open].
  - (2) Select the desired image data, then click [Open].
- If multiple printers are registered, select Tiger600 Series from "Printer Name".



### 4 Select the loaded image data.

- It will be displayed in the tab for Tiger600 Series selected in "Printer Name".



### 5 Check the settings and alter as necessary.

- Specify the following settings using the function icons on the right side of the screen.



(General Print): Specify settings such as enlargement/reduction and copying.



(Print Condition): Select a color profile that matches the media and ink set loaded in the machine.



- For more information, refer to the RasterLink reference guide. <https://mimaki.com/download/software.html>

## 6 Prepare a job (RIP data) from image data.



- If the output port is set to [Ethernet], the job name is automatically determined by RasterLink and saved in the specified shared folder.



- Click (Execute) from the function icons on the right side of the screen. Select "RIP and Print", then click [Start].
- When the output destination folder is [SharedJob]: The RIP job is added to the MPC job list. ["When saved to \[SharedJob\]"\(P. 108\)](#)
- When the output destination folder is [HotFolder]: "Job receiving" is displayed in the lower-left corner of the MPC screen, and printing starts. ["When saved to \[HotFolder\]"\(P. 109\)](#)



- If you select HotFolder, you can start printing while creating a job. You can start printing without waiting for a job to be completed, so you can reduce waiting time when printing long-distance jobs.
  - (1) Note 1
    - If you select HotFolder, use a 10GBASE-T network to connect the RIP PC and the control PC. If you connect with a network less than 10GBASE-T, scanning may stop during printing.
  - (2) Note 2
    - Longer distance jobs have larger file sizes. This can consume free space on the control PC, so refer to the following and delete jobs as needed during operation.
      - Control PC job storage folder capacity: approx. 890 GB (initial state)
      - Size estimates for jobs
        - 300 × 600 width 1,850 mm length 100,000mm (100 m): approx. 50 GB
        - 600 × 600 width 1,850 mm length 100,000 mm (100 m): approx. 100 GB
        - 600 × 1200 width 1,850 mm length 100,000 mm (100 m): approx. 200 GB


### When saved to [SharedJob]

Saving data in [SharedJob] adds the jobs to the MPC job list.

### ● Job checking procedure

Jobs that have been successfully loaded are saved in [SharedJob].

- From MENU on the touch panel, tap [PRINT] > [JOB LIST] > [SharedJob].



- If a job is not displayed, tap the refresh button.

## When saved to [HotFolder]


Saving data in [HotFolder] starts printing immediately.

- If another job is currently being printed
  - The job is added to the queue. Printing starts automatically when the other job print is complete. However, if automatic operation mode or work change mode is turned on, continuous print mode will be turned off and printing will not start after the other job print is complete.

## ● Job checking procedure

Jobs that have been successfully loaded are saved to [HotFolder].

- From MENU on the touch panel, tap [PRINT] > [JOB LIST] > [HotFolder].




- Up to 100 jobs can be saved to [HotFolder] by default. If the number of jobs exceeds 100, the oldest job in the print history will be deleted. The number of jobs that can be saved can be changed as follows:  
Setting 2 Menu[System setting] > [HotFolder setting]

## Copying jobs to a shared folder at any time

Jobs can be created in advance on the RIP PC, and then copied to the shared folder at any time for importing to MPC.

- 1 Create a job on the RIP PC in advance.**
- 2 Copy the job created on the RIP PC to the shared folder (SharedJob or HotFolder) to be used.**
  - Enter [\\\*\*\*\*\*] in the Explorer address bar to open the shared folder of the machine.





- Please change "\*\*\*\*\*" to the serial number of the printer.
- From MENU on the touch panel, tap [SYSTEM] > [System information] to display the serial number on the browser screen at right.

## With Output Port Set to [File]

Import jobs (RIP data) to the machine (control PC) using an external hard drive (e.g., USB flash memory).

## Creating RIP Data


### 1 Launch RasterLink.

- Click the icon on the desktop of the RIP PC.




### 2 Select the image data to print.

- (1) Select [File] > [Open].
  - (2) Select the desired image data, then click [Open].
- If multiple printers are registered, select Tiger600 Series from "Printer Name".



### 3 Select the loaded image data.

- It will be displayed in the tab for Tiger600 Series selected in "Printer Name".



### 4 Check the settings and alter as necessary.

- Specify the following settings using the function icons on the right side of the screen.
  - (General Print): Specify settings such as enlargement/reduction and copying.
  - (Print Condition): Select a color profile that matches the media and ink set loaded in the machine.



- For more information, refer to the RasterLink reference guide. <https://mimaki.com/download/software.html>

### 5 Prepare a job (RIP data) from image data.

- Click (Execute) from the function icons on the right side of the screen. Select "RIP and Print", then click [Start].

### 6 Specify the destination and save the job (RIP data).

#### Saving to an External Hard Drive (e.g. USB Flash Drive)

#### 1 Save the job (RIP data) stored on the RIP computer to an external hard drive.


- "Creating RIP Data"(P. 110)

#### 2 Connect the external hard drive into the machine (control PC).


### 3 From MENU on the touch panel, tap [JOB IMPORT].



- A dialog box appears.
- (1) Select the removable disk on which you will save the job.
  - (2) Specify where to save the job.
    - To add a folder, tap [ADD NEW FOLDER]. When the dialog box appears, enter a folder name to add the folder.



- (3) Select the job.
- (4) Tap [→] to import the job.





## 2.8 Printing


### Check beforehand

- Is media loaded? 🖱️ ["Load the media"\(P. 68\)](#)
- Is the maintenance switch set to print mode? 🖱️ ["Maintenance Switch"\(P. 39\)](#)
- Did you set the head gap? 🖱️ ["Setting the Head Gap"\(P. 89\)](#)

## Starting Printing

### 1 Tap [JOB LIST] and select the job to print.

- A dialog box appears.




- Print speeds may differ for the same image data, depending on the width of the medium loaded, print origin position, and resolution.
- Any errors will prevent further printing.




- Turn on the heater when printing, to avoid any winding problems. 🖱️ ["Setting 1 Menu"\(P. 142\)](#)
- If you wish to delete a job, tap and hold (long tap) on the job and then tap [Delete]. Jobs deleted any other way will remain listed in [JOB LIST].

### 2 Set the print conditions.

- 🖱️ ["Setting Print Conditions"\(P. 114\)](#)




### 3 Tap [Print].



- Printing starts once the machine receives the job. Check printing progress in the print status area.  
 ["Mimaki Printer Controller"\(P. 122\)](#)



- Print speeds may differ for the same image data, depending on the width of the medium loaded, print origin position, and resolution.
- Any errors will prevent further printing.

## Setting Print Conditions




No.	Name	Overview
1	Job Information	Check the job information as needed.
	Job ID	The ID set for each job. This is used on PICT.
2	Detailed Job Information	Check the job details as needed.
3	Machine setting	Check the machine settings information as needed.
4	Print origin Y	Enter the print origin in the scan (horizontal) direction.  <a href="#">"Print Origin"(P. 115)</a>
	Print origin X	Enter the print origin in the feed (vertical) direction.  <a href="#">"Print Origin"(P. 115)</a>
	Repeat	Prints the set number of copies of the same job.
	Print Length	Sets the print length.
	Pass	Sets the passes. The passes selected using the RIP software are indicated as "RIP selected passes". Problems such as drying issues, image defects and nozzle clogging may arise if the number of passes selected is smaller than the RIP selected passes.
	Over print	Set the number of layers in overprinting.
	Print direction	Set to print unidirectionally or bidirectionally.
	Scan speed	Set the carriage scanning speed.

No.	Name	Overview
	MAPS	Set whether to use Auto or Presets 1 to 3 (🔗 "Setting 1 Menu"(P. 142)). Selecting manual enables individual settings for each job.
	After feed	Sets the feed position and distance after printing.

Print Origin

The print start position can be altered.



Pausing Printing

1 While printing is in progress, tap [Pause].

- Printing pauses.



- Some functions are not available while printing is paused.

2 Tap [Resume].

- Printing resumes.



Stopping Printing

1 Tap [Stop] to cancel printing.



- After cancellation, the carriage returns to the station.
- Any subsequent jobs are displayed in the print status area. To resume printing, tap [Resume].

## **Skipping the wait until heater temperature is reached**

- 1** Tap [Skip] while waiting for the heater temperature to reach the specified level for printing.
  - Printing starts immediately, without waiting to reach the heater temperature.



- This may affect the print finish.

## Printing Using Nozzle Recovery

Nozzle recovery is a function that is useful when nozzle clogging cannot be resolved for specific nozzles. When nozzle recovery is enabled, if a nozzle is determined to be clogged in the nozzle check, normal nozzles are used supplementarily during printing.

### Enabling Nozzle Recovery Function

#### ● Enabling nozzle recovery


##### 1 From the MPC menu, tap [MAINTENANCE].

- The Maintenance menu is displayed.

##### 2 Tap [Nozzle Recovery] > [Nozzle Recovery].

- A dialog box appears.

##### 3 Tap [Mode] to enable it.




##### 4 Tap [SET].




- Using this function does not change the time required for printing.
- If the print conditions are set to the minimum number of passes in the RIP software, the nozzle recovery function will be disabled.
- Even when nozzle recovery has been registered and enabled, recovery will not be applied to print patterns such as test printing and dot position correction.

#### ● Checking nozzle recovery settings

##### 1 Check the Nozzle recovery setting ("On" or "Off") in "Machine setting" on the print conditions screen.




- 2 Check the nozzle recovery setting ("Off", "Disabled", or "Enabled") for the job being printed on the JOB STATUS check screen after starting printing.






- ✓ A confirmation message is displayed before the start of printing to continue with nozzle recovery when certain conditions apply. There are three different patterns for the confirmation messages, as follows:

- (1) For print conditions in which nozzle recovery does not apply  
 → Displayed when printing will be performed in high-performance mode.  
 Change the following settings to enable nozzle recovery:
- Increase the number of passes
  - Reduce the MAPS speed
  - Change the scan speed from "High" to




"Normal"

- (2) When nozzles exist that cannot be recovered using nozzle recovery (Case 1)  
 → Printing is possible by reducing the print speed to enable nozzle recovery. Select [Apply settings and continue print] on the message window.



- (3) When nozzles exist that cannot be recovered using nozzle recovery (Case 2)  
 → Displayed in the case of print conditions for which nozzle recovery cannot be applied even by reducing the print speed.  
 Change the following settings to enable nozzle recovery:
- Increase the number of passes
  - Reduce the MAPS speed
  - Change the scan speed from "High" to "Normal"







# Chapter 3 Settings (MPC)



## This chapter


This chapter describes various functions of the MPC (Mimaki Printer Controller).

Mimaki Printer Controller .....	122	Setting 1 Menu .....	142
Screen structure .....	122	Setting 2 Menu .....	144
Print menu .....	126	Brake function .....	145
Maintenance Menu .....	127	History Menu .....	148
Registering abnormal nozzle with the nozzle		System menu .....	149
check tool .....	129	Power Supply .....	150
Nozzle recovery registration.....	138		















## 3.1 Mimaki Printer Controller

MPC software is used to operate and control the Tiger600 Series. The Mimaki Printer Controller is installed on the control PC. The touch panel is used for MPC operations.

### Screen structure




No.	Item	Overview
1	PRINTER STATUS (printer information area)	Machine status is indicated by icons. <a href="#">"PRINTER STATUS"(P. 123)</a> <ul style="list-style-type: none"> <li><a href="#">DETAIL</a>: Displays the status of each component of the configuration.</li> </ul>
2	INK STATUS (ink information area)	Icons indicate remaining ink levels, ink errors, and other Ink tank status information. <a href="#">"INK STATUS"(P. 124)</a> <ul style="list-style-type: none"> <li><a href="#">DETAIL</a>: Displays the Ink tank slot number and ink color.</li> </ul>
3	SYSTEM ALARM (system information area)	Of various possible errors, this area shows the most important errors. <a href="#">"SYSTEM ALARM"(P. 124)</a> <ul style="list-style-type: none"> <li><a href="#">DETAIL</a>: Displays all current errors.</li> </ul>
4	MENU (menu area)	Shows various menus. The "*" symbol displayed in each menu indicates the default values. <ul style="list-style-type: none"> <li> (PRINT): Set print conditions/settings for the media used.  <a href="#">"Print menu"(P. 126)</a></li> <li> (MAINTENANCE): Menu used for machine maintenance  <a href="#">"Maintenance Menu"(P. 127)</a></li> <li> (SETTING 1): Used to set various printing-related operations  <a href="#">"Setting 1 Menu"(P. 142)</a></li> <li> (SETTING 2): Used to set various operations for the machine  <a href="#">"Setting 2 Menu"(P. 144)</a></li> <li> (HISTORY): Shows maintenance records and other information.  <a href="#">"History Menu"(P. 148)</a></li> </ul>







No.	Item	Overview
		<ul style="list-style-type: none"> <li> (SYSTEM): Shows various information about the machine.  "System menu"(P. 149)</li> </ul>
5	QUICK MENU (quick menu area)	<p>Shows frequently used menus.</p> <ul style="list-style-type: none"> <li> (Feed): Feeds the media.</li> <li> (Vacuum): Applies suction to hold media in place.</li> <li> (Tension bar): Initializes the tension bar.</li> <li> (Test print): Prints a test pattern to confirm that the ink prints correctly.  "Test Printing"(P. 90)</li> <li> (Cleaning): Clean the heads in case of ejection failures (e.g., nozzle clogging, deflection).  "Head Cleaning"(P. 93)</li> <li>This is displayed only when [Setting 1] &gt; [Drying heater] is enabled.  "Setting 1 Menu"(P. 142)</li> <li> (Heater error): An error has occurred in the drying heater. The drying heater will not operate even when the button is pressed.</li> <li> (Heater stopped): The heater has stopped and is not turned on. Pressing the button starts heating the heater until the preset temperature is reached.</li> <li> (Heater on): The drying heater is warming up to the preset temperature. Pressing the button stops the heater.</li> <li> (Heater standby): The drying heater is at standby after warming up to the preset temperature. Pressing the button stops the heater.</li> </ul>
6	(Content area)	Shows setting screens for the selected menu.

## PRINTER STATUS

Icons indicate the machine status. Tap [Detail] to display the status of each component of the configuration.



### ● Icon display


Icon	Overview
	Local mode. Used for test printing, maintenance, and settings
	Printing in progress.
	Printing is paused.
	Maintenance is in progress. No other operations can be performed while maintenance is underway.
	An obstruction has been detected. Printing pauses.
	Set the maintenance switch to maintenance mode.

## ● Detail display

Display details	Overview
Machine status	Displays the device operation status.
Auto cleaning next time:	Displays the timing for auto cleaning and auto flushing.
Heater	Displays the drying heater temperature. This is displayed only when [Setting 1] > [Drying heater] is enabled.  "Setting 1 Menu"(P. 142)

## INK STATUS

Icons indicate remaining ink levels, ink errors, and other Ink tank status information. Tap [Detail] to display the slot number and ink color.



## ● Icon display


Icon	Overview
	Remaining ink levels are indicated graphically and as percentages.
	A blue warning icon appears in the lower right if ink runs low. Very little ink remains. Have new ink ready.
	A yellow warning icon appears in the lower right if ink runs out or ink errors occur. Printing is not possible.
	The remaining purified water level is indicated as a percentage.
	A blue warning icon appears in the lower right if purified water runs low. Very little purified water remains. Replenish purified water.
	A red warning icon appears in the lower right if purified water runs out or purified water tank errors occur. Take the appropriate action in based on the error.

## SYSTEM ALARM






Of various possible errors, this area shows the most important errors. Tap [Detail] to display all current errors.



## ● Alarm display




No.	Overview	
1	Level	(Level 0): Printing is possible. Printing will continue even if these errors occur during printing. <ul style="list-style-type: none"> <li>Examples: Ink near-end, tank cap not fitted</li> </ul>

No.	Overview	
		 (Level 1): Printing and cleaning is not possible. Any printing underway will pause if any of these errors occur. Take the appropriate action in accordance with the content of the message. <ul style="list-style-type: none"> <li>Examples: Ink end</li> </ul>
		 (Level 2): Printing and cleaning is not possible. Any printing underway is aborted if any of these errors occur. Take the appropriate action in accordance with the content of the message. <ul style="list-style-type: none"> <li>Examples: Ink overflow</li> </ul>
		 (Level 3): No machine operations are possible. Take the appropriate action in accordance with the content of the message. If you see this message repeatedly, contact your local dealer or our service office.
2	Code	Refer to the error code list.  <a href="#">"Problems Indicated by Messages"(P. 187)</a>
3	Unit	Not disclosed; used for service
4	Contents	Refer to the error code list.  <a href="#">"Problems Indicated by Messages"(P. 187)</a>

## Clearing Alarms

### 1 Tap [DETAIL].

- Displays all current errors.




### 2 Resolve the cause of the error.

-  ["Problems Indicated by Messages"\(P. 187\)](#)

### 3 Tap [CLEAR ALARM].


- This clears the error.



- If this does not clear the error/alarm, your response may be incorrect or inadequate. Check the alarm details once again and take corrective action. If this alarm recurs, contact your local dealer or our service office.

## 3.2 Print menu


Set print conditions/settings for the media used.



No.	Item	Overview
1	Job status area	<p>Displays a job thumbnail and print status.</p> <ul style="list-style-type: none"> <li>: Pause the job currently being printed.</li> <li>: Resume printing.</li> <li>: Cancel printing.</li> </ul>
2	Browser area	<p>List print jobs. Tap a job to display a dialog box for setting print conditions/settings.  <a href="#">"Setting Print Conditions"(P. 114)</a></p> <ul style="list-style-type: none"> <li>: Show the jobs stored on the control PC.</li> <li>: Show queued jobs. Numbers in the upper right of the icon indicate the number of queued jobs.</li> <li>: Show printed jobs. Tap on a job to print it.</li> <li>: Show jobs used for test patterns.</li> <li>: Show the home folder.</li> <li>: Show the folder one level above.</li> <li>: Update the folder display.</li> <li>: Import the job into MPC.  <a href="#">"With Output Port Set to [File Interface]"(P. 102)</a></li> <li>: Create a new folder. A dialog box appears.</li> <li>: Delete the job or folder that was selected with a long tap. Jobs deleted any other way will remain listed in [JOB LIST].</li> <li>: Lets you sort or otherwise change how the job list is displayed.</li> </ul>

## 3.3 Maintenance Menu

This menu is used for machine maintenance.



Item	Overview
Cleaning	Print a test pattern to clean the heads in case of ejection failures (e.g., nozzle clogging, deflection). <a href="#">"Head Cleaning"(P. 93)</a>
Cleaning	Three types of cleaning are available. Choose the method based on test results.
Powerful Cleaning	Use when problems are not resolved by regular cleaning.
Auto Maint.	Set the conditions to start print head cleaning automatically.
Cleaning (Standby)	<ul style="list-style-type: none"> <li>Cleaning (Standby): When this is turned on, head cleaning will be performed once the [Interval (Time)] has elapsed. Set to OFF if you prefer not to clean automatically.</li> <li>Interval (time): Cleans heads after the specified value is exceeded.</li> <li>Mode: Set type of cleaning.</li> </ul>
Cleaning (Print)	<ul style="list-style-type: none"> <li>Cleaning (Print): When this is turned on, head cleaning will be performed during printing once the [Interval (Time)] has elapsed. Set to OFF if you prefer not to clean automatically.</li> <li>Interval (Time): Cleans heads during printing after the specified value is exceeded.</li> <li>Mode: Set type of cleaning.</li> </ul>
Flushing (Standby)	<ul style="list-style-type: none"> <li>Flushing (Standby): Set to ON for flushing. Flushing reduces nozzle clogging via regular print head ink discharge.</li> <li>Interval (time): Flushes heads after the specified value is exceeded.</li> </ul>
Nozzle Recovery	Allows other nozzles to be used for printing if nozzle washing or other maintenance fails to resolve ejection failure (such as nozzle clogging or deflection).
Nozzle Recovery	<ul style="list-style-type: none"> <li>Mode: Set to ON to perform nozzle recovery.</li> </ul>
Nozzle recovery confirmation message	If nozzle recovery cannot be performed, setting [Nozzle Recovery Confirmation Message] to OFF will start printing without displaying the print continuation confirmation dialog box.
Nozzle recovery operation guide	Shows the nozzle recovery operation guide.
Scanner	Starts the scanner application.
Nozzle check tool	Starts the nozzle check tool. Allows nozzles with abnormalities to be registered.
Nozzle recovery registration	This displays the currently registered nozzle check results. Also allows abnormal nozzles to be registered and cleared manually. <a href="#">"Nozzle recovery registration"(P. 138)</a>
Daily maintenance	Lists items for which daily maintenance should be performed.

Item		Overview
	Daily station maintenance	Moves the carriage for cleaning around the station. ☞ "Wiper Cleaning"(P. 157) ☞ "Wiper Unit Cleaning"(P. 161)
	Head maintenance	Moves the carriage to the maintenance space for cleaning in the print head area.☞ "Carriage Underside Cleaning"(P. 159)
	Station & Head maintenance	Performs daily station maintenance and head maintenance simultaneously. Moves the carriage to the maintenance space for cleaning the area around the station and the print head. Maintenance can be performed efficiently since the carriage only needs to be moved once. ☞ "Wiper Cleaning"(P. 157) ☞ "Carriage Underside Cleaning"(P. 159) ☞ "Wiper Unit Cleaning"(P. 161)
Weekly maintenance		Lists items for which weekly maintenance should be performed.
	Weekly station maintenance	Moves the carriage for cleaning around the station.☞ "Wiper Unit Cleaning"(P. 161)
Other maintenance		Lists maintenance items to inspect in the event of errors.
	Ink tank calibration	Runs the ink tank calibration wizard.
	Purified water tank calibration	Runs the purified water tank calibration wizard.
	Drying unit Taking out	Runs the drying unit taking out wizard.
	Moisture tray maintenance	Runs the moisture tray maintenance wizard. ☞ "Moisture Tray Cleaning"(P. 167)
Replace parts		Displays replacement instructions for components requiring periodic replacement.
	Replace ink filter	The machine requires ink filter replacement about once a year, but sooner replacement may be required depending on operating conditions. ☞ "Ink filter replacement"(P. 177) <ul style="list-style-type: none"> <li>• If a supply error (061B INK SUPPLY) occurs: The filter may be blocked. Use this function to replace the ink filter.</li> <li>• If a supply warning (067D INK SUPPLY WARN) occurs: The filter may be beginning to clog. Replacing the ink filter as soon as possible is recommended.</li> </ul>
	Replace Wiper	The machine maintains a count of the number of wiping cycles. Once the specified value is reached, "0605 REPLACE WIPER" will appear in SYSTEM ALARM on the touch panel. Replace dirty or warped wipers with new ones. ☞ "Wiper Replacement"(P. 174)
Machine status check		Checks the machine status.
	Ink supply unit test	Checks the ink supply capacity. Displays the amount of ink that can be supplied over a specific period in increments of 0.1 ml.



## Registering abnormal nozzle with the nozzle check tool

Abnormal nozzle locations can be registered by using the nozzle check tool with printed image data from a nozzle recovery pattern.


### Printing nozzle recovery patterns

Print a nozzle recovery pattern as follows. Patterns are printed at about A4 size.




- Use various types of transfer paper for the media.

- 1 From the MPC menu, tap [PRINT] > [TEST PATTERN].
- 2 Tap [User] > [NozzleCheck], then tap the nozzle recovery pattern.




- 3 Tap [Print] to print the pattern on the media.



## Scanning nozzle recovery patterns


Cut out and scan the printed nozzle recovery pattern.

- 1 Cut the printed nozzle recovery pattern along the cut lines.




- 2 From the MPC menu, tap [MAINTENANCE] > [Nozzle recovery] > [Scanner].

- The scanner application starts up.




### 3 Tap [Scan settings].




### 4 On the scan settings screen, select [ScanGear]. Configure the settings as follows, then select [OK].

- [Data Format]: png
- Select the [Enable large image scans] check box.




## 5 Place the printed nozzle recovery pattern face-down on the scanner and close the cover.

- On the scanner, align the top of the black triangle in the pattern with the arrow mark of the scanner that indicates the starting point.



## 6 Open the scanner application and select [ScanGear].

- A dialog box appears.



## 7 Select the [Extended Mode] tab, configure the settings as follows, then select [Scan].

- [Document Type]: Paper/Photo
- [Output Resolution]: 2400
- [Edge Enhancement]: OFF





## Analyzing and applying nozzle recovery patterns

The scanned nozzle recovery pattern is analyzed by the nozzle check tool and analysis results are applied to the printer.

### 1 From the MPC menu, tap [MAINTENANCE] > [Nozzle recovery] > [Nozzle check tool].

- The nozzle check tool starts up.



## 2 Configure nozzle check tool settings.

- In [Model parameter], select the model, type of ink, and ink set.
- In [Analysis contents], confirm that the model, type of ink, and ink set are correctly selected.

**Target printer**

Model parameter  
Tiger600\_MLSb510\_4C\_BMYK\_NCT

**Analysis contents**

Model: Tiger600 4Color

Ink set: MLSb510 BMYK

**Adjustment items**

☒ Nozzle check


## 3 In [Analyze image file], tap [Open] and select the scanned image data.

- Image data is displayed in [Analysis image].

**Analysis image file**

Open


(No Data)



## 4 Tap [Start Analysis].

- The image data is analyzed and the analysis results are displayed in [Analysis result].

Start Analysis





## 5 Configure nozzles for nozzle recovery.

(1) Tap [Candidates only].

- Only nozzles that are candidates for nozzle recovery are shown in the data display area.




(2) For nozzles targeted for recovery, click the [Target] check box.

- Nozzles set for recovery are indicated by a red cell background color.

Blk.	No.	Res.	Target
#6 [Magenta] (5)	1	NG	<input checked="" type="checkbox"/>
	2	NG	<input type="checkbox"/>
	3	NG	<input type="checkbox"/>
	4	NG	<input type="checkbox"/>
	5	NG	<input type="checkbox"/>
#11 [Magenta] (1)	256	NG	<input type="checkbox"/>


## 6 Tap [Output RESULT].

- The settings are saved and applied to the printer.



**Important!**

- In case of errors, refer to the operation manual for the nozzle check tool.
- Access the operation manual as follows.
  - (1) Start the nozzle check tool.
  - (2) Tap [Help] > [Show manual].



## Nozzle recovery registration

### Nozzle recovery registration dialog


This displays the currently registered nozzle check results. It also allows abnormal nozzles to be registered and cleared manually.

**1 From MENU on the touch panel, tap [MAINTENANCE].**

- The Maintenance menu is displayed.

**2 Tap [Nozzle Recovery] > [Regist nozzle recovery].**

- A dialog box appears.











No.	Name	Overview
1	Nozzle image	Displays an image corresponding to the nozzle recovery table. <ul style="list-style-type: none"> <li>Clogged nozzle locations flash red.</li> </ul>
2	Nozzle recovery table filter	This allows the details in the nozzle image and nozzle recovery table to be narrowed down by specifying particular conditions. <ul style="list-style-type: none"> <li>[Color]: Filters the nozzles by color. "ALL" displays all ink colors and nozzles.</li> <li>[Result]: Filters the nozzles by nozzle check results. "Abnormal" displays only the clogged nozzles. "ALL" displays all results.</li> </ul>
3	Apply change	Updates the nozzle recovery registration with the changes made.
4	Clear	Clears the changes made to the nozzle recovery registration.
5	Nozzle recovery table	Displays the individual nozzle status for each color. <ul style="list-style-type: none"> <li>Abnormal nozzles are highlighted in orange.</li> <li>Head line: Head row (horizontal direction on nozzle status image)</li> <li>Nozzle line: Nozzle row (vertical direction on nozzle status image)</li> <li>Nozzle No.: Nozzle number for each ink color</li> <li>Status: Nozzle check results (normal/abnormal)</li> </ul>
6	Scroll buttons	Used to scroll the nozzle recovery table. <ul style="list-style-type: none"> <li>: Jump 1,000 nozzles in the direction of the arrow.</li> <li>: Jump 100 nozzles in the direction of the arrow.</li> </ul>

Print and register nozzle check pattern


The procedure for manual nozzle recovery registration is as follows:

- 1 From MENU on the touch panel, tap [Print].
- 2 Tap [Test pattern] > [User] > [Nozzle Check], then tap the job for the slot on which the color for nozzle recovery is mounted.

BROWSER

JOB LIST	JOB QUEUE	JOB HISTORY	TEST PATTERN
<div><div></div><div>user\Nozzle Check</div><div></div></div>			
	NozzleCheck for Scanner	Resolution : 600×600 Width : 210mm Height : 297mm	Last print : 2023/06/28 13:24:11
	NozzleCheckPattern Slot1	Resolution : 600×600 Width : 276mm Height : 260mm	Last print : 2023/06/28 13:20:03
	NozzleCheckPattern Slot2	Resolution : 600×600 Width : 276mm Height : 260mm	Last print : -
	NozzleCheckPattern Slot3	Resolution : 600×600 Width : 276mm Height : 260mm	Last print : -
	NozzleCheckPattern Slot4	Resolution : 600×600 Width : 276mm Height : 260mm	Last print : -

- 3 Tap [Print].
  - Print a nozzle check pattern.
  - Ink is ejected from all of the nozzles for the color selected.
- 4 Check the print results.
  - Check the nozzle numbers for the clogged nozzle locations.



- 5 From MENU on the touch panel, tap [Maintenance].
  - The Maintenance menu is displayed.
- 6 Tap [Nozzle Recovery] > [Regist nozzle recovery].
  - A dialog box appears. "Nozzle recovery registration dialog"(P. 138)

## 7 Update the nozzle recovery table with the print results.

Regist nozzle recovery

Color: ALL Apply change

Result: ALL Clear

Nozzle No.	Nozzle line	Head line	Status
1	1	1	Normal
1420	2	2	Normal
1421	3	3	Normal
2780	4	4	Normal
2781	5	5	Normal
4140	6	6	Normal
4141	7	7	Normal
5560	8	8	Normal

(1) Set the filters as follows:

- [Color]: Color for nozzle recovery registration
- [Result] ALL

Color: Black

Result: ALL

(2) Refer to the nozzle numbers for the clogged nozzle locations in the print results on the nozzle recovery table, then tap the [Status] row to set to [Abnormal].

- The text in the nozzles for which [Status] was changed turns yellow.

Black	1	4	17	Abnormal
Black	1	6	18	Abnormal
Black	1	3	19	Normal

## 8 Tap [Apply change].

- A dialog box appears.
- To edit the change details, tap [Cancel].

## 9 Tap [Apply].


- The changes are applied.

Following changes will be applied.  
If you want to apply changes, please select 'Apply' button.

Cancel Apply


Color	Head line	Nozzle line	Nozzle No.	Status
Black	1	4	17	Abnormal
Black	1	6	18	Abnormal
Black	1	4	21	Abnormal
Black	1	4	25	Abnormal

**Important!**


- The results for nozzles to which changes were applied in nozzle recovery registration will not be updated even if changes are subsequently applied using the nozzle check tool. (Manual registration using nozzle recovery registration takes precedence.)
- To update only the results of the nozzle check tool, clear the nozzle recovery registration information and then apply the changes using the nozzle check tool.  ["Nozzle recovery registration dialog"](#)(P. 138)

## 3.4 Setting 1 Menu

Set various print options.




Item	Overview
Print	Set print options.
Logical Seek	<p>Sets the range of carriage movement.</p> <ul style="list-style-type: none"> <li>Carriage movement range for <b>Logical Seek OFF</b> setting           <div> <div> <p>Unidirectional print</p> <p>Color bar      Print data      Carriage movement      Flushing Box</p> </div> <div> <p>Bi-directional printing</p> </div> </div> </li> <li>Carriage movement range for <b>Logical Seek ON</b> setting           <p>When the refresh level is 0, the carriage moves to the color bar.</p> <div> <div> <p>Unidirectional print</p> <p>Print data      Carriage movement</p> </div> <div> <p>Bi-directional printing</p> </div> </div> <p>For refresh levels 1 to 3, the carriage moves to the flushing box for the refresh operation.</p> <div> <div> <p>Unidirectional print</p> <p>Print data      Carriage movement</p> </div> <div> <p>Bi-directional printing</p> </div> </div> </li> </ul>
Refresh	<p>Reduces nozzle clogging by regularly discharging ink from the print heads.</p> <ul style="list-style-type: none"> <li>Level: More ink is discharged for higher level numbers.</li> </ul>
Pre feed	Turn on to allow pre feed length to be set.
Select head	Sets the head line used.
Select head operation manual	Allows the head selection operation manual to be viewed.
Dry feed	Sets the feed distance when drying.
Add feed	Sets the additional feed distance.
Color bar	<ul style="list-style-type: none"> <li>Position: Sets the position for printing a color bar.</li> </ul>

Item		Overview
		<ul style="list-style-type: none"> <li>– Off: No color bar is printed.</li> <li>– Right side: Prints on the right side of the print data.</li> <li>– Left side: Prints on the left side of the print data.</li> <li>– Both sides: Prints on both sides of the print data.</li> <li>• Discharge amount: Sets the amount of ink discharged on the color bar. Selecting a larger amount makes the color bar bolder. The width also varies according to the print conditions.</li> <li>• Overlay: Sets whether to print color bars overlaid. <ul style="list-style-type: none"> <li>– OFF: Prints color bars without overlaying.</li> <li>– ON: Prints color bars overlaid.</li> </ul> </li> </ul>
	Print feed speed	Sets the feed speed during printing in %.
MAPS		<p>MAPS: Mimaki Advanced Pass System</p> <ul style="list-style-type: none"> <li>• This function disperses the boundaries between passes to make feed streaks between passes less visible.</li> <li>• Altering MAPS may alter the color. This function may be less effective with certain types of images.</li> </ul>
	MAPS preset 1 setting	<p>Register a preset of your choice.</p> <ul style="list-style-type: none"> <li>• Speed: Reducing speeds will make streaks less visible. However, printing will be slower.</li> <li>• Smoothing: Increasing smoothing makes streaks less visible.</li> </ul>
	MAPS preset 2 setting	
	MAPS preset 3 setting	
	Default MAPS	Set your preferred preset from 1 to 3 as described above or set to Auto. This should normally be set to Auto.
Internal pattern		Set the print position for printed patterns used in test printing or for correcting the drop position.
	Origin shift	<ul style="list-style-type: none"> <li>• Origin shift: Prints in the direction specified when set to ON.</li> <li>• Origin shift direction: Set the print direction.</li> </ul> 
	Origin shift margin	<ul style="list-style-type: none"> <li>• Y margin: Sets the scan (horizontal) direction margin.</li> </ul>
Heater		<p>Sets the drying heater operation.</p> <ul style="list-style-type: none"> <li>• Drying heater: Toggles the drying heater on and off. (Default: On)</li> <li>• Temperature: Specifies the heater temperature (20 to 60 °C, default: 40 °C)</li> <li>• OFF Time: Toggles the setting to turn off the heater after the preset time has elapsed. (Default: On)</li> <li>• OFF Time: The time until the heater turns off. (0 to 90 mins, default: 60 mins)</li> </ul>
Feed Comp.		<p>Set the feed offset.</p> <ul style="list-style-type: none"> <li>• Feed offset: Enter the feed offset value.</li> <li>• Feed offset pattern: Prints a feed offset pattern.</li> </ul>

## 3.5 Setting 2 Menu

Set various operation-related settings.



Item		Overview
Media		Set information about media.
	Media origin	Enter the media origin position.
	Media thickness / Head gap	Manually enter the media thickness and head gap. ☞ "Setting the Head Gap"(P. 89)
	Brake Roller	Sets the brake roller. Setting a larger value increases the brake force. Set to an appropriate value to suit the media used. (Can be set in 1 % increments) <ul style="list-style-type: none"> <li>• Brake Roller: On/Off (Default: Off)</li> <li>• Rear Brake L: 0 to 100 % (Default: 0 %)</li> <li>• Rear Brake R: 0 to 100 % (Default: 0 %)</li> <li>• Front Brake: 0 to 100 % (Default: 0 %)</li> </ul>
	Set media	Displays the media setting items. ☞ "Load the media"(P. 68)
	Media near end	Sets the conditions for which media near end is detected. Media near end is detected using the thickness of the paper core as the datum. Measure the thickness of the paper core on the feeding shaft, and enter this value. <ul style="list-style-type: none"> <li>• Paper core thickness: 1 to 20 mm</li> </ul>
Bi-directional adjustment		When using bi-directional printing, correct the drop position. ☞ "Correcting the Drop Position"(P. 95)
	Bi-direction adjustment value	Check the printed pattern and enter correction values.
	***dpi Pattern	Select and print the pattern based on the print conditions. <ul style="list-style-type: none"> <li>• Options: WF1 600 dpi / WF2 300 dpi</li> </ul>
Feed Control		Sets feeding
	Feed Speed	Set the feed speed in % when executing the feed function in the QUICK MENU.
System setting		Configure the system.
	Languages	Change the touch panel display language.
	Length unit	Changes the length units on the touch panel.
	Temp. unit	Changes the temperature display units on the touch panel.
	Print speed units	Sets the print speed units displayed on the job status screen.
	Network setting	Set the network address. <ul style="list-style-type: none"> <li>• Check IP address: Shows the machine's current IP address.</li> <li>• DHCP: Set to ON to use the IP address assigned by the DHCP server.</li> </ul>




## Brake function

A roller is available with a brake function on the return roller. Controlling the friction torque on the return roller improves feeding accuracy and winding performance.

1. Brake roller: Brake can be set via the MPC.
2. Winding unit brush roller: Can be clamped or unclamped depending on whether a slit collar is fastened.




- Depending on the media type and print conditions, there is a risk of deteriorating feeding accuracy and winding performance. The conditions should be determined by checking operation with the media to be used.




## Setting procedure (MPC)

- 1 From MENU on the touch panel, tap [Setting 2] > [Media] > [Brake Roller].







- 2 Set the brake conditions.

- 3 Tap SET.




## Setting procedure (Winding unit brush roller)

	Lock screw	Brush roller	Typical use
1	Lock	Brush clamped	Basic settings
2	Unlock	Brush free to rotate	For thin media and high-density printing. * Clamping may increase the chance of wrinkling. Normally it is recommended to increase the basic weight.



V Wrinkle smoothing




\* Brush roller is non-driven

## [Feed conditions and printable ink volume for different media]

Media / Maker		Jet-X / Coldenhove	TexPrint Moda39 / Beaver Paper	Versa / Canapa	TRS95 (MTW-110-162-150) /Mimaki (Sappi)	
Recommended environment		20~25°C/35~60%	23°C/50%	23~25°C/45~55%	25°C/45%	
Feeding conditions	Basis weight	57gsm	39gsm	22gsm	95gsm	
	X speed	Def : 350 mm/s	350mm/s	350mm/s	350mm/s	
	X acceleration	Def : 0.2 G	0.2G	0.2G	0.2G	
	<a href="#">Brake Roller</a> Rear L/Rear R/Front	Each 0~100%	0% / 0% / 0%	5% / 5% / 0%	0% / 0% / 0%	
Printable ink volume	Draft 550ml/h @300x600 1P <a href="#">BiStd</a>	GAP <sup>※1</sup> 3mm in ( ) : 2mm GAP OK	<8.5 cc/ml ( <4.6 cc/ml )	<7.4 cc/ml ( <7.4 cc/ml )	<7.1 cc/ml ( <6.4 cc/ml )	<9.6 cc/ml ( <9.6 cc/ml )
	Drying ※2	Set temperature : 70℃	12.5 cc/ml	12.5 cc/ml	19.4 cc/ml	12.5 cc/ml
	Codking	GAP <sup>※1</sup> 2mm / 3mm	<4.6 cc/ml, ≥19.3 cc/ml	≥19.3 cc/ml, ≥19.3 cc/ml	0.0 cc/ml, <9.2 cc/ml	>18.4 cc/ml, >18.4 cc/ml
	Winding wrinkles	①Minimum winding diameter (≥100mm)	<8.5 cc/ml	<7.4 cc/ml	<7.1 cc/ml	<9.6 cc/ml
	Standard 310ml/h @600x600 1P <a href="#">BiStd</a>	GAP <sup>※1</sup> 3mm in ( ) : 2mm GAP OK	9.2~11.4 cc/ml ( 0.0 cc/ml )	<9.6 cc/ml ( <9.6 cc/ml )	<6.4 cc/ml ※3 ( <6.4 cc/ml )	<12.9 cc/ml ( <12.9 cc/ml )
	Drying ※2	Set temperature : 70℃	18.2 cc/ml	18.2 cc/ml	19.4 cc/ml	18.2 cc/ml
	Codking	GAP <sup>※1</sup> 2mm / 3mm	0.0 cc/ml, ≥19.2 cc/ml	12.8 cc/ml, ≥19.3 cc/ml	<6.4 cc/ml, <6.4 cc/ml	>25.7 cc/ml, >25.7 cc/ml
	Winding wrinkles	①Minimum winding diameter (≥100mm)	<11.4 cc/ml	<9.6 cc/ml	<11.4 cc/ml	<12.9 cc/ml

# 3.6 History Menu


Shows the machine's maintenance history and other information.



Item	Overview
Maintenance	Shows maintenance history.
Alarm	Shows the system alarm history.
Print	Shows the print history.
Controller	Shows the MPC operation history.

## 3.7 System menu

Shows various information about the machine.




Item		Overview
System information		Shows system information about the machine and control PC.
	HDD disk space	Shows the disk space available on the control PC.
	Machine information	Shows information about the machine.
	Version	Shows the machine firmware version and MPC version.
	License	Shows license information.
Tool		Executes the various tools.
	Manual Log collection tool	Collects the machine operating logs and settings information manually. <a href="#">"Collecting Logs"(P. 202)</a>
	Open PICT Up	Displays PICT Up.
	PICT Up update	Updates PICT Up.
Document		Shows the MPC user's guide and an error code list.
	Operation manual	Shows the MPC user's guide.
	Alarm list	Shows a list of error codes.
	Application note	Displays a document describing solutions to problems and other useful tips.
	Support Video Link	Displays the QR code used to view the support video.
Service maintenance mode		This mode is exclusively for use by Mimaki representatives.
Power		Controls power to the machine and the control PC. <a href="#">"Power Supply"(P. 150)</a>
	Reset machine	Used when the alarm does not clear even after clearing the alarm, or when operation is unstable.
	Reboot System	Used if recovery fails even after a machine reset. The control PC will restart. The system will take some time to start up.
	Shutdown system	Shuts down the system. Turn off the main power supply. <a href="#">"Turning Off the Power"(P. 150)</a>

## Power Supply

Do not turn off the main power supply for the machine or the power supply for the control PC. The control PC controls the machine. Turn off the power only when machine issues cannot be resolved, and always restart after turning the power off.


### Turning Off the Power

- 1** From [MENU] on the touch panel, tap [SYSTEM].
  - This displays the system menu.
- 2** Tap [POWER] > [Shutdown System].
  - The control PC shuts down.
- 3** Turn off the main power for the machine.
  - Turn the switch 90 degrees counterclockwise.
  - The main power supply is located on the left at the rear of the machine.



## Turning On the Power


- 1 Turn the machine main power switch 90 degrees clockwise.




- 2 Turn on the control PC.

- This launches the MPC. The machine is ready to use.

FANATIC PC (PC with black cover)



CONTEC PC (PC with silver cover)







# Chapter 4 Maintenance



## This chapter

To ensure years of precise performance, maintain the machine periodically based on frequency of use.

Read the maintenance precautions thoroughly before maintaining this product.

Maintenance Precautions .....	154	Consumable Item Replacement .....	174
Maintenance Timing .....	155	Wiper Replacement .....	174
Items Required for Maintenance .....	155	Carriage Filter Replacement .....	175
Performing Maintenance .....	157	Blower Filter Replacement .....	176
Wiper Cleaning .....	157	Ink filter replacement .....	177
Carriage Underside Cleaning .....	159		
Wiper Unit Cleaning .....	161		
Flushing Box Cleaning .....	161		
Waste Ink Tank Waste Ink Level Checking .....	162		
Platen Cleaning .....	163		
X Drive Roller Cleaning .....	163		
Ink Maintenance .....	164		
Drying Fan Filter Cleaning .....	165		
Jam Sensor Detecting Plate Cleaning .....	166		
Exterior Cleaning (e.g., cover, Y-bar, ) .....	167		
Moisture Tray Cleaning .....	167		
Performing supply test .....	169		
Drying Unit Cleaning .....	171		
Cleaning the Print Head Nozzle Surface..	172		

## 4.1 Maintenance Precautions



- This machine includes parts that must be replaced periodically. We therefore recommend taking out a maintenance contract. Carry out maintenance periodically and replace consumable items to prevent quality defects and accidents.

### WARNING



- Clean periodically. Debris and dust will accumulate on electrical components when the machine is used for extended periods. There is a risk of failure, electric shock, or fire due to current leakage.
- Do not clean by blowing—e.g., avoid using air blowers. Doing so may lead to failure, electric shock, or fire involving the machine if airborne debris or dust gets inside electrical components. Wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out. A vacuum cleaner may also be used for cleaning.



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.

### CAUTION



- For heavy soiling, wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out.



- Pay close attention to ventilation and be sure to wear safety glasses, gloves, and a mask when handling ink, maintenance liquid, waste ink, or other solutions used with the machine. Leaking ink may adhere to the skin or get into the eyes or mouth.



### NOTICE



- Never touch the print head nozzle surface. (Allow only personnel trained by Mimaki engineers to clean the head nozzle surface. No other persons must ever touch the nozzle surface.) Do not allow water or alcohol to come into contact with the print nozzle surface. This will increase the risk of machine failure or ejection failures (e.g., nozzle clogging or deflection).
- Do not use cotton swabs to clean around the head or carriage. Fibers from cotton swabs may adhere to the head nozzle surface and lead to ejection failures (e.g., nozzle clogging or deflection).
- Do not splash ink or maintenance liquid on the covers. Exposure to splashing ink or maintenance liquid may damage or deform the cover.
- Do not use benzine, thinner, or any chemical agent containing abrasives. Use of these chemicals may result in damage to or deformation of parts.
- Do not move the carriage by hand. To move the carriage, use the carriage out function on the menu.

## 4.2 Maintenance Timing

Timing	Item
At the end of the work day	Clean the wiper and wiper bracket. <a href="#">"Wiper Cleaning"(P. 157)</a>
	Clean the underside of the carriage. <a href="#">"Carriage Underside Cleaning"(P. 159)</a>
	Clean the wiper unit. <a href="#">"Wiper Unit Cleaning"(P. 161)</a>
	Clean the flushing filter. <a href="#">"Flushing Box Cleaning"(P. 161)</a>
	Check the waste ink levels in the waste ink tank. <a href="#">"Waste Ink Tank Waste Ink Level Checking"(P. 162)</a>
At the end of the week's work	Clean the platen. <a href="#">"Platen Cleaning"(P. 163)</a>
	Clean the X drive roller. <a href="#">"X Drive Roller Cleaning"(P. 163)</a>
	Shake the ink. <a href="#">"Ink Maintenance"(P. 164)</a>
At the end of two weeks' work	Clean the drying fan filter. <a href="#">"Drying Fan Filter Cleaning"(P. 165)</a>
	Clean the jam sensor detecting plate. <a href="#">"Jam Sensor Detecting Plate Cleaning"(P. 166)</a>
	Clean the cover (exterior). <a href="#">"Exterior Cleaning (e.g., cover, Y-bar, )"(P. 167)</a>
	Clean the moisture tray. <a href="#">"Moisture Tray Cleaning"(P. 167)</a>
Once a month	Perform a supply test. <a href="#">"Performing supply test"(P. 169).</a>
Cleaning as required	Clean the drying unit. Maintain the unit if there is any dust or ink contamination. <a href="#">"Drying Unit Cleaning"(P. 171)</a>
	Clean the print head nozzle surface. As a guide, after using approximately one mini-jumbo roll (approx. 3,000 m) or when the printing time exceeds 24 hours, perform a nozzle status check using a test print before carrying out maintenance. <a href="#">"Cleaning the Print Head Nozzle Surface"(P. 172)</a>
	Replace the wiper (SPA-0271). The machine maintains a count of the number of wiping cycles. Once the specified value is reached, the message [0605] appears in SYSTEM ALARM. Replace dirty or warped wipers with new ones. <a href="#">"Wiper Replacement"(P. 174)</a>
	Replace the carriage filter (SPC-0766). Check the mist filters, and replace all of them at the same time if especially dirty. <a href="#">"Carriage Filter Replacement"(P. 175)</a>
	Replace the blower filter (SPC-0921). Check the blower filter condition, and replace if especially dirty. • Replacement guide: Once every six months (*Varies depending on extent of contamination, usage environment, and volume printed.) <a href="#">"Blower Filter Replacement"(P. 176)</a>
	Replace the ink filters (SPA-0363). Replace the ink filter for the corresponding path if a message (067D or 061B) appears in SYSTEM ALARM or if the result of the supply test is less than 45 cc. <a href="#">"Ink filter replacement"(P. 177)</a>

### Items Required for Maintenance

To order replacement consumable items, contact your local dealer or our service office. For more information on consumable items, refer to our website. <https://mimaki.com/supply/inkjet.html>

Code	Item	Intended use
SPC-0527	Cleaning Stick for Head Surrounding	For maintenance
SPC-0774	300 fan filter	For drying fan filter replacement
SPC-0826	3-inch paper core 160	3-inch paper core
SPC-0755	Cotton gauze	For maintenance
SPC-0766	H fan filter	For carriage filter replacement
SPA-0271	Wiper kit 300TS	For wiper replacement
SPC-0876	Cap absorber	Ink wiping sponge
SPA-0327	20 L polyethylene container	For purified water tank and waste ink tank
SPA-0355	10 L ink tank cap	Cap for external supply tank
SPC-0921	Blower filter	For blower filter replacement
SPA-0363	Replacement ink filters (×4)	For external supply filter replacement



- Do not store consumables where children may enter.

## 4.3 Performing Maintenance

### Wiper Cleaning

The wiper wipes off ink adhering to the print head nozzle surface. Continuing to use the dirty wiper may cause the wiper to which dried ink and dust are attached to rub against the nozzle surface, leading to printing defects (e.g., nozzle clogging or deflection).




- Be careful to avoid leaving fragments from the cleaning stick behind when cleaning. These fragments will increase the risk of ejection failures (e.g., nozzle clogging or deflection).



The following maintenance items can be performed at the same time. Maintenance can be performed efficiently since the carriage only needs to be moved once. It can be carried out simultaneously from the MPC MENU under [Maintenance] > [Daily Maintenance] > [Station & Head Maintenance].


- ["Wiper Cleaning"\(P. 157\)](#)
- ["Carriage Underside Cleaning"\(P. 159\)](#)
- ["Wiper Unit Cleaning"\(P. 161\)](#)

- 1 From the MPC menu, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Tap [Daily maintenance] > [Maintenance wizard], then tap [Daily station maintenance].**
  - The carriage moves over the table.
- 3 Switch the maintenance switch to maintenance mode.** ["Maintenance Switch"\(P. 39\)](#)
- 4 Remove the wiper.**
  - Hold the lugs on both sides of the wiper bracket, then pull out the wiper.



- 5 Clean the wiper and bracket.**


- Wipe off any ink and dust adhering using a cleaning stick moistened with maintenance liquid. Wipe off the maintenance liquid. Make sure none remains.






- Replace dirty or warped wipers with new ones.  ["Wiper Replacement"\(P. 174\)](#)

## 6 Reattach the wiper at the original position.



## 7 Clean the wiper cleaner.

- Wipe off any ink and dust adhering using a cleaning stick moistened with maintenance liquid. Wipe off the maintenance liquid. Make sure none remains.




- Clean only the surface of the wiper cleaner. There is no need to clean the back side.




- Do not remove the wiper cleaner from the bracket.



- After cleaning, make sure the wiper cleaner is not facing upward.



- Once a week, use a paper towel or similar item to absorb the ink in the ink-receiving pan. There is a risk of ink overflowing.



- Do not remove the ink pad from the ink pad case. There is a risk of ink overflowing.

**8** Tap [Complete] once cleaning is complete.

**9** Switch the maintenance switch to print mode and tap [OK]. **"Maintenance Switch"**(P. 39)

## Carriage Underside Cleaning

The underside of the carriage becomes coated with ink wiped off by the wiper. Continuing to use the dirty carriage underside will rub dried ink and attached dust on to the media, resulting in contaminated prints.

The print head uses an extremely delicate mechanism. Take great care when handling it.



- Be careful to avoid leaving fragments from the cleaning stick behind when cleaning. These fragments will increase the risk of ejection failures (e.g., nozzle clogging or deflection).



The following maintenance items can be performed at the same time. Maintenance can be performed efficiently since the carriage only needs to be moved once.

It can be carried out simultaneously from the MPC MENU under [Maintenance] > [Daily Maintenance] > [Station & Head Maintenance].

- **"Wiper Cleaning"**(P. 157)
- **"Carriage Underside Cleaning"**(P. 159)
- **"Wiper Unit Cleaning"**(P. 161)

**1** From the MPC menu, tap [MAINTENANCE].

- The Maintenance menu is displayed.


**2** Tap [Daily maintenance] > [Maintenance wizard], then tap [Head maintenance].

- The carriage moves to the maintenance space.

**3** Switch the maintenance switch to maintenance mode. **"Maintenance Switch"**(P. 39)


## 4 Slide the maintenance cover on the left side of the Y-bar.

- Lift the lever and slide it to the left.




## 5 Clean around the print head.

- Wipe off any ink and dust adhering using a cleaning stick moistened with maintenance liquid. Wipe off the maintenance liquid. Make sure none remains.




- Never touch the print head nozzle surface.

## 6 Once cleaning is complete, slide the maintenance cover on the left side of the Y-bar to close it and tap [Complete].



- Make sure the maintenance cover is returned to the correct position.






- 7 Switch the maintenance switch to print mode.  ["Maintenance Switch"\(P. 39\)](#)
- 8 Tap [Complete] > [Finish].


## Wiper Unit Cleaning


Continued use when dirty may prevent ink from flowing into the waste ink tank or cause dried ink and attached dust to rub against the head nozzle surface, leading to ejection failures (e.g., nozzle clogging, deflection).




The following maintenance items can be performed at the same time. Maintenance can be performed efficiently since the carriage only needs to be moved once. It can be carried out simultaneously from the MPC MENU under [Maintenance] > [Daily Maintenance] > [Station & Head Maintenance].

-  ["Wiper Cleaning"\(P. 157\)](#)
-  ["Carriage Underside Cleaning"\(P. 159\)](#)
-  ["Wiper Unit Cleaning"\(P. 161\)](#)


- 1 From the MPC menu, tap [MAINTENANCE].
  - The Maintenance menu is displayed.
- 2 Tap [Weekly maintenance] > [Weekly station maintenance].
  - The carriage moves over the platen.
- 3 Switch the maintenance switch to maintenance mode.  ["Maintenance Switch"\(P. 39\)](#)
- 4 Clean the wiper tray.
  - Wipe off any ink and dust adhering using a cleaning stick moistened with maintenance liquid. Wipe off the maintenance liquid. Make sure none remains.
  - Scrape off any dried ink with a spatula or similar tool.




- 5 Tap [Complete] once cleaning is complete.
- 6 Switch the maintenance switch to print mode and tap [OK].  ["Maintenance Switch"\(P. 39\)](#)

## Flushing Box Cleaning

The flushing box filter becomes dirty with ink during flushing. Continuing to use the dirty carriage underside will rub dried ink and attached dust on to the media, resulting in contaminated prints.

- 1 Switch the maintenance switch to maintenance mode.  **"Maintenance Switch"(P. 39)**
- 2 Use a disposable cup or similar container to rinse the contaminated parts of the filter on the left and right with purified water.



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.

- 3 Switch the maintenance switch to print mode.  **"Maintenance Switch"(P. 39)**

## Waste Ink Tank Waste Ink Level Checking

Ink used during head cleaning and other processes is collected in the waste ink tank at the lower right of the machine.



- Continuing to use the product without disposing of the waste ink may result in waste ink overflowing from the waste ink tank. Visually check the ink level in the waste ink tank every day.




- Pay close attention to ventilation and be sure to wear safety glasses, gloves, and a mask when handling ink, maintenance liquid, waste ink, or other solutions used with the machine. Leaking ink may adhere to the skin or get into the eyes or mouth.

## Platen Cleaning



- Switch the maintenance switch to maintenance mode before carrying out maintenance.

Continuing to use the dirty platen will prevent proper feeding of the media. It will also cause dried ink and attached dust to rub against the head nozzle surface and lead to ejection failures (e.g., nozzle clogging or deflection).



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.




- For heavy soiling, wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out.

## X Drive Roller Cleaning



- Switch the maintenance switch to maintenance mode before carrying out maintenance.

Continuing to use the dirty platen will prevent proper feeding of the media. It will also cause dried ink and attached dust to rub against the head nozzle surface and lead to ejection failures (e.g., nozzle clogging or deflection).



- Clean using purified water.



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.



- For heavy soiling, wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out.

## Ink Maintenance

If ink constituents are sedimented, the ink density may become uneven. We recommend stirring the ink periodically to keep printing consistent.

### ● Shaking the Ink tank

#### 1 Shake the Ink tank gently from left to right to ensure it is fully mixed.

- Tighten the Ink tank lid securely, then move from left to right to ensure that the ink moves inside, holding the lid with a paper towel.



## Drying Fan Filter Cleaning



- Switch the maintenance switch to maintenance mode before carrying out maintenance.

Wash the drying fan filter in water if it is dirty.


### ● Recommended cleaning guide




- Check the filter for dirt every two weeks, and wash.
- Replace the filter every three months. Blowing Fan Filter Replacement

#### 1 Remove the fan filter cover.

- Push the fan filter cover claw outward, and pull the cover to the front.



#### 2 Remove the filter.




#### 3 Wash the filter.



- Dry the filter after washing.

## 4 Attach the dry filter together with the fan filter cover.

- Push in the fan filter cover until the tab clicks.



## Jam Sensor Detecting Plate Cleaning




- Switch the maintenance switch to maintenance mode before carrying out maintenance.

Continuing to use the dirty carriage underside will rub dried ink and attached dust on to the media, resulting in contaminated prints.

### 1 Clean the jam sensor detecting plate.


- Clean the jam sensor detecting plate underside at the left and right sides of the carriage.
- Wipe off any ink and dust adhering using a cleaning stick moistened with maintenance liquid. Wipe off the maintenance liquid. Make sure none remains.



## Exterior Cleaning (e.g., cover, Y-bar, )



- Switch the maintenance switch to maintenance mode before carrying out maintenance.




- For heavy soiling, wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out.



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.

## LM Guide

Wipe off dust from the left and right ends of the LM guide surface with a soft dry cloth.



- The LM guide is lubricated. Never wipe with solvents such as ethanol. Wipe off any excess or dripping lubricant with a soft dry cloth.

## Moisture Tray Cleaning

Replace the water in the moisture tray periodically. Continuing to use it when it is dirty will result in contaminated prints.




- be sure to wear the included safety glasses and gloves.
- Be careful to avoid contaminating the surrounding area with ink.



- Before commencing maintenance, check to confirm that the waste ink tank is sufficiently empty (with capacity for at least 5 L) and that there is at least 3 L of purified water for replenishment.

### 1 From the MPC menu, tap [MAINTENANCE].


- The Maintenance menu is displayed.


- 2 Tap [Other maintenance] > [Moisture tray maintenance].
- 3 Move the carriage to the maintenance position.
- 4 Switch the maintenance switch to maintenance mode.  ["Maintenance Switch"\(P. 39\)](#)
- 5 Open the discharge valve on the moisture tray as instructed on the wizard screen. Tap [OK], then drain the ink from the moisture tray.



- Draining takes approximately 10 minutes.

- 6 Clean the moisture tray. Once cleaning is complete, tap [OK].



- 7 Replenish the purified water in the moisture tray. Once complete, tap [OK].
- 8 Switch the maintenance switch to print mode.  ["Maintenance Switch"\(P. 39\)](#)
- 9 Return the carriage to its original position.
- 10 Exit [Moisture tray maintenance], then tap [OK].



## Performing supply test

If the ink filter becomes clogged, this may prevent normal maintenance and possibly lead to head damage. This procedure should therefore be performed regularly to check the extent of ink filter clogging (ink supply capacity).




- If the ink supply capacity is reduced, replacing the ink filter can prevent problems caused by filter clogging.
- Note that the test may fail if the ink level in the ink tank is near the end or exceeds 10 L. The result for paths where the test failed will be 0.0 cc.



- Do not replace the ink tank or subject the external supply unit to vibration while the test is in progress, as this may cause the test to fail.

- 1 From the MPC menu, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Tap [Machine condition check] > [Ink supply unit test].**
  - A dialog box appears.




- 3 Check to confirm that "Supply test" is selected for [Test type], then tap [EXEC].**
  - The test starts.



- The test takes approximately three to five minutes.

## 4 Check the results.



- The result for paths where the test failed will be 0.0 cc. Check to confirm that there are no ink tank level warnings (such as INK END or INK NEAR-END) and check to confirm that the ink tank is properly installed before starting the test.

Test result	Machine compatible with simple filter replacement kit
45 cc or greater	Normal No particular action is required.
Under 45 cc	Check to confirm that the ink tank is installed properly, then repeat the test. If the results do not improve, replace the ink filter. <a href="#">"Ink filter replacement"(P. 177)</a>

## Drying Unit Cleaning

Maintain the unit if there is any dust or ink contamination.




- The drying unit becomes extremely hot. Check to confirm that the unit has sufficiently cooled before commencing maintenance.



- Switch the maintenance switch to maintenance mode before carrying out maintenance.

- 1 From the MPC menu, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Tap [Other maintenance] > [Drying unit Taking out].**
  - Pull out the drying unit as instructed on the wizard screen.
- 3 Carry out maintenance once the drying unit has been pulled out.**



- For heavy soiling, wipe using a soft cloth soaked in diluted neutral detergent and thoroughly wrung out.



- Take care not to allow liquids to get inside the machine. Otherwise there is a risk of failure, electric shock, or fire.

## Cleaning the Print Head Nozzle Surface

Clean the print head nozzle surface if other cleaning or maintenance fails to resolve ejection failures (e.g., nozzle clogging, deflection).

As a guide, after using approximately one mini-jumbo roll (approx. 3,000 m) or when the printing time exceeds 24 hours, perform a nozzle status check using a test print before carrying out maintenance.

**Important!**


- Allow only personnel trained by Mimaki engineers to clean the head nozzle surface. Allowing those without adequate training to clean nozzle surfaces may result in head failure.





- Use only the supplies specified by Mimaki. Cleaning with other products may cause print head wear.



- Do not clean the nozzle surfaces using cotton or other materials that may shed fibers. Fibers from such materials may cause nozzle clogging.




- 1 From the MPC menu, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Tap [Daily maintenance] > [Maintenance wizard], then tap [Head maintenance].**
  - The carriage moves to the maintenance space.
- 3 Switch the maintenance switch to maintenance mode.**  **"Maintenance Switch"(P. 39)**
- 4 Slide the maintenance cover on the left side of the Y-bar.**
  - Lift the lever and slide it to the left.




## 5 The nozzle surface is cleaned.

- Gently press a cleaning stick moistened with maintenance fluid against the nozzle surface for about 10 seconds.



- Do not rub or press the cleaning stick with excessive force against the nozzle surface. Doing so may cause print head wear.
- Do not reuse cleaning sticks.

## 6 Once cleaning is complete, slide the maintenance cover on the left side of the Y-bar to close it and tap [Complete].



- Make sure the maintenance cover is returned to the correct position.

## 7 Switch the maintenance switch to print mode. **"Maintenance Switch"**(P. 39)

## 8 Tap [Complete] > [Finish].

## 9 Execute cleaning (in normal mode).

-  **"Head Cleaning"**(P. 93)

## 10 Make a test print and check the print results.

- Repeat the cleaning and test printing process until the print results appear normal.

## 4.4 Consumable Item Replacement

To order replacement consumable items, contact your local dealer or our service office.

For more information on consumable items, refer to our website. <https://mimaki.com/supply/inkjet.html>




- Do not store consumables where children may enter.





- When disposing of consumable items, contact an industrial waste disposal operator or dispose of in accordance with local laws and regulations.

### Wiper Replacement


The machine maintains a count of the number of wiping cycles. Once the specified value is reached, [0605] will appear in SYSTEM ALARM on the touch panel. Replace dirty or warped wipers with new ones.

- 1 From the MPC menu, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Tap [Replace parts] > [Replace wiper].**
  - The carriage moves over the platen.
- 3 Switch the maintenance switch to maintenance mode.**  **"Maintenance Switch"(P. 39)**
- 4 Remove the wiper.**
  - Hold the lugs on both sides of the wiper bracket, then pull out the wiper.



- 5 Clean the wiper cleaner.**
  -  **"Wiper Cleaning"(P. 157)**

## 6 Mount a new wiper.



## 7 Tap [Complete] once replacement is complete.

- The wiper usage count is reset.

## 8 Switch the maintenance switch to print mode and tap [OK]. ["Maintenance Switch"\(P. 39\)](#)

# Carriage Filter Replacement


Check the mist filters and replace if very dirty.



- Switch the maintenance switch to maintenance mode before carrying out maintenance.

## 1 Remove the carriage filter covers.

- Remove the screws, then remove the filter covers.



- Filters are positioned on the left and right of the carriage.

## 2 Install new filters.

## 3 Install the filter covers.

- Left and right of carriage: Fit the tabs on the bottom of the filter cover to the carriage cover, then secure with screws.

## Blower Filter Replacement

Check the blower filter condition, and replace if especially dirty.


- Replacement guide: Once every six months (\*Varies depending on extent of contamination, usage environment, and volume printed.)



- Turn off the main power before performing maintenance tasks.


### 1 Remove the side cover.

- Remove the knob screw, then slide the cover upward to remove it.




### 2 Remove the filter box cover.

- Remove the three filter box clamps, then remove the cover.



### 3 Replace the filter.

- Replace the cylindrical filter with a new filter.





## 4 Reattach the filter box cover and the side cover.

- Reattach the three filter box clamps, and reattach the knob screw on the side cover.

## Ink filter replacement

### ● Ink filter replacement timing

Replace the ink filter for the corresponding path if one of the following messages appear in SYSTEM ALARM or if the result of the supply test is less than 45 cc.

Message	Status	Remarks
067D:09(ZZZZZZZZ)INK SUPPLY WARN	The ink supply rate has started to drop.	Printing and maintenance are still possible, but it is recommended that the ink filter be replaced as a precaution.
061 B:09(ZZZZZZZZ)INK SUPPLY	Ink cannot be supplied to the sub-tank.	Printing is not possible, and normal maintenance such as auto cleaning is not possible. While the basic maintenance operations are possible, leaving the machine in this state may lead to nozzle clogging that cannot be remedied. The ink filters therefore must be replaced.

\* "ZZZZZZZZ" indicates the path number. (\_3\_ for path 3 and \_6\_ for path 6)



- Ink filters can be replaced by the operator only on machines compatible with the simple filter replacement kit.




- be sure to wear the included safety glasses and gloves.
- If the messages described persist even after replacing the ink filters, contact Mimaki Technical Support.

### ● Ink filter replacement procedure



- 1 From MENU on the touch panel, tap [MAINTENANCE].**
  - The Maintenance menu is displayed.
- 2 Select [Replace parts] > [Replace ink filter], then tap [Start].**

### 3 Open the F maintenance cover as instructed on the wizard screen.




### 4 Remove the fitting below the filter.

- Press down on the fitting latch, then pull out the insert.



- Be sure to press down the latch fully before removing the insert. If you try to force off the insert without pressing down the latch fully, there is a risk of damaging the O-ring on the fitting, which may cause ink leakage.

## 5 Remove the fitting above the filter.



## 6 Detach the tube from the filter.



- Lay paper towels around the area before starting replacement work to protect the surrounding area from ink when disconnecting tubes.




## 7 Attach the tube to the new filter.



- Mount the ink filter so that the arrow engraved on it is pointing upward.


## 8 Attach the filter to the upper fitting.




## 9 Attach the tube to the lower fitting.




- Be sure to press down the latch fully when inserting the fitting. If you try to forcibly insert the fitting without pressing down the latch fully, there is a risk of damaging the O-ring on the fitting, which may cause ink leakage.
- Take care not to push in the valve at the tip of the fitting when connecting the fitting. If the valve is pushed in, ink may leak out, and air may enter the ink paths, causing malfunctioning.




Valve not pushed in  
(valve sealed)




Valve pushed in  
(valve open)



## 10 Mount the filter by pushing into the filter BKT.




## 11 Tighten the fittings above and below the filter, and recheck to confirm that they are not loose.



12 Check to confirm that the fittings are securely connected.

(1) There are no gaps in the fittings.




(2) The fittings do not detach when pulled gently.

13 Close the F maintenance cover.

14 Perform a supply test from the MPC [MAINTENANCE] menu. "Performing supply test"(P. 169)

15 Check to confirm that the test results are less than 45 cc.



- If the test results are less than 45 cc immediately after replacing the filters, contact Mimaki Technical Support.



# Chapter 5 Troubleshooting



**This chapter**

This chapter describes corrective action for troubleshooting and messages on the display.


Troubleshooting.....	184	Image defects occur.....	185
The power does not turn on. ....	184	Ink has leaked out.....	186
Printing is not possible. ....	184	Touch panel operation is not possible. ....	186
The media jams or the media is dirty. ....	184	Problems Indicated by Messages .....	187
The media is skewed (winding shift). ....	184	Collecting Logs.....	202

## 5.1 Troubleshooting

For information on troubleshooting, refer to this chapter. Refer to the Mimaki website (<https://mimaki.com/support/>) for frequently asked questions (FAQs) about the machine and customer support videos.

If the recommended corrective action does not resolve the problem, contact your local dealer or our service office.

### The power does not turn on.

Points to check	Corrective action
Is the main power supply turned on?	Turn on the main power supply. ☞ "Turning On the Power"(P. 151)
Is the PRINTER STATUS icon on the touch panel set to  ?	Turn the power on. ☞ "Power Supply"(P. 150)

### Printing is not possible.

Points to check	Corrective action
Is the LAN cable connected to the machine also connected to the control PC?	Insert the LAN cable connector into the LAN port until it clicks into place. ☞ "System Configuration"(P. 40)
Does an "Ink end" message appear in SYSTEM ALARM on the touch panel?	Replace with new ink. ☞ "Ink Tank Replacement Method"(P. 56)
Does a message appear in SYSTEM ALARM on the touch panel?	Take appropriate measures based on the message. ☞ "SYSTEM ALARM"(P. 124)☞ "Problems Indicated by Messages"(P. 187)


### The media jams or the media is dirty.

Points to check	Corrective action
Are you using the recommended media?	Make sure you are using the recommended media. <a href="https://mimaki.com/supply/inkjet.html">https://mimaki.com/supply/inkjet.html</a>
Are you using curled media?	Do not use curled media or media with folded ends.

### The media is skewed (winding shift).

#### ● Winding shift

Over time, strong forces acting in the core direction may cause the media to shift outward from the winding core side as it is taken up.





1. **Recover the take-up roll when it reaches approximately 1,500 m.**

Winding shift tends to occur more easily beyond 1,500 m. Regularly recovering the take-up roll can help reduce the impact of winding shift on subsequent processes.

2. **Dry ink sufficiently on transfer paper.**

Winding shift is more likely to occur when the ink is not sufficiently dried. Check the heater temperature setting, and check to confirm that the ink is sufficiently dried during take-up.

3. **Reduce the number of passes.**

The extent of winding shift varies depending on the feed rate. Reducing the number of passes can help reduce the effects of winding shift.

## Image defects occur.

Symptom / Points to check	Corrective action
White stripes, blurs, and dark stripes occur. (Scan (horizontal) direction)	<ol style="list-style-type: none"> <li>1. Remove any paper scraps or other debris adhering to areas over which the print head passes. (🔧 <a href="#">"Platen Cleaning"(P. 163)</a>)</li> <li>2. Perform the procedure described in (🔧 <a href="#">"Head Cleaning"(P. 93)</a>).</li> <li>3. Perform the procedure described in (🔧 <a href="#">"Wiper Cleaning"(P. 157)</a>).</li> <li>4. Perform the procedure described in (🔧 <a href="#">"Carriage Underside Cleaning"(P. 159)</a>).</li> </ol>
Offsetting occurs during bidirectional printing.	<ol style="list-style-type: none"> <li>1. Perform the procedure described in (🔧 <a href="#">"Correcting the Drop Position"(P. 95)</a>).</li> </ol>
Ink droplets drip during printing.	<ol style="list-style-type: none"> <li>1. Perform the procedure described in (🔧 <a href="#">"Wiper Cleaning"(P. 157)</a>).</li> <li>2. Perform the procedure described in (🔧 <a href="#">"Carriage Underside Cleaning"(P. 159)</a>).</li> <li>3. Perform the procedure described in (🔧 <a href="#">"Head Cleaning"(P. 93)</a>).</li> <li>4. Set auto maintenance. (🔧 <a href="#">"Maintenance Menu"(P. 127)</a>)</li> </ol>
Clear clogged nozzles.	<ol style="list-style-type: none"> <li>1. Perform the procedure described in (🔧 <a href="#">"Head Cleaning"(P. 93)</a>).</li> <li>2. Perform the procedure described in (🔧 <a href="#">"Wiper Cleaning"(P. 157)</a>).</li> <li>3. Perform the procedure described in Ink fillup (Print head).</li> <li>4. Perform the procedure described in (🔧 <a href="#">"Wiper Replacement"(P. 174)</a>).</li> <li>5. Set [MAINTENANCE] &gt; [Nozzle recovery] &gt; [Nozzle recovery] to "On".</li> </ol>
Nozzle clogging occurs during standby.	Check to confirm that the station is not exposed to direct drafts, such as from air conditioners. If the station is exposed to direct drafts, take measures to protect it, such as by installing a partition between the machine and the air conditioner.
Is the head gap excessive?	Reduce the head gap. If the head gap cannot be reduced, increase flushing frequency during printing (🔧 <a href="#">"Maintenance Menu"(P. 127)</a> ) or make regular test prints to check for nozzle clogging.
Are there any ink colors that aren't used much?	Increase the refresh level (🔧 <a href="#">"Setting 1 Menu"(P. 142)</a> ) during printing. Discharge from infrequently used nozzles tends to be inconsistent. Increasing the refresh level will allow more frequent nozzle use but increase ink consumption.
Are you using media easily affected by static electricity?	Increase flushing intervals during printing (🔧 <a href="#">"Maintenance Menu"(P. 127)</a> ) (🔧 <a href="#">"Setting 1 Menu"(P. 142)</a> ) or make regular test prints to check for nozzle clogging.
Is the machine installed in a location with low humidity?	Increase the humidity by installing a humidifier or similar equipment. When printing continuously, increase flushing frequency during printing (🔧 <a href="#">"Setting 1 Menu"(P. 142)</a> ) or make regular test prints to check for nozzle clogging.

Symptom / Points to check	Corrective action
Is the machine installed in a location with significant amounts of airborne dust or powder?	Install the machine in a location free of excessive dust or powder (office equivalent: dust levels = $0.15 \text{ mg/m}^3$ ). If the printer is installed elsewhere, make regular test prints to confirm no nozzle clogging occurs.

## Ink has leaked out.



- If an ink leak occurs, turn off the main power immediately and turn off the breaker. Then, contact your local dealer or our service office.

## Touch panel operation is not possible.







Points to check	Corrective action
Are any objects such as tape or labels affixed to the touch panel screen or the black outer frame?	Touch panel operation may not be possible if objects such as tape or labels are attached to it. Please remove any such objects before operation.
Is the touch panel dirty?	If it is very dirty, gently wipe off the dirt with a soft cloth.





## 5.2 Problems Indicated by Messages



If a problem is detected, the buzzer will sound and a message will appear in SYSTEM ALARM on the touch panel. Take the appropriate action in accordance with the content of the message. If a message reappears even after taking the prescribed action, contact your local dealer or our service office.

Error number	Error level	Message	Cause	Corrective action
0108	2	HD TYPE	<ul style="list-style-type: none"><li>• A problem was detected with head control.</li></ul>	<ol style="list-style-type: none"><li>1. Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li><li>2. If the error appears again, contact your local distributor, our sales office, or service center.</li></ol>
010E	2	FROM CLEAR	<ul style="list-style-type: none"><li>• A problem was detected with the control PCB.</li></ul>	
010F	2	FROM WRITE		
0115	2	PCB MAIN-F1		
0116	2	PCB MAIN-F2		
011F	2	PCB SLIDER		
0122	2	PRAM NONE		
0123	2	PRAM DATA		
0124	2	PRAM ADDR		
0127	2	POWER OFF		
0128	2	HDC FIFO		
0129	0	BATTERY EXCHANGE	<ul style="list-style-type: none"><li>• Internal clock battery depletion was detected.</li></ul>	<ul style="list-style-type: none"><li>• Contact your local distributor, our sales office, or service center.</li></ul>
012A	2	HDC SPEED	<ul style="list-style-type: none"><li>• A problem was detected with head control.</li></ul>	
012D	2	PCB MAIN-F4	<ul style="list-style-type: none"><li>• A problem was detected with the control PCB.</li></ul>	<ol style="list-style-type: none"><li>1. Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li><li>2. If the error appears again, contact your local distributor, our sales office, or service center.</li></ol>
012E	2	HeadFaild	<ul style="list-style-type: none"><li>• A problem was detected with the head.</li></ul>	
0151	2	Main PCB V1R2	<ul style="list-style-type: none"><li>• A problem was detected with the control PCB.</li></ul>	
0152	2	Main PCB V2R5		
0153	2	Main PCB V3R3		
0154	2	Main PCB V05		
015F	2	Head Drive Hot	<ul style="list-style-type: none"><li>• A problem was detected with the control PCB.</li></ul>	
0171	2	NEW HEAD CONNECT	<ul style="list-style-type: none"><li>• New head connection was detected.</li></ul>	
0186	2	HDC WAVEFLOW	<ul style="list-style-type: none"><li>• A problem was detected with head control.</li></ul>	
0189	2	COM VOLT		

Error number	Error level	Message	Cause	Corrective action
018C	2	Main PCB V12	<ul style="list-style-type: none"><li>A problem was detected with the control PCB.</li></ul>	<div>1. Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</div> <div>2. If the error appears again, contact your local distributor, our sales office, or service center.</div>
018D	2	PCB EXIO1		
018E	2	FLS NOT COMP	<ul style="list-style-type: none"><li>A problem was detected with head control.</li></ul>	
018F	2	OFFSET WAVE		
0190	2	Main PCB V_V1	<ul style="list-style-type: none"><li>A problem was detected with the control PCB.</li></ul>	
019E	2	HDC FUSE ERROR		
01BB	2	COMIO VHV1		
01BF	2	PCB MAIN-F2/F3		
01D1	2	PCB EXIO-FUSE		
01D8	2	HEAD XHOT	<ul style="list-style-type: none"><li>A problem was detected with the head temperature.</li></ul>	
01E6	0	PRAM SIZE	<ul style="list-style-type: none"><li>A problem was detected with the control PCB.</li></ul>	
01E7	2	PCB INKCTRL1		
01EA	2	PCB EXIO2		
0201	1	COMMAND	<ul style="list-style-type: none"><li>A communication error was detected between the control PC and printer.</li></ul>	
0202	1	PARAMETER		
0203	2	Ment Command		
030C	2	SCAN DATA TIMEOUT	<ul style="list-style-type: none"><li>A communication error was detected.</li></ul>	
0310	2	PORT OPEN ERROR		
0311	2	ACK ERROR		
0312	2	CMD ERROR		
0313	2	CMD TIMEOUT		
0314	2	NOTICE ERROR		
0401	2	MOTOR X	<ul style="list-style-type: none"><li>A problem was detected with the X motor.</li></ul>	
0402	2	MOTOR Y	<ul style="list-style-type: none"><li>A problem was detected with the Y motor.</li></ul>	
0405	0	STATION ERROR	<ul style="list-style-type: none"><li>The carriage attempted to move beyond the upper limit.</li></ul>	
0406	2	Wiper origin detection failure	<ul style="list-style-type: none"><li>The wiper origin could not be detected.</li></ul>	
041B	1	MEDIA NEAR END	<ul style="list-style-type: none"><li>The remaining amount of media is low. Or the media roll diameter is small. * Near end</li></ul>	<ul style="list-style-type: none"><li>Replace with new roll media.</li></ul>

Error number	Error level	Message	Cause	Corrective action
			detection has a margin of error of approximately 10 m.	
0423	1	TAKE-UP TENSION-BAR	<ul style="list-style-type: none"> <li>Take-up tension bar initialization failed.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media has been correctly loaded from the printing surface to the take-up shaft.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the take-up shaft rotation direction switch is correctly set for the media orientation.</li> </ol>
0424	1	FEEDING TENSION-BAR	<ul style="list-style-type: none"> <li>Feeding tension bar initialization failed.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media has been correctly loaded from the feeding shaft to the printing surface.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the feeding shaft rotation direction switch is correctly set for the media orientation.</li> </ol>
0425	1	TAKE-UP TENSION_BAR DROP DOWN	<ul style="list-style-type: none"> <li>The take-up tension bar dropped below the limit position.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media is loaded via the correct path.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the take-up unit is rotating.</li> </ol>
0426	1	FEEDING TENSION_BAR DROP DOWN	<ul style="list-style-type: none"> <li>The feeding tension bar dropped below the limit position.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media is loaded via the correct path.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the feeding unit is rotating.</li> </ol>
0429	1	TAKE-UP TENSION-BAR LIMIT OVER	<ul style="list-style-type: none"> <li>The take-up tension bar moved beyond the movement limit position.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media is loaded via the correct path.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the take-up unit is rotating.</li> </ol>
042A	1	FEEDING TENSION-BAR LIMIT OVER	<ul style="list-style-type: none"> <li>The feeding tension bar moved beyond the movement limit position.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the media is loaded via the correct path.  <a href="#">"Loading Media on to the Printer Main Unit"(P. 81)</a></li> <li>Check to confirm that the feeding unit is rotating.</li> </ol>
0441	2	HEADHEIGHT WRONG	<ul style="list-style-type: none"> <li>A problem was detected with vertical head control.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>








Error number	Error level	Message	Cause	Corrective action
0449	2	SCAN COORD(MIN)	<ul style="list-style-type: none"> <li>A problem was detected with Y motor control.</li> </ul>	<ul style="list-style-type: none"> <li>Turn off the main power supply for the machine and wait briefly before turning the power back on. If the error appears again, contact your local distributor, our sales office, or service center.</li> </ul>
044A	2	SCAN COORD (MAX)		
0481	3	Take-up Shaft Position	<ul style="list-style-type: none"> <li>The take-up shaft ejection position could not be detected.</li> </ul>	<ol style="list-style-type: none"> <li>Execute [Winding] &gt; [Rotate roll to removable position] again.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0482	3	Feeding Shaft Position	<ul style="list-style-type: none"> <li>The feeding shaft ejection position could not be detected.</li> </ul>	<ol style="list-style-type: none"> <li>Execute [Feeding] &gt; [Rotate roll to removable position] again.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0483	1	Take-up INVERTER alarm	<ul style="list-style-type: none"> <li>A problem was detected with the take-up motor inverter unit.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0484	1	Feeding INVERTER alarm	<ul style="list-style-type: none"> <li>A problem was detected with the feeding motor inverter unit.</li> </ul>	
0485	1	Take-up Emergency Button is pushed	<ul style="list-style-type: none"> <li>The take-up unit emergency stop switch was pressed.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the emergency stop switch on the take-up unit.</li> </ul>
04A0	1	X serbo amp error	<ul style="list-style-type: none"> <li>A problem was detected with the servo amplifier (X motor).</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again even after turning the power back on, contact your local distributor, our sales office, or service center.</li> </ol>
04A1	1	Y serbo amp error	<ul style="list-style-type: none"> <li>A problem was detected with the servo amplifier (Y motor).</li> </ul>	
04AF	0	Y motor position mismatch	<ul style="list-style-type: none"> <li>A problem was detected with the Y motor coordinates.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0505	1	MEDIA JAM	<ul style="list-style-type: none"> <li>The media jam sensor was triggered.</li> </ul>	<ol style="list-style-type: none"> <li>Remove the media in contact with the carriage and reload with fresh media.</li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ol>
0509	2	HDC Position count	<ul style="list-style-type: none"> <li>A problem was detected with position control.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>








Error number	Error level	Message	Cause	Corrective action
050A	3	Y origin detection failure	<ul style="list-style-type: none"> <li>A problem was detected with Y origin detection (initialization).</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
050F	2	L-SCALE BLACK	<ul style="list-style-type: none"> <li>A problem was detected with the linear scale.</li> </ul>	
0511	3	Z origin detection failure	<ul style="list-style-type: none"> <li>A problem was detected with Z origin detection (initialization).</li> </ul>	
0519	2	NEGATIVE PRESS SENSOR	<ul style="list-style-type: none"> <li>A problem was detected with the negative pressure sensor.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
051A	2	POSITIVE PRESS SENSOR	<ul style="list-style-type: none"> <li>A problem was detected with the positive pressure sensor.</li> </ul>	
0531	2	WRONG INKTANK SENSOR	<ul style="list-style-type: none"> <li>A problem was detected with the weight sensor on the ink supply unit.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the ink tank is correctly mounted, it has not been impacted, and no object has been placed on top.</li> <li>If the error appears even after checking, perform [Maintenance] &gt; [Other maintenance] &gt; [Ink tank calibration].</li> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on. If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0542	1	Emergency switch	<ul style="list-style-type: none"> <li>An emergency stop switch was pressed.</li> </ul>	<ol style="list-style-type: none"> <li>Eliminate the cause for which the emergency stop switch was pressed.</li> <li>Reset the emergency stop switch.</li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a> <ul style="list-style-type: none"> <li>Clearing the alarm will start the initial operations.</li> </ul> </li> <li>If the error is not cleared, contact your local distributor, our sales office, or service center.</li> </ol>
054A	2	PDC Position interrupt	<ul style="list-style-type: none"> <li>A problem was detected with print control.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
054D	0	HDCE Cooling Fan Error	<ul style="list-style-type: none"> <li>An error was detected with the HDCE cooling fan rotation.</li> </ul>	







Error number	Error level	Message	Cause	Corrective action
0556	3	Y LIMIT SENSOR	<ul style="list-style-type: none"> <li>The carriage has exceeded the operating range in the Y direction.</li> </ul>	<ul style="list-style-type: none"> <li>Contact your local distributor, our sales office, or service center.</li> </ul>
0557	1	Light curtain detects obstacles	<ul style="list-style-type: none"> <li>The light curtain detected an obstacle.</li> </ul>	<ol style="list-style-type: none"> <li>Remove the obstacle from the light curtain detection area.  <a href="#">"Light Curtain"(P. 37)</a></li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ol>
0558	0	PDC Scan position	<ul style="list-style-type: none"> <li>A scan coordinate error occurred.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0561	3	Carriage Cap Sensor	<ul style="list-style-type: none"> <li>A problem was detected with the carriage cap sensor.</li> </ul>	<ul style="list-style-type: none"> <li>Contact your local distributor, our sales office, or service center.</li> </ul>
0601	0	INK NEAR END	<ul style="list-style-type: none"> <li>The ink in the ink tank has run out.</li> </ul>	<ul style="list-style-type: none"> <li>Install an ink tank as follows:</li> </ul> <ol style="list-style-type: none"> <li>Lift the cap cover and detach the fitting.</li> <li>Load a new ink tank.</li> <li>Connect the fitting and lower the cap cover.</li> <li>Execute [CLEAR ALARM].</li> </ol> <p>If the warning persists, contact your local distributor, our sales office, or service center.</p>
0602	1	INK END	<ul style="list-style-type: none"> <li>Available ink has run out.</li> </ul>	
0603	0	NO INK TANK	<ul style="list-style-type: none"> <li>No ink tank was detected.</li> </ul>	
0605	0	REPLACE WIPER	<ul style="list-style-type: none"> <li>It is time to replace the wiper.</li> </ul>	<ol style="list-style-type: none"> <li>Replace the wiper.  <a href="#">"Wiper Replacement"(P. 174)</a></li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ol>
0607	0	STATION CLEANING	<ul style="list-style-type: none"> <li>Station maintenance has not been performed for a long period of time.</li> </ul>	<ul style="list-style-type: none"> <li>Perform station maintenance as follows:</li> </ul> <ol style="list-style-type: none"> <li>Clean the station.  <a href="#">"Wiper Cleaning"(P. 157)</a></li> <li>Clean the wiper.</li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ol>
0617	1	WRONG SUBTANK SENSOR	<ul style="list-style-type: none"> <li>A problem was detected with the sub-tank fluid level sensor.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>






Error number	Error level	Message	Cause	Corrective action
061A	1	INK OVERFLOW	<ul style="list-style-type: none"> <li>Sub-tank sensor limit was detected.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears even after clearing, contact your local distributor, our sales office, or service center.</li> </ol>
061B	1	INK SUPPLY	<ul style="list-style-type: none"> <li>Ink cannot be supplied to the sub-tank.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the ink tank fittings are connected and the cap cover is mounted.  <a href="#">"Replacing the ink tank"(P. 56)</a> <ul style="list-style-type: none"> <li>This error may occur if the machine is allowed to stand for extended periods after Near End has occurred.</li> <li>Replace the ink filter.  <a href="#">"Ink filter replacement"(P. 177)</a></li> </ul> </li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again even after clearing, select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
061C	1	NEGATIVE PRESS CONTROL	<ul style="list-style-type: none"> <li>Negative pressure control could not be initiated.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
061D	1	NEGATIVE PRESS NOT ENOUGH	<ul style="list-style-type: none"> <li>Proper negative pressure cannot be maintained.</li> </ul>	
061E	1	NEGATIVE PRESS OVER	<ul style="list-style-type: none"> <li>Excessive negative pressure</li> </ul>	
061F	1	POSITIVE PRESS CONTROL	<ul style="list-style-type: none"> <li>Positive pressure control could not be initiated.</li> </ul>	
0620	1	POSITIVE PRESS NOT ENOUGH	<ul style="list-style-type: none"> <li>Proper positive pressure cannot be maintained.</li> </ul>	
0621	1	POSITIVE PRESS OVER	<ul style="list-style-type: none"> <li>Excessive positive pressure</li> </ul>	<ol style="list-style-type: none"> <li>Check whether there are any ink leaks in the vicinity of the Ink tank.</li> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0637	2	INK LEAK	<ul style="list-style-type: none"> <li>A ink leak was detected at the ink supply unit.</li> </ul>	

Error number	Error level	Message	Cause	Corrective action
066B	2	SUBTANK EMPTY	<ul style="list-style-type: none"> <li>There is no ink in the sub-tank.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the Ink tank fittings are connected and the cap cover is mounted.  <a href="#">"Replacing the ink tank"(P. 56)</a> <ul style="list-style-type: none"> <li>This error may occur if the machine is allowed to stand for extended periods after Near End has occurred.</li> <li>Replace the ink filter.  <a href="#">"Ink filter replacement"(P. 177)</a></li> </ul> </li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again even after clearing, select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0678	0	INK CIRCULATION WARN	<ul style="list-style-type: none"> <li>A problem was detected with ink circulation control.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the tube fittings are securely connected to the Ink tank.</li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again even after clearing, select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
067D	0	INK SUPPLY WARN	<ul style="list-style-type: none"> <li>A drop in the ink supply speed to the sub-tank was detected.</li> <li>The ink filter may be becoming clogged.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the Ink tank fittings are connected and the cap cover is mounted.  <a href="#">"Replacing the ink tank"(P. 56)</a> <ul style="list-style-type: none"> <li>This error may occur if the machine is allowed to stand for extended periods after Near End has occurred.</li> <li>Replace the ink filter.  <a href="#">"Ink filter replacement"(P. 177)</a></li> </ul> </li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again even after clearing, select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> </ol>

Error number	Error level	Message	Cause	Corrective action
				4. If the error appears again, contact your local distributor, our sales office, or service center.
0686	0	Subtank Discharge	<ul style="list-style-type: none"> <li>A problem was detected with the sub-tank discharge process.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0687	0	Purified Water Tank None	<ul style="list-style-type: none"> <li>The purified water tank was not detected.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the purified water tank is correctly mounted, then perform [CLEAR ALARM].  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0688	0	Purified Water END	<ul style="list-style-type: none"> <li>There is no purified water in the purified water tank.</li> </ul>	<ol style="list-style-type: none"> <li>Replenish purified water in the purified water tank.  <a href="#">"Purified Water Replenishment Procedure"(P. 62)</a></li> <li>Check to confirm that there is sufficient purified water in the purified water tank, then perform [CLEAR ALARM].  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0689	0	Purified Water NEAR END	<ul style="list-style-type: none"> <li>There is only a little purified water remaining in the purified water tank.</li> </ul>	
068A	0	Purified Water Tank Sensor	<ul style="list-style-type: none"> <li>A problem was detected with the purified water tank sensor (load cell).</li> </ul>	<ol style="list-style-type: none"> <li>Perform [Maintenance] &gt; [Other maintenance] &gt; [Purified water tank calibration].</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
068B	0	Check InkTank Cap	<ul style="list-style-type: none"> <li>The supply unit cap was detected as detached.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the supply unit Ink tank cap cover is correctly attached, then perform [CLEAR ALARM].  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
068C	0	ST Tub Level Sensor	<ul style="list-style-type: none"> <li>A problem was detected with the station moisture tray fluid level sensor.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
068D	0	ST Tub solution Low	<ul style="list-style-type: none"> <li>The station moisture tray fluid level is below the minimum.</li> </ul>	<ol style="list-style-type: none"> <li>Check the fluid level in the station moisture tray, and replenish with purified water if it is low.</li> <li>Perform [CLEAR ALARM] after replenishing the purified water.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>

Error number	Error level	Message	Cause	Corrective action
068E	2	ST Tub solution Full	<ul style="list-style-type: none"> <li>The station moisture tray fluid level exceeds the maximum.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>Clearing an alarm will attempt draining for up to 20 seconds. If the alarm is still displayed even after you clear it multiple times, or if fluid is not drained to the waste ink tank when the alarm is cleared, contact your local distributor, our sales office, or service center.</li> </ol>
068F	0	ST Tub solution Supply	<ul style="list-style-type: none"> <li>A problem was detected with the station moisture tray purified water supply.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the purified water tank is correctly mounted, then perform [CLEAR ALARM].  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0690	0	Negative Press Leak	<ul style="list-style-type: none"> <li>A problem was detected with negative pressure control.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0691	2	INK LEAK in Carriage	<ul style="list-style-type: none"> <li>A ink leak was detected inside the carriage.</li> </ul>	<ol style="list-style-type: none"> <li>Check whether there are any ink leaks in the vicinity of the carriage.</li> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0694	0	Check InkTank Connection	<ul style="list-style-type: none"> <li>A problem was detected with the ink tank fitting connection.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the Ink tank fittings are securely connected.</li> <li>Execute [CLEAR ALARM].  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0702	2	THERMISTOR CONNECT	<ul style="list-style-type: none"> <li>A problem was detected with the heater thermistor connection.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0703	1	Heater temperature not reached	<ul style="list-style-type: none"> <li>The heater temperature setting is not reached even when heated beyond the stipulated duration.</li> </ul>	<ol style="list-style-type: none"> <li>Check to confirm that the room temperature is within the permissible ambient temperature range.  <a href="#">"Specifications"(P. 206)</a></li> <li>Check to confirm that the voltage is within the rated voltage range for the machine.  <a href="#">"Specifications"(P. 206)</a></li> </ol>

Error number	Error level	Message	Cause	Corrective action
				<ol style="list-style-type: none"> <li>Lower the heater temperature setting, and check whether an error occurs.</li> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0710	2	HEATER TEMP ERROR	<ul style="list-style-type: none"> <li>A problem was detected with the heater temperature.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
071E	0	Head Temperature Mismatch	<ul style="list-style-type: none"> <li>A problem was detected with the head temperature.</li> </ul>	<ol style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
071F	2	Head Thermistor Error		
0759	1	HEATER UNCONNECTED	<ul style="list-style-type: none"> <li>The drying heater is not connected.</li> </ul>	<ol style="list-style-type: none"> <li>Connect the connectors on the left and right of the drying unit.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
075A	2	SSR cooling fan abnormal	<ul style="list-style-type: none"> <li>The SSR cooling fan has stopped.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
075B	2	Drying fan abnormal	<ul style="list-style-type: none"> <li>The drying fan has stopped.</li> </ul>	
075C	2	Drying fan sensing thermistor connection	<ul style="list-style-type: none"> <li>A problem was detected with the connection of the thermistor used to detect drying fan operation error.</li> </ul>	
075D	2	SSR operation abnormal	<ul style="list-style-type: none"> <li>A problem was detected with heater control.</li> </ul>	
0801	2	(C)OPCODE	<ul style="list-style-type: none"> <li>A problem was detected with the control PCB.</li> </ul>	
0802	2	(C)SWI		
0803	2	(C)PFTCH ABRT		
0804	2	(C)DATA ABRT		

Error number	Error level	Message	Cause	Corrective action
0806	2	FW/SIO bit		
0807	2	FW/SIO wbsy		
080E	2	FW/FROM prm		
080F	2	FW/SIO vch		
0811	2	FW/SIO read		
0815	2	FW/SIO rsrc		
0816	2	FW/FROM WRC		
0817	2	FW/SaveArea		
081B	2	FW/STACK OV		
0826	2	FW/PrmSaveBuf		
0828	2	Unexpected ERROR		
0829	2	FW/ERASE TIMEOV		
083A	2	PARAMETER ERROR	<ul style="list-style-type: none"> <li>A parameter error was detected.</li> </ul>	
083B	2	MESSAGE ERROR	<ul style="list-style-type: none"> <li>A message between tasks contained an invalid value.</li> </ul>	
0916	2	ROM MISMATCH	<ul style="list-style-type: none"> <li>An update was attempted with mismatched firmware.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0917	1	WIPER MOVE	<ul style="list-style-type: none"> <li>A problem was detected with the wiper operation.</li> </ul>	
091D	1	COVER OPEN	<ul style="list-style-type: none"> <li>The maintenance cover is open.</li> </ul>	<ol style="list-style-type: none"> <li>Close the maintenance cover.</li> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ol>
0935	1	Mode change failure	<ul style="list-style-type: none"> <li>The maintenance switch was operated while the machine was under mechanical control.</li> </ul>	<ul style="list-style-type: none"> <li>Clear the alarm on the touch panel.  <a href="#">"Clearing Alarms"(P. 125)</a></li> </ul>
0B1A	2	PCB BaseIO	<ul style="list-style-type: none"> <li>A problem was detected with the control PCB.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
0B1E	2	PCB BaseIO-FUSE		
0B36	2	PCB INKIO		
0B37	2	PCB WFIO		
0B39	2	PCB WFIO-FUSE		
0B3E	2	PCB LOADCELL AD		
0B48	2	PCB HDCE		
0B49	2	PCB HDCE-VHVFET		

Error number	Error level	Message	Cause	Corrective action
0B4A	2	PCB HDCE-FUSE		
0B4B	2	HDCE PCB V1R2		
0B4C	2	HDCE PCB V2R5		
0B4D	2	HDCE PCB V3R3		
0B54	2	PCB INKIO-FUSE		
0D09	2	HD MEMORY	<ul style="list-style-type: none"><li>A problem was detected with head internal memory access.</li></ul>	<ol style="list-style-type: none"><li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li><li>If the error appears again, contact your local distributor, our sales office, or service center.</li></ol>
0D0B	2	HD CONNECT	<ul style="list-style-type: none"><li>A problem was detected with the head connection.</li></ul>	
0D0C	2	HD THERMIS	<ul style="list-style-type: none"><li>A problem was detected with the head temperature.</li></ul>	
0D1C	2	HD BUSY	<ul style="list-style-type: none"><li>A problem was detected with head control.</li></ul>	
0D1D	2	HD CMD		
C101	0	Command Format ERROR	<ul style="list-style-type: none"><li>A communication error was detected between the control PC and machine.</li></ul>	<ol style="list-style-type: none"><li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li><li>If the error appears again, contact your local distributor, our sales office, or service center.</li></ol>
C102	0	Notify receive ERROR		
C103	0	Respons receive ERROR		
C104	0	No Parameters		
C105	0	Invalid parameter		
C106	0	Respons set ERROR	<ul style="list-style-type: none"><li>An invalid parameter was received.</li></ul>	
C107	0	Notice Respons ERROR	<ul style="list-style-type: none"><li>A communication error was detected between the control PC and machine.</li></ul>	
C111	2	Print data transmission error		
C800	0	Serial number not set	<ul style="list-style-type: none"><li>The serial number has not been set.</li></ul>	<ul style="list-style-type: none"><li>The machine serial number has not been set. contact your local distributor, our sales office, or service center.</li></ul>
C801	2	Destination specification error	<ul style="list-style-type: none"><li>A problem was detected with the machine connection.</li></ul>	<ul style="list-style-type: none"><li>The machine configuration settings are incorrect. contact your local distributor, our sales office, or service center.</li></ul>
C802	2	Device composition error		
C803	2	Version mismatch	<ul style="list-style-type: none"><li>A problem was detected with the version of units in the system.</li></ul>	<ul style="list-style-type: none"><li>The version of units in the system is incorrect. contact your local distributor, our sales office, or service center.</li></ul>



Error number	Error level	Message	Cause	Corrective action
C998	2	System error (datasize)	<ul style="list-style-type: none"> <li>An unexpected error (other than an exception) occurred.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
CC10	0	Cannot execute automatic cleaning	<ul style="list-style-type: none"> <li>Auto cleaning failed.</li> </ul>	Auto maintenance cannot be performed, or an error occurred during performing maintenance. Do the following: <ol style="list-style-type: none"> <li>Confirm that the carriage is in the parking position.</li> <li>Confirm that there are no ink supply system errors.</li> <li>Clear all errors that have occurred.</li> <li>If necessary, perform a machine reset.</li> </ol>
CC11	0	Cannot execute automatic flushing	<ul style="list-style-type: none"> <li>Auto flushing failed.</li> </ul>	
CC20	0	Log upload confirmation	<ul style="list-style-type: none"> <li>Log upload confirmation OK. * This alarm is for confirmation purposes.</li> </ul>	-
B004	0	Please Perform Daily Station Maintenance	<ul style="list-style-type: none"> <li>At least one day has passed since "Daily station maintenance" was last performed.</li> </ul>	<ol style="list-style-type: none"> <li>Perform "Daily station maintenance".   "Wiper Cleaning"(P. 157)   "Wiper Unit Cleaning"(P. 161)           </li> </ol>
B005	0	Please Perform Head Maintenance	<ul style="list-style-type: none"> <li>At least one day has passed since "Head maintenance" was last performed.</li> </ul>	<ol style="list-style-type: none"> <li>Perform "Head maintenance".  "Carriage Underside Cleaning"(P. 159)</li> <li>Clear the alarm on the touch panel.  "Clearing Alarms"(P. 125)</li> </ol>
B006	0	Please Perform Weekly Station Maintenance	<ul style="list-style-type: none"> <li>At least seven days have passed since "Weekly station maintenance" was last performed.</li> </ul>	<ol style="list-style-type: none"> <li>Perform "Weekly station maintenance".   "Wiper Unit Cleaning"(P. 161)           </li> <li>Clear the alarm on the touch panel.  "Clearing Alarms"(P. 125)</li> </ol>
D002	0	CONNECT FAILED	<ul style="list-style-type: none"> <li>A communication error was detected between modules on the PC.</li> </ul>	<ol style="list-style-type: none"> <li>Select [SYSTEM] &gt; [Power] &gt; [Shutdown System]. Turn off the control PC, then turn off the main power supply for the machine. Wait briefly before turning the power back on.</li> <li>If the error appears again, contact your local distributor, our sales office, or service center.</li> </ol>
D003	0	CONNECT TIMEOUT RETRY OVER		
D004	0	SEND FAILED		
D005	0	RECEIVE FAILED		
D006	0	RECEIVE DATA FAILED		
D007	0	RECEIVE NAK DATA		
D008	0	ACK/NAK TIMEOUT RETRY OVER		
D009	0	SEND TIMEOUT		




Error number	Error level	Message	Cause	Corrective action
D010	0	RECEIVE TIMEOUT (Not received)		
D011	0	COMMAND UNDEFINED		
D012	0	RECEIVE TIMEOUT (Length Not achieved)		
D013	0	INITIALIZE ERROR		

# 5.3 Collecting Logs

If a problem arises with the machine, you may be requested by our service engineers or service office to collect the corresponding logs. Please follow the procedure below to collect the logs if requested.

● Log collection tool




No.	Overview
1	Select the data to be collected. <ul style="list-style-type: none"><li>• All: Collects all log data. "All" should normally be selected.</li><li>• Logs and Parameters: Allows either "Operation Logs" or "Setting Parameters" to be selected.</li></ul>
2	Select a destination for saving data to. <ul style="list-style-type: none"><li>• USB: Saves to an external hard drive.<ul style="list-style-type: none"><li>– Choose the output USB device: Select the external hard drive to be saved to.</li><li>– Load USB list: Tap if a particular external hard drive is not listed.</li></ul></li><li>• Cloud Storage: Saves log data directly to Mimaki cloud storage.<ul style="list-style-type: none"><li>– Set the period for which you want to retrieve data: Up to 180 days of log data can be set.</li></ul></li></ul>
3	Tap [Get Data] to start log data acquisition.

## ● Saving Log Data to an External Hard Drive

Save the logs to an external hard drive, and send the data to our service engineers by e-mail or other means.



- Please contact our service engineers if the log data volume is excessive.

- 1 Connect an external hard drive to the machine (control PC).**
- 2 From MENU on the touch panel, tap [SYSTEM] > [Tools] > [Manual Log collection tool].**
  - The log collection tool starts up.  [P. 202](#)
- 3 Select the data to be collected.**
  - "All" should normally be selected.
- 4 Select a destination for saving data to.**
  - Select [USB], then select the external hard drive to be saved to.
- 5 Tap [Get Data].**
  - Data is saved in Zip format to the external hard drive.  
Example: 20211001-0903\_Tiger600\_A1234567\_P.zip




- The log data has been encrypted and can be sent as is.

## ● Uploading the Logs to Cloud Storage

If the machine is connected to the Internet, you can save the logs directly to our cloud storage platform.




- Contact your network administrator for more information regarding network connectivity.
- Please be careful of the size of the log data if you are using a metered Internet connection.

- 1 From MENU on the touch panel, tap [SYSTEM] > [Tools] > [Manual Log collection tool].**
  - The log collection tool starts up.  [P. 202](#)
- 2 Select the data to be saved.**
  - "All" should normally be selected.
- 3 Select a destination for saving data to.**
  - Select [Cloud Storage].
- 4 Set the log data collection interval.**
  - If you select "Logs and Parameters", set the period specified by our service engineer.

## 5 Tap [Get Data].

- The log data is uploaded to the cloud storage platform.
- If it is the first time using this service, the [Cloud Settings] and [ConsentFormDialog] dialog boxes will appear.

### ● [Cloud Settings] dialog box




(1) Select the following check box:

- Allow data collection to the cloud

(2) Set [Region] to [Global], then tap [OK].

### ● [ConsentFormDialog] dialog box



(1) Check the details described, then select the following check boxes:

- I consent to the collection of my data in the cloud
- I agree to the privacy policy

(2) Tap [Agree].

## 6 Please notify our service engineer once the upload is complete.

# Chapter 6 Appendix



**This chapter**  
This chapter describes the machine specifications.

## 6.1 Specifications

Item		Specifications
Print head	Type	On-demand piezo head
	Specifications	8 heads (2 staggered, 4 in-line array)
	Resolution	Y: 300 dpi, 600 dpi X: 600 dpi
Ink set	4-color	B, M, Y, K
Media	Form	Roll media only (3-inch paper core internal diameter)
	Type	Transfer paper
	Max. printing width	1850 mm
	Max. mounting width	1900 mm
	Thickness	1 mm or less (Feed test required)
	Roll spindle	3-inch air chuck shaft
	Roll external diameter	600 mm or less
	Roll weight	300 kg or less (6.6 lb or less)
	Mounting position	Center mounting
	Printing face	Exterior
	Roll end	Taped or loosely affixed to paper core
Machine accuracy	Distance accuracy (Y)	$\pm 0.3$ mm or $\pm 0.3$ % of specified distance, whichever is greater
	Distance accuracy (X)	$\pm 55$ $\mu$ m of intermittent feed amount or $\pm 0.3$ % of specified distance, whichever is greater
	Perpendicularity	$\pm 0.5$ mm/500 mm
	Media skew	Not more than $\pm 10$ mm/2,000 m
Air pressure operation unit	Air gun	Input: 0.6 to 0.8 MPa @Dry air
Printing gap		2.0 mm to 4.0 mm
Origin alignment		Manual input
Ink supply	Ink capacity	2 L internal buffer tank + 10 L external supply unit
	Level detection	Weight detection (load cell)
Waste ink tank		Max. 220 mm $\times$ 350 mm $\times$ 400 mm
Purified water tank		Max. 220 mm $\times$ 350 mm $\times$ 400 mm
Drying unit		Installed underneath machine Temperature setting range: 20 to 70 °C
Interface	Data transfer function	10Gigabit Ethernet/USB3.1, USB2.0 (removable disk)
Languages		English, Japanese
Noise levels	During standby	Not exceeding 55 dB (A)
	Continuous operation	Not exceeding 68 dB (A)

Item		Specifications
Compliance with standards		IEC 62368-1 ETL compliance, CE marking (EMC Directive, Low Voltage Directive, Machinery Directive), CB certified, RoHS, REACH, RCM marking, KC certification, UKCA marking
Power supply specifications <sup>*1</sup>		AC 3-phase 4-wire 380 to 415 V $\pm 5\%$ 50/60 Hz $\pm 1\%$ , max. 25 A
Power consumption		15 kW or less
Installation environment <sup>*2</sup>	Permissible ambient temperature	20 to 30 °C
	Relative humidity	35 to 65%RH (no condensation)
	Temperature range in which accuracy is guaranteed	20 to 25 °C
	Temperature gradient	Not more than $\pm 10$ °C/h
	Dust	Not more than 0.15 mg/m <sup>3</sup> (equivalent to typical office)
	Maximum operating altitude	2000 m
External dimensions <sup>*3</sup>	Width	Not exceeding 5,300 mm (not exceeding 5,850 mm)
	Depth <sup>*4</sup>	Not exceeding 2,800 mm (not exceeding 2,310 mm)
	Height	Not exceeding 1,900 mm (not exceeding 1,950 mm)
Weight <sup>*3, 5</sup>		Not exceeding 1,620 kg (not exceeding 2,300 kg)

\*1. Excluding options

\*2. Ink printing consistency will decrease in conditions outside this range.

\*3. The figures in parentheses indicate package dimensions.

\*4. Including main unit and winding unit (excluding touch panel protruding parts)

\*5. Not including weight of ink.

## 6.2 LICENSE Library

Mimaki printer Firmware

Copyright ©2020 MIMAKI ENGINEERING CO.,LTD. All rights reserved.

This product contain open source software listed in the tables below.

Component	License
StarterWare for ARM® based TI Sitara Processors	BSD-TI

The following license terms and conditions shall apply to the open source software listed in the table above:

BSD-TI

Copyright (C) 2010 Texas Instruments Incorporated - <http://www.ti.com/>

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of Texas Instruments Incorporated nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



# INDEX

## A

Add feed .....	142
After feed .....	115
Alarm .....	122
Alarm list.....	149
Application note .....	149
Apply change.....	138
Auto Maint. ....	127

## B

Bi-direction adjustment value .....	95, 144
Bi-directional adjustment .....	95, 144
Blower filter.....	155
Brake Roller.....	144
Browser area .....	126

## C

Cable carrier .....	34
Capping station .....	34, 37
Carriage.....	34, 36, 155, 159
Carriage filter.....	155
Cleaning .....	123, 127
Clear.....	138
Clear alarm .....	125
Color bar.....	142
Color profile .....	54
Consumables .....	155, 174
Control PC .....	34, 40, 41, 96, 102, 105, 106, 110, 111, 149, 150, 151

## D

Daily maintenance .....	127, 157
Daily station maintenance .....	128, 157
Delete job .....	126
Detailed Job Information .....	114
DISCLAIMERS .....	5
Document .....	149
Drop Position Correction .....	66, 95
Dry feed .....	142
Drying fan .....	155, 165

Drying heater .....	123
Drying unit .....	34, 38, 155
Drying unit Taking out .....	128

---

## E

---

Ejection failures .....	92
Emergency stop switch .....	26, 34
Error List.....	149

---

## F

---

Feed .....	123
Feed Comp.....	143
Feed Control.....	144
Feed switch .....	34
Feeding unit.....	36
Flushing filter .....	155
Folder .....	126

---

## H

---

HDD disk space.....	149
Head Cleaning.....	93
Head gap .....	144
Head maintenance .....	128
Heater.....	143
History .....	122, 148

---

## I

---

Ink.....	122
Ink End .....	56
Ink Filters .....	155
Ink lever .....	36
Ink maintenance .....	164
INK NEAR-END.....	56
INK STATUS .....	122, 124
Ink Supply Unit .....	34
Ink tank .....	36
Ink tank calibration .....	128
Installation guide .....	48, 54, 55
Installation Space .....	24
Interference .....	5
Internal pattern .....	92, 143

---

**J**


---

Jam sensor .....	155, 166
Job .....	40, 96, 102, 106, 110
Job history .....	126
Job import .....	105, 112, 126
Job Information .....	114
Job status area .....	126
Jobs .....	100, 101, 106, 108, 109, 113, 126
JOG button .....	34

---



---

**L**


---

LAN cable .....	40
Languages .....	144
License .....	149
Lifter .....	32
Light Curtain .....	34, 37
Local network .....	41, 96, 106
Logical Seek .....	142

---



---

**M**


---

Machine information .....	149
Machine setting .....	114
Main power supply .....	150
Main power switch .....	34, 150, 151
Maintenance .....	122, 127
Maintenance mode .....	39
Maintenance Switch .....	34
Manual Log collection tool .....	149
MAPS .....	115, 143
Media .....	68, 89, 144
Media near end .....	144
Media origin .....	144
MENU .....	122
Mimaki driver .....	54
MIST FILTER .....	175
Moisture tray .....	37, 155, 167
Moisture tray maintenance .....	128
MPC .....	40, 122, 126
MPC user's guide .....	149

---



---

**N**


---

Network setting .....	144
-----------------------	-----

---

Nozzle check tool .....	127
Nozzle image .....	138
Nozzle recovery registration .....	127
Nozzle recovery table .....	138
Nozzle recovery table filter .....	138
Nozzle Recovery .....	127

---

## O

---

Open PICT Up .....	149
Operation manual .....	149
Origin shift .....	92, 143
Origin shift margin .....	92, 143
Other maintenance .....	128
Over print .....	114

---

## P

---

Pass .....	114
Pause .....	115, 126
PICT Up update .....	149
Platen .....	37, 155, 163
Power .....	149
Powerful Cleaning .....	127
Pre feed .....	142
Print .....	142
Print conditions/settings .....	126
Print direction .....	114
Print head .....	89, 155
Print Length .....	114
Print menu .....	122, 126
Print mode .....	39
Print origin .....	115
Print origin X .....	114
Print origin Y .....	114
PRINTER STATUS .....	122, 123
Purified water tank .....	32, 34
Purified water tank calibration .....	128

---

## Q

---

Queued jobs .....	126
QUICK MENU .....	123

---

## R

---

RasterLink .....	54, 55, 107, 111
Reboot System .....	149
Reference guide .....	107, 111
Refresh .....	142
Removable disk .....	102, 110
Repeat .....	114
Replace ink filter .....	128
Replace parts .....	128, 174
Replace Wiper .....	128, 174
Reset machine .....	149
Resume .....	115, 126
RIP PC .....	32
RIP software .....	40
Rotation direction switch .....	35

---

## S

---

Scan speed .....	114
Scanner .....	127
Scroll buttons .....	138
Select head .....	142
Serial number .....	97, 101, 107, 110
Service maintenance mode .....	149
Set media .....	144
Setting 1 .....	92, 122, 142
Setting 2 .....	89, 95, 122, 144
Shutdown system .....	150
Signal tower .....	34
Signal tower light .....	38
Stop .....	115, 126
Supply test .....	155
Support Video Link .....	149
Symbols .....	6
SYSTEM ALARM .....	122, 124
System information .....	47, 97, 101, 107, 110, 149
System menu .....	123, 149
System setting .....	144

---

## T

---

Table .....	34
Take-up Unit .....	36
Tension bar .....	123
Tension bar initializing switch .....	34

Test pattern .....	126
Test Printing .....	123
Tool .....	149
Touch panel.....	34
TxLink.....	48, 97, 102

---

V

---

Vacuum .....	123
Version .....	149

---

W

---

Warning Labels .....	27
Waste ink tank.....	32, 34, 155, 162
Weekly maintenance .....	128, 161
Weekly station maintenance .....	128, 161
Winding unit.....	34
Wiper .....	155, 157, 174
Wiper unit .....	155

---

X

---

X drive roller .....	155
----------------------	-----

---

Y

---

Y-bar.....	34
------------	----

## **Operation manual**

---

May, 2025

MIMAKI ENGINEERING CO., LTD.

2182-3 Shigeno-otsu, Tomi-shi, Nagano 389-0512 JAPAN

---

D203673-17-30052025

