

ピンチローラー交換手順書 機種別対応表

このたびは、ピンチローラー交換用キット (SPC-0746) をお買い上げいただきありがとうございます。

セット内容

部品名称	数量	部品名称	数量
ピンチローラー	1	Eリング	1
止めネジ	2	ワッシャー	2
弓形Eリング	1		

交換に必要な工具

- (1) 六角レンチ (1.5mm)
- (2) 精密ドライバー (マイナス小)
- (3) ピンセット
- (4) ラジオペンチ
- (5) セロテープ

交換手順書

手順書	主な機種
ピンチローラー交換手順書 1	CG-45,CG-90SD,MX シリーズ ,CG-90AP,CG-90APR,CG-100AP
ピンチローラー交換手順書 2	CG-30,CG-50,CG-101,CG-100SD,CG-61,MC-300
ピンチローラー交換手順書 3	CG-EX,CG-LX,CG-FX/FXII,CG-60st,CG-60SR/SL,CG-SRII

Procedure Manual for Replacing Pinch Roller Correspondence Table by Models

Thank you very much for your purchasing our kit for replacing pinch roller (SPC-0746).

Contents

Part name	Quantity	Part name	Quantity
Pinch roller	1	E-ring	1
Setscrew	2	Washer	2
Arched E-ring	1		

Necessary tools

- (1) Hexagon wrench (1.5mm)
- (2) Precision screwdriver (Small Flat head)
- (3) Tweezers
- (4) Needle-nose plier
- (5) Scotch tape

Procedure Manual for Replacing Pinch Roller

Procedure Manual	Main Models
Procedure Manual for Replacing Pinch Roller 1	CG-45,CG-90SD,MX series, CG-90AP,CG-90APR,CG-100AP
Procedure Manual for Replacing Pinch Roller 2	CG-30,CG-50,CG-101,CG-100SD,CG-61,MC-300
Procedure Manual for Replacing Pinch Roller 3	CG-EX,CG-LX,CG-FX/FXII,CG-60st,CG-60SR/SL,CG-SRII