

# UJF-3042HG / UJF-6042 テーブルタップ位置の訂正

平素は、弊社製インクジェットプリンタをご愛用いただきありがとうございます。


さて、UV インクジェットプリンタ UJF-3042HG/6042(取扱説明書 D202465-11) のタップ位置についての記載に、誤記がございました。  
訂正し、お詫び申し上げます。

今後もミマキエンジニアリング製インクジェットプリンタをご愛用いただきますようお願い申し上げます。



## タップ位置について

メディアをセットするためのテーブルや吸着テーブルにはそれぞれ以下の寸法で M4 タップ (UJF-3042HG: 12 箇所、UJF-6042: 16 箇所) が開いています。  
タップ位置の図面データは、ミマキエンジニアリングダウンロードページ (<http://www.mimaki.co.jp/download>) の「マニュアル」よりダウンロードできます。

• UJF-3042HG



• UJF-6042



- 重要!**
- 図のタップ位置 (○) 以外にもタップ穴 (○) が開いていますが、それらの穴は製造工程で必要な穴のため、使用しないでください。
  - 指定のタップ穴 (○) 以外は、断りなく位置を変更する場合があります。

# UJF-3042HG / UJF-6042 Correction of Table Tap Position

Thank you very much for using our inkjet printers.


We regret to inform you there was a mistake in the description of the tap positions of our UV inkjet printer UJF-3042HG/6042(Operation Manual D202466-11). We have corrected this mistake and apologize for any inconvenience.

We hope that you will continue to enjoy using Mimaki Engineering's inkjet printers.



## About tap position

The table and the vacuum table on which the media set have the M4 tap (UJF-3042HG: for 12 positions, UJF-6042: for 16 positions) of the size below respectively. You can download data illustrating the tap positions from the "Manual" section of the Mimaki Engineering download page (<http://eng.mimaki.co.jp/download/>).

### • UJF-3042HG



### • UJF-6042



### Important!

- Although tap holes (○) are open except the tap position in the drawing (●), they are necessary in the production process. Therefore, please do not use them.
- We may change the position except specified tap holes (●) without prior notice.